


*Multi Reader
AY-V12
Installation Guide*



August 2005

ROSSLARE
SECURITY PRODUCTS

Table of Contents

1. Introduction	3
2. Technical Specifications	4
3. Installation	5
3.1 The Installation Kit	5
3.2 Installing the AY-V12 Multi Reader:	5
4. Wiring Instructions	7
5. Operation Instructions	8
Appendix A: Limited Warranty	9
Appendix B: Technical Support	11

1. Introduction

The AY-V12 Multi Reader is an RFID proximity card reader, utilized with access control systems.




Figure 1 The AY-V12 Multi Reader

This Manual contains the following information:

- Installation
- Wiring Instructions
- Operation Instructions

2. Technical Specifications

Electrical Characteristics

Power Supply Type	Linear type - recommended
Operating Voltage Range	5 - 16VDC
Absolute Maximum (non-operating)	18VDC
Input Current	Standby: 120mA Read: 140mA
Tamper Output	Open collector, active low, max. sink current 30mA
Maximum Cable Distance to Controller	500 ft (150 meters)
Card Read Distance	Weigand 26 output format with a 9" (22 cm) maximum read range

Environmental Characteristics

Operating Temp. Range	25°F to 145° F (-30°C to 63°C)
Operating Humidity	0 – 95% (non-condensing) Suitable for outdoor use (IP54)

Dimensions

Height x Width x Depth	4.92" x 4.92" x 0.83" 125mm x 125mm x 21 mm
Weight	0.628 Lbs. (285g)

3. Installation

3.1 The Installation Kit

The Installation kit comprises of the following items that are to be used during the installation procedure:

- One Installation Template
- Two pan head screws & wall plugs
- One L shaped security screw tool
- Two Security screws

3.2 Installing the AY-V12 Multi Reader:




Figure 2: Removing the Top Cover

Figure 2 shows the front view of the AY-V12 Multi Reader.

When installing the reader, you must remove the snap-off cover to access the screw holes.

The Reader must be mounted with the appropriate screws (not supplied), as described in the template provided.

To Install the Reader:

1. Determine an approximate location for the installation of the Reader.
2. Peel off the back of the self-adhesive installation label template and locate it at the required location.
3. Using the template as a guide, drill two holes (the size of which are indicated in the template) to install the Reader onto the surface,
4. Drill a 7/16" (10mm) hole for the cable. In the event that you are installing the reader on metal, place a grommet or electrical tape around the edge of the hole.
5. Route the interface cable from the Reader to the Controller. A linear type power supply is recommended.



Note:

The Multi Reader can also be mounted using strong epoxy glue. After application, the Reader should be firmly held in place until the glue dries

4. Wiring Instructions

The AY-V12 Multi Reader is supplied with an 18" pigtail, comprising a 6-conductor cable.

To connect the Reader to the Controller:

1. Prepare the Reader cable by cutting its jacket back 1¼" and strip the insulation from the wires, ½".
2. Prepare the Controller cable by cutting its jacket back 1¼" and strip the insulation from the wires, ½".
3. Splice the Reader's pigtail wires to the corresponding Controller wires and cover each joint with insulating tape.

If the tamper output is being utilized, connect the purple wire to the correct input on the Controller.

Reader	Color	Wiegand Output
5~16 VDC	Red	DC+Input
Shield / Ground	Black	Ground
Data 1	White	Data 1
Data 0	Green	Data 0
LEDCTLO	Brown	LED Control
Tamper	Purple	Tamper

4. Trim and cover all unused conductors.



Note:

- The individual wires from the Reader are color-coded according to the Wiegand standard.
- When using a separate power supply for the Reader, this supply and that of the Controller, must have a common ground.
- The Reader's cable shield wire should preferably be attached to an earth ground, or a signal ground connection at the panel, or power supply end of the cable. This configuration is best for shielding the Reader cable from external interference.

5. Operation Instructions

The Reader should be tested after wiring it to a power supply and the Controller.

To test the Reader:

1. Power up the Reader. The LED flashes green on power up (it may flash orange), and the Beeper sounds, three times, thus indicating that the Reader is working properly. The LED returns to its idle state (red).
2. Present the appropriate type of proximity card to the Reader. The LED will momentarily flash green and a short beep is emitted, thus indicating that the card was properly read by the Reader.

The Reader transmits the card's data to the Controller. The Controller checks the data and if it is valid, the LED will change momentarily to green. It then returns to its idle state (red).

The range is measured using a Rosslare Proximity Card (P/N AT-11/12) or equivalent. The range also depends on electrical environment and/or proximity to metal.

Limited Warranty

Appendix A: Limited Warranty

ROSSLARE ENTERPRISES LIMITED S (Rosslare) TWO YEARS LIMITED WARRANTY is applicable worldwide. This warranty supersedes any other warranty. Rosslare's TWO YEARS LIMITED WARRANTY is subject to the following conditions:

Warranty

Warranty of Rosslare's products extends to the original purchaser (Customer) of the Rosslare product and is not transferable.

Products Covered By This Warranty and Duration

ROSSLARE ENTERPRISES LTD. AND / OR SUBSIDIARIES (ROSSLARE) warrants that the AY-V12 RFID proximity card Reader, to be free from defects in materials and assembly in the course of normal use and service. The warranty period commences with the date of shipment to the original purchaser and extends for a period of 2 years (24 Months).

Warranty Remedy Coverage

In the event of a breach of warranty, ROSSLARE will credit Customer with the price of the Product paid by Customer, provided that the warranty claim is delivered to ROSSLARE by the Customer during the warranty period in accordance with the terms of this warranty. Unless otherwise requested by ROSSLARE ENTERPRISES LTD. AND / OR SUBSIDIARIES representative, return of the failed product(s) is not immediately required. If ROSSLARE has not contacted the Customer within a sixty (60) day holding period following the delivery of the warranty claim, Customer will not be required to return the failed product(s). All returned Product(s), as may be requested at ROSSLARE ENTERPRISES LTD. AND /OR SUBSIDIARY'S sole discretion, shall become the property of ROSSLARE ENTERPRISES LTD. AND /OR SUBSIDIARIES.

To exercise the warranty, the user must contact Rosslare Enterprises Ltd. to obtain an RMA number after which, the product must be returned to the Manufacturer freight prepaid and insured

In the event ROSSLARE chooses to perform a product evaluation within the sixty (60) day holding period and no defect is found, a minimum US\$ 50.00 or equivalent charge will be applied to each Product for labor required in the evaluation.

Rosslare will repair or replace, at its discretion, any product that under normal conditions of use and service proves to be defective in material or workmanship. No charge will be applied for labor or parts with respect to defects covered by this warranty, provided that the work is done by Rosslare or a Rosslare authorized service center.

Exclusions and Limitations

ROSSLARE shall not be responsible or liable for any damage or loss resulting from the operation or performance of any Product or any systems in which a Product is incorporated. This warranty shall not extend to any ancillary equipment not furnished by ROSSLARE, which is attached to or used in conjunction with a Product, nor to any Product that is used with any ancillary equipment, which is not furnished by ROSSLARE.

This warranty does not cover expenses incurred in the transportation, freight cost to the repair center, removal or reinstallation of the product, whether or not proven defective. Specifically excluded from this warranty are any failures resulting from Customer's improper testing, operation, installation, or damage resulting from use of the Product in other than its normal and customary manner, or any maintenance, modification, alteration, or adjustment or any type of abuse, neglect, accident, misuse, improper operation, normal wear, defects or damage due to lightning or other electrical discharge. This warranty does not cover repair or replacement where normal use has exhausted the life of a part or instrument, or any modification or abuse of, or tampering with, the Product if Product disassembled or repaired in such a manner as to adversely affect performance or prevent adequate inspection and testing to verify any warranty claim.

ROSSLARE does not warrant the installation, maintenance, or service of the Product. Service life of the product is dependent upon the care it receives and the conditions under which it has to operate.

In no event shall Rosslare be liable for incidental or consequential damages.

Limited Warranty Terms

THIS WARRANTY SETS FORTH THE FULL EXTENT OF ROSSLARE ENTERPRISES LTD. AND IT'S SUBSIDIARIES'S WARRANTY

THE TERMS OF THIS WARRANTY MAY NOT BE VARIED BY ANY PERSON, WHETHER OR NOT PURPORTING TO REPRESENT OR ACT ON BEHALF OF ROSSLARE.

THIS LIMITED WARRANTY IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES. ALL OTHER WARRANTIES EXPRESSED OR IMPLIED, INCLUDING WITHOUT LIMITATION, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE SPECIFICALLY EXCLUDED.

IN NO EVENT SHALL ROSSLARE BE LIABLE FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, OR FOR ANY OTHER INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES, INCLUDING BUT NOT LIMITED TO LOSS OF USE, LOSS OF TIME, COMMERCIAL LOSS, INCONVENIENCE, AND LOSS OF PROFITS, ARISING OUT OF THE INSTALLATION, USE, OR INABILITY TO USE SUCH PRODUCT, TO THE FULLEST EXTENT THAT ANY SUCH LOSS OR DAMAGE MAY BE DISCLAIMED BY LAW.

THIS WARRANTY SHALL BECOME NULL AND VOID IN THE EVENT OF A VIOLATION OF THE PROVISIONS OF THIS LIMITED WARRANTY.

Appendix B: Technical Support

Asia Pacific, Middle East

Rosslare Security Products Headquarters
905-912 Wing Fat Industrial Bldg,
12 Wang Tai Road,
Kowloon Bay Hong Kong
Tel: +852 2795-5630
Fax: +852 2795-1508
E-mail: support.apac@rosslaresecurity.com

United States and Canada

1600 Hart Court, Suite 103
Southlake, TX, USA 76092
Toll Free: +1-866-632-1101
Local: +1-817-305-0006
Fax: +1-817-305-0069
E-mail: support.na@rosslaresecurity.com

Europe, Africa

Global Technical Support & Training Center
HaMelecha 22
Rosh HaAyin, Israel 48091
Tel: +972 3 938-6838
Fax: +972 3 938-6830
E-mail: support.eu@rosslaresecurity.com

South America

Pringles 868, 1640 Martinez
Buenos Aires
Argentina
Tel: +54 11 4798-0095
Fax: +54 11 4798-2228

Web Site: www.rosslaresecurity.com

ROSSLARE
SECURITY PRODUCTS

WWW.ROSSLARESECURITY.COM



0706-0960094+00