

PowerSeries Neo Alarm Controller

V1.0 Reference Manual



Models:

HS2016/HS2032/HS2064/HS2128

WARNING: This manual contains information on limitations regarding product use and function and information on the limitations as to liability of the manufacturer. The entire manual should be carefully read.

Contents

1: Introduction	1	Factory Defaults	12
About the System	1	Alternate Communicator Setup	12
Features	1	Real Time Clock.....	13
Available Models	1	Communication Paths	13
Compatible Devices	2	Communications Options.....	13
2: Installation	3	Communication Attempt Limit	13
Overview of Installation Process	3	Supervision Restore	13
Alarm Controller Installation	3	Remote Firmware Upgrade	13
Mounting the Enclosure.....	3	Local Firmware Upgrade	13
Wiring	3	Testing the System	13
Terminal Descriptions.....	3	Walk Test.....	13
Wire Routing for Power & Non-Power Limited4	4	Viewing the Event Buffer.....	13
Corbus Wiring.....	4	4: System Operation	14
Installing Modules	5	Arming and Disarming	14
Zone Expander	5	Partition vs. Global Keypad	14
Output Expander	5	Labels	14
Wireless Transceiver Module	5	System Label.....	14
Power Supply Wiring.....	5	Zone Labels	14
Keypad Wiring.....	6	Partition Labels	14
Assigning Keypad Zones.....	6	Module Labels.....	14
Audio Verification Module	6	Event Labels	15
Alternate Communicator Wiring	6	Partition Command Output Labels.....	15
Zone Wiring	6	Annunciation	15
PGM Wiring.....	7	Door Chime	15
Bell Wiring.....	7	Temperature Display	15
Telephone Line Wiring	8	Low Temperature Warning.....	15
Smoke Detector Wiring	8	Keypad Function Keys	15
Fire Zone Wiring: 2-wire Smoke Detectors.....	8	Function Key Definitions	15
CO Detector	8	Language Selection	16
Ground Wiring.....	9	[*] Commands	16
Connecting Power.....	9	[*][1] Bypass or Stay/Away/Night Zones	17
3: Configuration	10	[*][2] Trouble Display	17
Basic Configuration Steps	10	[*][3] Alarm Memory Display	18
Using the Keypad	10	[*][4] Door Chime Enable/Disable	19
Special Keys	10	[*][5] Program Access Codes	19
LED Indicators.....	10	[*][6] User Functions	21
Enrollment	10	[*][7] Command Outputs 1-4.....	22
Enrolling Modules	10	[*][8] Installer Programming	22
Module Supervision.....	11	[*][9] No-Entry Arming.....	22
Enroll Wireless Devices.....	11	[*][0] Quick Arm/Exit.....	22
Working with Partitions	11	SMS Command and Control	22
Setting Up a Partition.....	11	SMS Command and Control Functions	22
Bell/Siren Operation	11	Visual Verification	23
Trouble Indicators	12	5: Programming	24
Keypad Partition Setup	12	How to Program	24
Global Zones.....	12	Programming Methods	24
Fire and CO Zone Types.....	12	Template Programming	24
Bell/PGM Support	12		
Communications	12		

Contents

DLS Programming.....	24
Installer Programming	25
Viewing Programming.....	25
Programming Hex and Decimal Data.....	25

Programming Descriptions.....26

Adding Labels.....	26
Zone Setup.....	27
System Times.....	30
Access Codes.....	30
PGM Configuration	31
PGM Types	31
System Options.....	37
Partition Setup	42
Reporting	43
System Communications	46
DLS Programming.....	50
Schedule Programming.....	52
Wireless Programming.....	52
Systems Information.....	53
Module Programming.....	53
Testing.....	54
Defaults.....	54

6: Programming Worksheets 55

7: Troubleshooting..... 93

Testing.....93

Troubleshooting.....93

Appendix A : Event Codes 98

Appendix B : Word Library 104

Appendix C : Template Programming Tables 105

Appendix D : Regulatory Approvals 110

UL/ULC Installations 111

SIA False Alarm Reduction Installations: Quick
Reference 113

Appendix E : ASCII Characters. . . . 114

Appendix F : Wiring Diagrams 115

Appendix G : Specifications 119

Appendix H : Index 122

Before Installing The Equipment

Ensure your package includes the following items:

- **Installation and User manuals, including the SAFETY INSTRUCTIONS.**

READ and SAVE these instructions!

Follow all WARNINGS AND INSTRUCTIONS specified within this document and/or on the equipment.

- **HS2016/2032/2064/2128 alarm controller**
- **Power Supply, direct plug-in**
- **Mounting hardware**

Safety Instructions for Service Personnel

Warning: When using equipment connected to the telephone network, always follow the basic safety instructions provided with this product. Save these instructions for future reference. Inform the end-user of the safety precautions that must be observed when operating this equipment.

Selecting A Suitable Location For The Alarm Controller

Use the following list as a guide to find a suitable location to install this equipment:

- Locate near a telephone socket and power outlet.
- Select a location free from vibration and shock.
- Place alarm controller on a flat, stable surface and follow the installation instructions.
Do NOT locate this product where people may walk on the secondary circuit cable(s).
Do NOT connect alarm controller to electrical the same circuit as large appliances.
Do NOT select a location that exposes your alarm controller to direct sunlight, excessive heat, moisture, vapors, chemicals or dust.
Do not install this equipment near water. (e.g., bath tub, kitchen/laundry sink, wet basement, near a swimming pool).
Do NOT install this equipment and accessories in areas where risk of explosion exists.
Do NOT connect this equipment to electrical outlets controlled by wall switches or automatic timers.
AVOID interference sources.
AVOID installing equipment near heaters, air conditioners, ventilators, and refrigerators.
AVOID locating equipment close to or on top of large metal objects (e.g., wall studs).
- See page 120 for information on locating smoke and CO detectors.

SAFETY Precautions Required During Installation

- **NEVER** install this equipment and/or telephone wiring during a lightning storm.
- **NEVER** touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.
- Position cables so that accidents can not occur. Connected cables must NOT be subject to excessive mechanical strain.
- Use only the power supply provided with this equipment. Use of unauthorized power supplies may cause damage.
- For direct plug-in versions, use the transformer supplied with the device.

WARNING:

THIS EQUIPMENT HAS NO MAINS ON/OFF SWITCH. THE PLUG OF THE DIRECT PLUG-IN POWER SUPPLY IS INTENDED TO SERVE AS THE DISCONNECTING DEVICE IF THE EQUIPMENT MUST BE QUICKLY DISCONNECTED. IT IS IMPERATIVE THAT ACCESS TO THE MAINS PLUG AND ASSOCIATED MAINS SOCKET/OUTLET IS NEVER OBSTRUCTED.

IMPORTANT NOTE!

This alarm system must be installed and used within an environment that provides the pollution degree max 2 and over-voltages category II NON-HAZARDOUS LOCATIONS, indoor only. The equipment is DIRECT PLUG-IN (external transformer) and is designed to be installed, serviced and/or repaired by service persons only; [service person is defined as a person having the appropriate technical training and experience necessary to be aware of hazards to which that person may be exposed in performing a task and of measures to minimize the risks to that person or other persons]. There are no parts replaceable by the end-user within this equipment. The wiring (cables) used for installation of the alarm system and accessories, shall be insulated with PVC, TFE, PTFE, FEP, Neoprene or Polyamide.

- (a) The equipment enclosure must be secured to the building structure before operation.
- (b) Internal wiring must be routed in a manner that prevents:
 - Excessive strain or loosening of wire on terminal connections;
 - Damage of conductor insulation
- (c) Disposal of used batteries must be made in accordance with local waste recovery and recycling regulations.
- (d) Before servicing, DISCONNECT the power and telephone connection.
- (e) DO NOT route any wiring over circuit boards.
- (f) The installer is responsible to ensure that a readily accessible disconnect device is incorporated in the building for permanently connected installations.

The power supply must be Class II, FAIL SAFE with double or reinforced insulation between the PRIMARY and SECONDARY CIRCUIT/ ENCLOSURE and be an approved type acceptable to the local authorities. All national wiring rules must be observed.

Section 1: Introduction

1.1 About the System

The PowerSeries Neo alarm panel is a feature-rich, scalable alarm system designed for residential and light commercial use. The alarm panel supports both hardwired and wireless devices. This section lists the features of the alarm panel, available models, and compatible devices.

1.1.1 Features

The following features are available on the PowerSeries Neo alarm controller.

Zones

- 16, 32, 64, or 128 wireless zones supported and 8 hardwired zones available on the controller
- 40 zone types and 14 programmable zone attributes
- Up to 16 separate wireless keypads supported
- Up to 32 separate wireless keys or panic pendants supported
- Up to 95 separate proximity tags supported

Access Codes

- Up to 98 access codes: one system master code, one installer code, and one maintenance code
- Programmable attributes for each user code (see page 20)

Programmable Outputs (PGMs)

- Up to 4 programmable outputs (PGM) on the alarm controller with 41 available options
- 148, 80, 38, 22 maximum programmable outputs

System Supervision Features

- The PowerSeries Neo continuously monitors a number of possible trouble conditions and provides audible and visual indication at the keypad. Trouble conditions include:
 - AC power failure
 - Zone trouble
 - Fire trouble
 - Telephone line trouble
 - Communicator trouble
 - Low battery condition
 - RF jam
 - AUX power supply fault
 - Failure to communicate
 - Module fault (supervisory or tamper)

Additional Features

- 2-way wireless device support
- Visual verification (images + audio)*
- Proximity tag support
- PGM scheduling
- Quick arming
- User, partition, module, zone and system labels
- Programmable system loop response
- Keypad and panel software versions viewable through keypad
- Doorbell zone type
- Low battery PGM type

1.1.2 Available Models

The following alarm controller models are available:

- HS2016
- HS2032
- HS2064
- HS2128

Model Differences

The table below lists the features of each alarm system model.

Table 1-1 Model Differences

Features	HS2128	HS2064	HS2032	HS2016
Hardwired zones	128	64	32	16
Onboard zone inputs	8	8	8	6
Wireless zones	128	64	32	16
Partitions	8	8	4	2
Users	95	95	72	48
Onboard outputs	4	4	2	2
Max outputs	148	80	38	22
Keypads	16	8	8	8
Wireless keys	32	32	32	16
Wireless sirens	16	8	8	4
Wireless repeaters *	8	8	8	4
Proximity tags	94	94	71	47
Alt Comm. phone #'s	4	4	4	4
User-programmable phone #'s	8	8	8	8
Lifesafety event buffer	1000	500	500	500
8-zone expander HSM2108	15	7	3	1
Power supply HSM2300	4	3	3	3
Power supply/high-current output expander HSM2204	4	3	1	1
8-output expander HSM2208	16	8	4	2
2-way wireless integration module	1	1	1	1
Audio verification PC5950	1	1	1	1

*For UL installations, 2 repeaters must be installed for proper signal routing.

1.1.3 Compatible Devices

The following wireless devices and modules are compatible with this alarm controller.

NOTE: On the chart below and throughout this document, x in the model number represents the operating frequency of the device as follows: 9 (912-919 MHz), 8 (868MHz), 4 (433MHz).

NOTE: Only models operating in the band 912-919 MHz are UL/ULC listed where indicated. Only ^{UL} approved devices are to be used with UL/ULC listed systems.

Table 1-2 Compatible Devices

Modules	
Wireless keypads	HS2LCDWFx HS2LCDWFPx HS2LCDWFPVx
Hardwired keypads with 2-way wireless integration module	HS2LCDRFx ^{UL} HS2LCDRFPx ^{UL} HS2ICNRFx ^{UL} HS2ICNRFpx ^{UL}
Hardwired keypads	HS2LCD ^{UL} HS2LCDP ^{UL} HS2ICN ^{UL} HS2ICNP ^{UL} HS2LED ^{UL}
2-way wireless integration module	HSM2HOSTx ^{UL}
8-zone expander	HSM2108 ^{UL}
8-output expander	HSM2208 ^{UL}
Power supply	HSM2300 ^{UL}
4 high current output expander	HSM2204 ^{UL}
Alternate communicator	3G2080 ^{UL} 3G2080R ^{UL} TL280 ^{UL} TL280R ^{UL} TL2803G ^{UL} TL2803GR ^{UL} PCL-422 ^{UL}
Hardwired Devices	
2-wire smoke detector x= A, B, or C A: ULC listed models B: UL listed models C: European and Australian models	FSA-210x ^{UL} FSA-210xT ^{UL} FSA-210xS ^{UL} FSA-210xST ^{UL} FSA-210xLST ^{UL} FSA-210xR ^{UL} FSA-210xRT ^{UL} FSA-210xRS ^{UL} FSA-210xRST ^{UL} FSA-210xLRST ^{UL}
4-wire smoke detector x= A, B, or C A: ULC listed models B: UL listed models C: European and Australian models	FSA-410x ^{UL} FSA-410xT ^{UL} FSA-410xS ^{UL} FSA-410xST ^{UL} FSA-410xLST ^{UL} FSA-410xR ^{UL} FSA-410xRT ^{UL} FSA-410xRS ^{UL} FSA-410xRST ^{UL} FSA-410xLRST ^{UL}

CO detector	CO-12/24 ^{UL} 12-24SIR ^{UL} FW-CO12 ^{UL} FW-CO1224 ^{UL} CO1224 ^{UL}
Wireless Devices	
Wireless PG smoke detector	PGx926 ^{UL}
Wireless PG smoke and heat detector	PGx916 ^{UL}
Wireless PG CO detector	PGx913 ^{UL}
Wireless PG PIR motion detector	PGx904(P) ^{UL}
Wireless PG PIR + camera motion detector	PGx934(P) ^{UL}
Wireless PG curtain motion detector	PGx924 ^{UL}
Wireless PG dual tech motion detector	PGx984(P)
Wireless PG mirror motion detector	PGx974(P) ^{UL}
Wireless PG outdoor motion detector	PGx994 ^{UL}
Wireless PG glass break detector	PGx912
Wireless PG shock detector	PGx935 ^{UL}
Wireless PG flood detector	PGx985 ^{UL}
Wireless PG temperature detector (indoor use)	PGx905 ^{UL}
Outdoor temperature probe (requires PGx905)	PGTEMP-PROBE
Wireless PG key	PGx939 ^{UL}
Wireless PG key	PGx929 ^{UL}
Wireless PG panic key	PGx938 ^{UL}
Wireless PG 2-button key	PGx949 ^{UL}
Wireless PG indoor siren	PGx901 ^{UL}
Wireless PG outdoor siren	PGx911 ^{UL}
Wireless PG repeater	PGx920 ^{UL}
Wireless PG door/window contact	PGx975 ^{UL}
Wireless PG door/window contact w/ AUX	PGx945 ^{UL}
Central Station Receivers	
SG-System I, II, III, IV, 5	
Enclosures	
The HS2128/HS2064/HS2032/HS2016 main board can be installed in the metal enclosures listed below: Tamper protection switches can be installed on all enclosures, including door opening protection and/or removal from the mounting position. Doors can be secured using screws or keylock. • Model PC5003C (removable door) made of 22Ga steel, painted, dimensions: 248mm(L) x 298mm(W) x 76mm(H), weight: 4.5Kg (with PCB, battery and transformer included)	

Section 2: Installation

2.1 Overview of Installation Process

The steps below are provided to assist with the installation of the alarm system. Read over this section briefly to get an overall understanding of the order of installation. Working from this plan can help reduce problems and reduce the overall time required for installation.

Step 1 – Create a Layout

Draw a rough sketch of the site and include all alarm detection devices, zone expanders, keypads and other required modules.

Step 2 – Mount the Panel

Decide on a location for the alarm panel and secure it to the wall using suitable mounting hardware. See 2.2.1 Mounting the Enclosure on page 3.

Step 3 – Wire the Alarm Controller

Wire each of the modules to the alarm controller following the guidelines provided in section 2.3.3 Corbus Wiring on page 4.

Step 4 – Wire Zones

Complete all zone wiring. Follow the guidelines provided in section 2.4.8 Zone Wiring on page 6 to connect zones using normally closed loops, single EOL resistor, double EOL resistors, fire zones and key-switch arming zones.

Step 5 – Complete Wiring

Complete all other wiring including bells or sirens, telephone line connections, ground connections or any other wiring necessary. Follow the guidelines provided in section 2.3.1 Terminal Descriptions on page 3.

Step 6 – Power up the Control Panel

Once all zone and alarm controller wiring is complete, connect the battery and power up the system. The alarm controller will not power up if only the battery is connected.

Step 7 – Enroll Keypads and Modules

All keypads must be enrolled in order to operate on the system. To enroll the first keypad, see page 11. To enroll optional keypads, see page 52.

Step 8 – Confirm Module Supervision

By default, all modules are supervised upon installation. Supervision is enabled at all times. To confirm that each module is properly supervised, see [903] Confirm Module on page 54.

Step 9 – Enroll Wireless Devices

Wireless devices are enrolled via the wireless transceiver module (HSM2HOSTx) or RF keypad and Installer Programming section [804]. See [804] Wireless Programming on page 52 to enroll wireless devices.

Step 10 – Program the System

Section 5 on page 24 provides a complete description of how to program the alarm controller. It contains complete descriptions of the various programmable features and options. Fill out the programming worksheets starting on page 57 completely before attempting to program the system.

Step 11 – Test the System

Test the panel completely to ensure that all features and functions operate as programmed.

2.2 Alarm Controller Installation

Begin the installation by mounting the alarm controller in the metal enclosure using the stand-offs provided. Optional modules, such as the HSM2108 and HSM2208, can also be mounted in the enclosure. Install hardware in the sequence indicated on the following pages.

2.2.1 Mounting the Enclosure

Locate the panel in a dry area, preferably near an unswitched AC power source and the incoming telephone line. Complete all wiring before applying AC or connecting the battery.

2.3 Wiring

All wiring entry points on the enclosure are designated by arrows. All circuits are classified UL power limited except for the battery leads. Minimum 1/4" (6.4mm) separation must be maintained at all points between power limited and non-power limited wiring and connections.

2.3.1 Terminal Descriptions

The following terminals are available on the PowerSeries Neo alarm controller.


Terminal	Description
AC	Power terminals. Connect the battery before connecting the AC. Do not connect the battery or transformer until all other wiring is complete.
BAT+, BAT-	Battery terminals. Use to provide backup power and additional current when system demands exceed the power output of the transformer, such as when the system is in alarm. Do not connect the battery until all other wiring is complete.
AUX+, AUX-	Auxiliary terminals. Use to power modules, detectors, relays, LEDs, etc. (700mA MAX). Connect the positive side of device to AUX+, the negative side to AUX-.
BELL+, BELL-	Bell/Siren power. Connect the positive side of any alarm warning device to BELL+, the negative side to BELL-.
RED, BLK, YEL, GRN	Corbus terminals. Use to provide communication between the alarm controller and connected modules. Each module has four Corbus terminals that must be connected to the Corbus.
PGM1 to PGM4	Programmable output terminals. Use to activate devices such as LEDs. (PGM1, PGM3, and PGM4: 50mA PGM2: 300mA or can be configured as an input)
Z1 to Z8 COM	Zone input terminals. Ideally, each zone should have one detection device; however, multiple detection devices can be wired to the same zone.
TIP, RING, T-1, R-1	Telephone line terminals.
EGND	Earth ground connection.
PCLINK_1	DLS/SA
PCLINK_2	DLS/SA, Alternate Communicator

2.3.2 Wire Routing for Power & Non-Power Limited

All wiring entry points are designated on the diagram by arrows. All circuits are classified UL installation power limited except for the battery leads which are not power limited.

A minimum 1/4" (6.4mm) separation must be maintained at all points between power limited and non-power limited wiring and connections. See page 115 for expanded diagrams.

Diagram 2-1: Wiring Routing



NOTE: Wire entry for power limited wiring must be separated by a different entry access from non-power limited wiring.

2.3.3 Corbus Wiring

The RED and BLK Corbus terminals are used to provide power while YEL and GRN are used for data communications. The 4 Corbus terminals of the alarm controller must be connected to the 4 Corbus terminals or wires of each module.

The following conditions apply:


- Corbus should be run with minimum 22 gauge quad. two pair twisted preferred.
- The modules can be home run to the panel, connected in series or can be T-tapped.

NOTE: Any module can be connected anywhere along the Corbus. Separate wire runs for keypads, zone expanders etc. are not necessary.

NOTE: No module can be more than 1,000/305m (in wire length) from the panel. Do not use shielded wire for Corbus wiring.

Diagram 2-2: Corbus Wiring

Module (A) is wired correctly as it is within 1,000/305m of the panel, in wire distance. Module (B) is wired correctly as it is within 1,000/305m of the panel, in wire distance. Module (C) is NOT wired correctly as it is farther than 1,000/305m from the panel.



Current Ratings

In order for the system to operate properly, the power output of the alarm controller and power supply modules cannot be exceeded. Use the data below to ensure that the available current is not exceeded.

Table 2-1: System Output Ratings

Device	Output	Rating (12V _{DC})
HS2016 HS2032 HS2064 HS2128	AUX:	700mA. Subtract the listed rating for each keypad, expansion module and accessory connected to AUX or Corbus. At least 100mA must be reserved for the Corbus.
	BELL:	700mA. continuous rating. 2.0A. short term. Available only with standby battery connected. Not for UL/ULC or EN certified applications
HSM2208	AUX:	250mA. Continuous rating. Subtract for each device connected. Subtract the total load on this terminal from the alarm panel AUX/Corbus output.
HSM2108	AUX:	100mA. Subtract for each device connected. Subtract the total load on this terminal from the panel AUX/Corbus output.

Alarm Controller Current Calculation Maximum (Standby or Alarm)

AUX (700mA max. including PGMs 1-4)	<input type="text"/>
Corbus (700mA max.)***	<input type="text"/>
PCLink+ (Alt. Com.: 125mA)	<input type="text"/>
Total (must not exceed 700mA)	<input type="text"/>

***See Corbus Current Calculation Chart.

For UL, ULC and Commercial Listed applications, the total standby and alarm current cannot exceed 700mA.

Table 2-2: Corbus Current Calculation Chart

Item	Current (mA)	x	Quantity	Total (mA)
HS2LCD	100	x		
HS2ICN	100	x		
HS2LED	100	x		
HS2LCDP	100	x		
HS2ICNP	100	x		
HS2LCDRF	100	x		
HS2ICNRF	100	x		
HS2ICNRFP	100	x		
Current required for connected devices =				
HSM2108*	30	x		
HSM2208*	40	x		
HSM2300/2204*	35	x		
HSM2HOSTx	35	x		
3G2080(R)/ TL2803G(R)/ TL280(R)	125 (PCLINK)	x		
Total Corbus Current =				

*These units draw current from the Corbus to power devices external to the module. This current must be added to the total Corbus current. See manufacturer's specifications for the current draw of each device.

Line Loss

Voltage loss through wire resistance must be considered for all installations. To ensure proper operation, at least 12.5VDC must be applied to all modules on the system (when AC is connected and the battery is fully charged). If less than 12.5VDC is applied, system operation is adversely affected.

To correct the problem, try any or all of the following:

1. Connect an HSM2300/2204 power supply between the alarm controller and the module to provide power to the Corbus.
2. Reduce the length of the Corbus run to the module.
3. Increase the gauge of wire.

Capacitance Limits

An increase in capacitance on the Corbus affects data transmission and causes the system to slow down. Capacitance increases for every foot of wire added to the Corbus. The capacitance rating of the wire used will determine the maximum length of the Corbus.

For example, 22-gauge, non-shielded, 4-conductor wire has a typical capacitance rating of 20 picofarads per foot (which is 20nF/1000'). For every 1000' of wire added – regardless of where it is run – the capacitance of the Corbus increases by 20nF.

The following chart indicates the total wire distance allowed for the capacitance rating of the wire used:

Table 2-3: Wire Capacitance

Wire Capacitance per 1000' (300m)	Total Corbus Wire Length
15nF	5300'/1616m
20nF	4000'/1220m
25nF	3200'/976m
30nF	2666'/810m
35nF	2280'/693m
40nF	2000'/608m


2.4 Installing Modules

Remove all power from the system while connecting modules to the alarm controller.

2.4.1 Zone Expander

The main alarm controller has connection terminals for zones 1 to 8. Additional HSM2108 zone expanders may be added to increase the number of zones on the system. Each zone expander consists of one group of 8 zones. At enrollment, the zone expander is automatically assigned to the next available zone slot. Connect the RED, BLK, YEL and GRN terminals to the Corbus terminals on the alarm panel. Board current draw: 30mA.

Diagram 2-3: HSM2108 Zone Expander




Refer to the HSM2108 installation sheet for more information.

2.4.2 Output Expander

The HSM2208 module is used to add up to 8 low-current programmable outputs to the alarm system.

The 4-wire Corbus connection is used by the panel to communicate with the module. Connect the RED, BLK, YEL and GRN terminals to the Corbus terminals on the alarm panel. Board current draw: 40mA.

Diagram 2-4: HSM2208 Output Expander




2.4.3 Wireless Transceiver Module

The HSM2HOSTx 2-way wireless integration module provides communication between wireless devices and the alarm controller.

Connect the HSM2HOSTx to the 4-wire Corbus of the alarm controller according to the diagram below.

Diagram 2-5: HSM2HOSTx Wiring Diagram




After you have completed the wiring, reconnect power to the security system. Board current draw: 35mA

2.4.4 Power Supply Wiring

The HSM2300/2204 power supply/high-current output module provides up to 1.0A of additional current and can be used to add up to four programmable outputs (HSM2204 only) to the alarm system.

The 4-wire Corbus connection provides communication between the module and alarm panel. Connect the RED, BLK, YEL & GRN terminals to the RED, BLK, YEL & GRN Corbus terminals on the alarm controller. If O1 is not used, connect to Aux with a 1K resistor. Board current draw: 1.2A.

Diagram 2-6: Power Supply Wiring



* Red, Blk, 12 Vdc @ 20mA

** Refer to the Specifications Chart above for the maximum current draw.

2.4.5 Keypad Wiring

To wire a keypad to the alarm controller, remove the keypad back-plate (refer to the keypad installation sheet) and connect the R, B, Y, and G terminals to the corresponding terminals on the alarm controller.

Keypad Zone/PGM Wiring


Hardwired devices can be connected to hardwired keypads with inputs (zone) or outputs (PGM). This saves from running wires back to the control panel for every device.

To connect a zone device to HS2LCD, HS2ICON and HS2LED keypads, run one wire to the P/Z terminal and the other to B. For powered devices, use red and black to supply power to the device. Run the red wire to the R (positive) terminal and the black wire to the B (negative) terminal.

Keypad zones support Normally Closed Loops, Single End of Line and Double End of Line.

To connect the PGM output, run one wire to the P terminal and the other to R.

Diagram 2-7: Keypad P/Z Terminals



NOTE: When using end of line supervision, connect the zone according to one of the configurations outlined in Section 2.4.8.. End of line resistors must be placed on the device end of the loop, not at the keypad.

Assigning Keypad Zones

When using keypad zone inputs, each input used must be assigned a zone number in Installer Programming.

First, ensure that you have enrolled all installed keypads into the desired slots (See “[902] Add/Remove Modules” on page 53). Next, assign keypad zones by entering programming section [861]-[876], subsection 011 for keypads 1-16. Enter a 3-digit zone number for each of the keypad zones. This number must be programmed into the slot location that the keypad is assigned to.

NOTE: If a keypad zone input is assigned to zone number 1 to 8, the corresponding zone cannot be used on the main control panel.

Once the keypad zones are assigned, you must also program zone definitions and zone attributes. See “[001] Zone Type” on page 27 and [002] Zone Attributes on page 29.


2.4.6 Audio Verification Module

(Non-UL listed systems only)

The PC5950 Universal VOX Audio Verification module provides “talk/listen-in” capability for audio verification of alarms. The module permits the central station to monitor microphones and communicate to occupants through speakers. The following diagram illustrates how to wire the PC5950 to the alarm control panel and listening stations.

Diagram 2-8: PC5950 Wiring Diagram

B Universal Configuration Wiring Diagram (Positive Bell Drive from Panel)



2.4.7 Alternate Communicator Wiring

See Alternate Communicator installation manual.

2.4.8 Zone Wiring

Power down the alarm controller and complete all zone wiring.

Zones can be wired to supervise normally open devices (e.g., smoke detectors) or normally closed devices (e.g., door contacts). The alarm panel can also be programmed for single end-of-line or double end-of-line resistors.

Zone programming is done using the following programming sections:

- [001] selects zone definition
- [013] Opt [1] for normally closed or EOL; Opt [2] for SEOL or DEOL

Observe the following guidelines when wiring zones:

- For UL listed installations use SEOL or DEOL only
- Minimum 22 AWG wire, maximum 18 AWG
- Do not use shielded wire
- Do not exceed 100Ω wire resistance. Refer to the chart below:

Table 2-4: Burglary Zone Wiring Chart

Wire Gauge	Maximum Length to EOL Resistor (ft/meters)
22	3000 / 914
20	4900 / 1493
19	6200 / 1889
18	7800 / 2377


Figures are based on maximum wiring resistance of 100Ω.

Normally Open and Normally Closed

Connect hardwired devices to any Z terminal and any Com terminal. Wire normally closed devices in series and normally open devices in parallel.

NOTE: For UL Installations, do not use normally closed loops.

Diagram 2-9: Normally Closed



The following chart shows zone status under certain conditions for NC Loops:

Table 2-5: NC Loop Status

Loop Resistance	Loop Status
0Ω (shorted wire, loop shorted)	Secure
Infinite (broken wire, loop open)	Violated


Single End-of-Line (SEOL) Resistor

When SEOL resistors are installed at the end of a zone loop, the alarm panel detects if the circuit is secure, open, or shorted. The SEOL resistor must be installed at the end of the loop for proper supervision.

To enable SEOL supervision, program section [013], options [1] and [2] to OFF.

NOTE: This option should be selected if either normally closed or normally open detection devices or contacts are used.

Diagram 2-10: SEOL Wiring



The following chart shows zone status under certain conditions for SEOL:

Table 2-6: SEOL Loop Status

Loop Resistance	Loop Status
0Ω (shorted wire, loop shorted)	Violated
5600Ω (contact closed)	Secure
Infinite (broken wire, loop open)	Violated


Double End of Line (DEOL) Resistors

When double end-of-line (DEOL) resistors are installed at the end of a zone loop, The second resistor enables the panel to determine if the zone is in alarm, tampered or faulted.

NOTE: Any zone programmed for Fire or 24-hr Supervisory must be wired with a SEOL resistor regardless of the type of zone wiring supervision selected for the panel. If you change the zone supervision options from DEOL to SEOL or from NC to DEOL, power the system down completely, then power it back up for correct operation.

To enable DEOL supervision, program section [013], option [1] to OFF and option [2] to ON.

Diagram 2-11: DEOL Wiring



NOTE: If the DEOL supervision option is enabled, all hardwired zones must be wired for DEOL resistors, except for Fire and 24 Hour Supervisory zones. Do not use DEOL resistors for Fire zones or 24 Hour Supervisory zones.

NOTE: Do not wire Fire zones to keypad zone terminals if the DEOL supervision option is selected.

NOTE: This option can only be selected if NC detection devices or contacts are used. Only one NC contact can be connected to each zone.

The following chart shows zone status under certain conditions for DEOL:

Table 2-7: DEOL Loop Status

Loop Resistance	Loop Status
0Ω (shorted wire, loop shorted)	Fault
5600Ω (contact closed)	Secure
Infinite (broken wire, loop open)	Tamper
11200Ω (contact open)	Violated

2.4.9 PGM Wiring

Min/max operating voltages for devices, sensors and modules is 9.5VDC - 14VDC.


PGMs switch to ground when activated from the alarm controller. Connect the positive side of the device to the AUX+ terminal and the negative side to a PGM terminal.

PGM 1, 3, 4 supply up to 50mA; PGM 2 supplies up to 300mA.

A relay is required for current levels greater than 50mA or 300mA. PGM2 can also be used for 2-wire smoke detectors.

NOTE: Use SEOL resistors on Fire zones only.

Diagram 2-12: LED Output With Current Limiting Resistor and Optional Relay Driver Output.



UL Compatibility ID For FSA-210B Series is: FS200

NOTE: For ULC listed installations, use FSA-210A and FSA-410A series.

2.4.10 Bell Wiring

These terminals supply 700mA of current at 10.4 - 12.5VDC for commercial/ residential installations. To comply with NFPA 72 Temporal Three Pattern requirements, section [013] Opt [8] must be ON. Note that steady, pulsed alarms are also supported.

Diagram 2-13: Bell Wiring




The Bell output is supervised and power limited by 2A PTC. If unused, connect a 1000Ω resistor across Bell+ and Bell- to prevent the panel from displaying a trouble. See [*][2] on page 17.

2.4.11 Telephone Line Wiring

Wire the telephone connection terminals (TIP, Ring, T-1, R-1) to an RJ-31x connector as indicated in the following diagram. For connection of multiple devices to the telephone line, wire in the sequence indicated. Use 26 AWG wire minimum for wiring.

Diagram 2-14: Telephone Line Wiring




NOTE: Ensure that all plugs and jacks meet the dimension, tolerance and metallic plating requirements of 47 C.F.R. Part 68, Sub-Part F. For proper operation, no other telephone equipment must be connected between the control panel and the telephone company facilities.

2.4.12 Smoke Detector Wiring

All zones defined as Fire must be wired according to the following diagram:

Diagram 2-15: Smoke Detector Wiring



See “[001] Zone Type” on page 27 for fire zone operation.

NOTE: Smoke detectors must be latching type. To reset a smoke detector, enter [*][7][2].


Table 2-8: Compatible 4-Wire Smoke Detectors

FSA-410B	FSA-410BLST	FSA-410BRST
FSA-410BT	FSA-410BR	FSA-410BLRST
FSA-410BS	FSA-410BRT	
FSA-410BST	FSA-410BRS	
Current ratings for DSC FSA-410 Series: 25mA		

Fire Zone Wiring: 2-wire Smoke Detectors

If PGM 2 is programmed for 2-wire smoke detector connection, the detectors must be wired according to the following diagram:

Diagram 2-16: 2-Wire Smoke Detector Wiring



NOTE: The maximum number of smoke detectors on a 2-wire loop is 18. For more information on Fire zones, see section [001] Zone Type on page 27.

NOTE: Do not combine smoke detector models from different manufacturers on the same circuit. Operation may be impaired. Refer to the smoke detector installation sheet when positioning detectors.

Table 2-9: Compatible 2-Wire Smoke Detectors

FSA-210B	FSA-210BLST	FSA-210BRST
FSA-210BT	FSA-210BR	FSA-210BLRST
FSA-210BS	FSA-210BRT	
FSA-210BST	FSA-210BRS	
Current ratings for DSC FSA-210B series: 35mA		

Table 2-10: 2-Wire Smoke Detector Initiating Circuit

Item	Specification
Style/Class, Supervised, Power Limited	Style B (Class B)
Compatibility Identifier	HS2-1
DC Output Voltage	9.7-13.8 VDC
Detector Load	2mA (MAX)
Single End of Line Resistor (SEOL)	2200Ω
Loop Resistance	24Ω (MAX)
Standby Impedance	3000Ω (NOM)
Alarm Impedance	1200Ω (MAX)
Alarm Current	86mA (MAX)

2.4.13 CO Detector

The following hardwired CO detector models can be used with PowerSeries Neo alarm controllers:

- Potter Model CO-12/24, UL File E321434
- Quantum Model 12-24SIR, UL File E186246
- NAPCO Model FW-CO12 or FW-CO1224, UL File E306780
- System Sensor Model CO1224, UL File E307195

NOTE: For multiple unit connections, the leads between CO detectors must be broken. The power supervision relay must be powered from the last detector in the loop.


Wireless CO detectors are also available. When installing wireless CO detectors, use only model PG9913^{UL}, PG8913, PG4913. An HSM2HOSTx (x=9^{UL}/8/4) wireless receiver or HS2LCDRF(P)x/HS2ICNRF(P)x (x=9^{UL}/8/4) wireless keypad are required when installing wireless CO detectors. For more details on these wireless devices, refer to their respective installation manuals.

NOTE: Use only ^{UL} approved devices with UL/ULC listed systems.

Table 2-11: CO Detector Ratings

Device	Description	Max Rating @12VDC
CO-12/24	Potter model CO detector	40mA
12-24SIR	Quantum model CO detector	75mA
FW-CO12	NAPCO model CO detector	90mA
FW-CO1224		

Diagram 2-17: CO Detector Wiring




2.4.14 Ground Wiring

NOTE: Using an insulated green wire (minimum 22AWG), connect the EGND terminal on the Corbus and the grounding wire from the building electrical installation to any of the available holes on the back or side of the metal cabinet. See the diagram attached to the cabinet for suggested GND point location and hardware recommendations.

NOTE: Wire and installation hardware not included.

Diagram 2-18: Ground Installation

Tighten nut to break paint and make good connection to the cabinet



2.4.15 Connecting Power

The alarm controller requires a 16.5V, 40VA transformer. While unplugged, connect the transformer to the AC terminals on the controller. The alarm controller can be programmed to accept a power line frequency of either 50Hz AC or 60Hz AC. See programming section [024], option [1].

NOTE: For UL/ULC installations use only 60Hz. For ULC S559 applications, Standex transformer (Model FTC3716) shall be employed for direct-wiring.

AC (UL Listed Installations)

Primary: 120VAC/60Hz./0.33A

Secondary: 16.5VAC/40VA DSC PTD1640U, DSC PTC1640U Class 2 transformer.

NOTE: Use DSC PTD1640 for Canadian installations.

WARNING: Do not connect the battery or transformer until all other wiring is complete.

Batteries

Do not connect the battery until all other wiring is complete.

NOTE: A sealed, rechargeable, lead acid battery or gel type battery is required to meet UL requirements for power standby times.

Connect the RED battery lead to the positive battery terminal and the BLACK battery lead to the negative battery terminal.

The panel can be programmed to charge the battery at 400mA or 700mA. (See “[982] Battery Settings” on page 54).

NOTE: Refer to Aux Loading and Battery Selection on page 112.

Battery Selection Charts

Use the following chart to determine the battery required to support the main panel for either 4 hours or 24 hours in the standby mode. The battery size is measured in amp hours (Ah).

Table 2-12: Standby Battery Guide

Battery Charging Current: 400mA/700mA*		
Battery Size	Standby	
	4Hr	24Hr
4Ahr	700mA	----
7Ahr	700mA	180mA
14Ahr	700mA	470mA

* with high current battery charge option enabled: [982] bit 1.

NOTE: Battery capacity deteriorates with age and the number of charge/discharge cycles. Replace every 3-5 years.

Refer to Appendix D: Regulatory Approvals on page 110 for detailed Aux. loading and battery charging information.

Section 3: Configuration

3.1 Basic Configuration Steps

Once basic installation of the alarm panel is complete, the following general configuration options should be set:

- create partitions, page 11
 - assign keypads to partitions, page 12
 - assign sirens to partitions, page 11
 - create global zones, page 12
 - set up partition account codes, page 12
 - set up partition timers, page 30
- enroll wireless modules and devices, page 10
- assign zone types, page 27, and attributes, page 29
- create zone labels, page 26
- add users, page 19
- set up the alternate communicator if equipped, page 12
- program phone numbers, page 46
- set up call directions for the central monitoring station, page 47
- set up system timers, page 30
- configure reporting codes, page 43
- test the system, page 13

3.2 Using the Keypad

The PowerSeries Neo alarm panel is compatible with several different keypad types (see 1.1.3 Compatible Devices on page 2); However, all keypads have certain basic functionality in common.

3.2.1 Special Keys

Scroll symbols <> on keypads with LCD displays indicate that options can be viewed by pressing the scroll (◀ ▶) keys. These keys can also be used to position the cursor.

The (*) key is similar in function to the “Enter” key on a personal computer. It is generally used to accept the existing programming option. It is also the first key entry for [*] commands and can be used to enter the letters A-F when in Installer Programming mode.

The (#) key is similar in function to the “ESC” (escape) key on a personal computer. It is generally used to exit the current programming section or to return to the previous one.

3.2.2 LED Indicators

Keypads have the following status lights that provide visual indication of basic system status:

- ✓ **Ready:** Panel is ready to be armed.
- 🔒 **Armed:** Panel is armed.
- ⚠ **Trouble:** System trouble. Enter [*][2] to view troubles.
- 🔄 **AC Power:** ON=AC present. OFF=AC absent.

Panel Status LED Operation

The red status LED, located on the alarm controller PCB, indicates the following:

- Power up sequence – flashes rapidly until the end of the power-up sequence.
- Firmware indication – flashes during the firmware upgrade process. If the firmware upgrade fails, the LED flashes rapidly.
- Trouble indication – Flashes when troubles are present. Troubles are indicated according to the following priority:
 - 1 flash - no keypads enrolled
 - 2 flashes - module supervision trouble
 - 3 flashes - bus low voltage

- 4 flashes - battery trouble
- 5 flashes - AC trouble
- 6 flashes - AUX trouble
- 7 flashes - bell trouble
- 8 flashes - TLM trouble

How to Enter Data

Conventions Used In This Manual

Brackets [] indicate numbers or symbols that must be entered on the keypad.

e.g., [*][8][Installer Code][898] requires the following key entries:

[*] [8] [5] [5] [5] [8] [9] [8]

[*] initiates a special command.

[5555] is the default installer code. The default installer code should be changed during initial programming of the system.

[898] indicates the particular programming section being accessed.

Entering Letters Manually

1. In Installer Programming, enter the section requiring text input (usually a system label).
2. Use the arrow keys [<][>] to move the cursor to a blank space or existing character.
3. Press the number key corresponding to the appropriate letter. Each number button accesses three letters and a number. The first press of the number key displays the first letter. The second press displays the second letter, etc.

1 A, B, C, 1	2 D, E, F, 2	3 G, H, I, 3
4 J, K, L, 4	5 M, N, O, 5	6 P, Q, R, 6
7 S, T, U, 7	8 V, W, X, 8	9 Y, Z, 9,0
	0 Space	

4. To select lower case letters press [*]. The Select Options list opens. Scroll to “lower case” and press [*] again to select.
5. When the required letter or number is displayed use the arrow keys [<][>] to scroll to the next letter.
6. When finished, press the [*] key, use the [<][>] keys to scroll to “Save” then press [*].
7. Continue from step 2 until all labels are programmed.

For information on entering hexadecimal data, see Programming Hex and Decimal Data on page 25.

3.3 Enrollment

All optional modules and devices must be enrolled on the system. During enrollment, the electronic serial number (ESN) of each device is identified to the control panel and zones are assigned. A wireless transceiver HSM2HOST or an RF keypad must be enrolled first before wireless devices can be enrolled.

3.3.1 Enrolling Modules

During automatic and manual enrollment, if an attempt is made to enroll more than the maximum number of modules, an error tone sounds and a message is displayed on LCD keypads.

Table 3-1 Module Capacity

Module	HS2016	HS2032	HS2064	HS2128
HSM2108 8 Zone expander	2	3	7	15
HSM2208 8 Output expander	2	4	8	16
Wireless Keypad: HS2LCDRF(P)4 HS2ICNRF(P)4 HS2LCDWF(P)(V)4	8	8	8	16
HSM2300 Power Supply 1A	3	3	3	4
HSM2204 4 High-current Output	1	1	3	4
HSM2HOSTx Transceiver	1	1	1	1
PC5950 Audio Verification (not UL evaluated)	1	1	1	1

Modules can be enrolled automatically or manually using section [902] of Installer programming. For instructions on enrolling modules, see page 53.

To confirm that a module has been successfully enrolled, use Installer Programming section [903]. See page 54 for details.

Enrolling the First Keypad

To enroll a hardwired keypad, connect the keypad to the alarm controller, power up the alarm panel then press any button on the keypad.

To enroll a wireless keypad, first connect the HSM2HOSTx wireless integration module (or RF keypad) to the alarm controller. Next, power up the alarm panel and a wireless keypad. Press any button on the keypad to enroll it on the HSM2HOSTx. The HSM2HOSTx is then enrolled on the alarm panel. To enroll other keypads, see page 53.

3.3.2 Module Supervision

By default, all modules are supervised upon installation. Supervision is enabled at all times so that the panel can indicate a trouble if a module is removed from the system.

To check which modules are currently connected and supervised, see [903] Confirm Module on page 54.

If a module is connected but is not recognized by the system, it may be due to any of the following reasons:

- the module is incorrectly wired to the alarm controller
- the module has exceeded its maximum wire run length
- the module does not have enough power
- the module is not enrolled on the wireless receiver

Removing Modules

Enrolled modules can be deleted from the system via programming section [902]. For instructions, see [902] Add/Remove Modules on page 53.

3.3.3 Enroll Wireless Devices

Wireless devices are enrolled via the wireless transceiver module and Installer Programming section [804][000]. See “Compatible Devices” on page 2. for a list of supported wireless devices.

Wireless devices are enrolled using one of the following methods:

Auto Enrollment

To enroll a wireless device using this method, press and hold the Enroll button on the device for 2-5 seconds until the LED lights then release the button. The alarm panel automatically recognizes the device and the keypad displays a confirmation message. The device ID and next available zone number are displayed. Press [*] to accept or scroll to another available zone number. Batteries must be installed in the wireless device in order to enroll.

Various zone features are programmable depending on the type of device. Refer to page 27 for details.

Pre-Enrollment

Pre-enrollment is a two step process. The first step requires entering each device ID ([804][001]-[716]). Every wireless device has an ID printed on the sticker attached to the device. The format is XXX-YYYY where:

- XXX identifies the type or model of the device
- YYYY is a short encrypted ID used by the system to identify the specific device

Pre-enrollment can be done at a remote location and using DLS/SA. The second step is to press the enrollment button on the device, usually done on location. Installer Programming does not have to be entered at this step. Both steps must be performed in order to complete the enrollment.

3.4 Working with Partitions

A partition is a limited area of the premises that operates independently from the other areas. Partitioning a system can be beneficial if the property has outbuildings that need to be secured independently of a main area or if the home has a separate apartment. Each partition can have its own keypad or a keypad can have access to all partitions (only if all partitions belong to the same owner). User access to partitions is controlled via access codes. A master code can access the entire system and partitions, while a user code is limited to assigned partitions.

Setting up a partition requires configuration of the following:

- create the partition
- define bell/siren operation
- assign keypads
- assign zones
- assign users

3.4.1 Setting Up a Partition

Partitions are added or removed from the system by applying or removing a partition mask via Installer Programming section [200]. The number of available partitions depends on the alarm panel model. See [200] Partition Mask on page 42 for more information.

3.4.2 Bell/Siren Operation

Each partition must have a siren. The system siren connected to the bell output of the alarm controller can be mounted in a central location within hearing range of all partitions. Each partition can also have wireless sirens activated only on the assigned partition. See Wireless Programming on page 52 for details.

Single Siren Output Operation

With a siren shared across all partitions, control over activation/deactivation of the output depends on the partition that initiated the alarm sequence. Only the partition that originated the alarm can deactivate the bell output.

Global zones, such as smoke detectors shared by multiple partitions, can deactivate the siren on all partitions the zone is assigned to.

Bell Timeout

Each partition has a dedicated maximum bell activation time, programmable in minutes, to enable activation or deactivation of the siren according to events occurring on the partition(s). See System Times on page 30 for more information.

Fire Pre-Alerts

Smoke detector zones should be enrolled on all partitions. If a smoke detector zone assigned to only one partition activates, the only way to silence the delayed fire pre-alert is by pressing a key on a keypad assigned to that partition. If the smoke detector zone is assigned to all partitions, pressing a key on any keypad silences the pre-alert.

Multiple Siren Output Operation

When multiple sirens are used in the installation, they can be programmed to sound alarm conditions for all partitions, or for individual partitions by using a partition enable mask. If hardwired sirens are used, this is accomplished via bus power supplies with a supervised high-current output. The output is then programmed as a Fire and Burglary PGM output type.

NOTE: Only the first output of the HSM2204 output module has bell supervision. Some conditions, such as an installer system test, may override the partition assignment and cause all sirens to activate. User system tests only activate the sirens/outputs assigned to that partition.

3.5 Trouble Indicators

Both audible and visual trouble indications are available on all partitions. For more information, see [*][2] Trouble Display on page 17. Programming section [013] option 3 controls whether or not troubles are indicated when the alarm system is armed.

3.6 Keypad Partition Setup

Keypads can be configured to control an individual partition or all partitions. In general, a partition keypad controls the partition it is assigned to. A Global keypad controls all partitions. Global keypads should be placed in common areas of the premises, such as points of entry or reception areas, where the ability to arm and disarm more than one partition at a time is required.

Partition keypads can also be temporarily loaned to other partitions.

To select a keypad operating mode:

1. Enter Installer Programming: [*][8][installer code].
2. Select [861]-[876] to program keypads 1-16.
3. Press [000] for partition assignment.
 - For Global operation, key in 00.
 - To assign a keypad to a partition, key in 01-08 for partition 1-8.
4. Press the [#] key twice to exit programming.
Continue this procedure at each keypad until all have been assigned to the correct partition.

Users are assigned partition access rights via the [*][5] menu.

Loaned Partition Setup

To loan a keypad to another partition:

1. Press and hold [#]. The keypad switches to Global display.
2. Select a partition by pressing digits 1 to 8. The keypad is temporarily loaned to another partition.
If the keypad is inactive for more than 30 seconds, it reverts to its assigned partition.

3.6.1 Global Zones

If a zone is added to more than one partition, it becomes a global zone. A global zone is only armed when all assigned partitions are armed and is disarmed when any assigned partition is disarmed. Global zones behave as follows:

- A global Stay/Away type zone is not activated until all partitions the zone is assigned to are armed in the Away mode. Interiors must be activated on all partitions for the global Stay/Away zone to be active.
- A shared zone bypassed on one partition is bypassed on all partitions the zone is assigned to.
- An entry delay started on a global zone sounds an entry delay on all keypads assigned to partitions the global zone is assigned to.
- A global Delay type zone follows the longest programmed delay time of the partitions it is assigned to.

3.6.2 Fire and CO Zone Types

Fire zones only place the partition they are assigned to into alarm. Other partitions retain their current state.

A fire **reset** only resets partitions they are assigned to.

One or more fire zones may be located on any partition.

On alarm, the fire auto-scroll display appears on all partition keypads and on all global keypads. Fire alarm silence and fire system reset may be done directly on any partition keypad. To silence a fire or CO alarm from a global keypad requires that the global keypad be loaned to one of the partitions the zone is assigned to.

3.6.3 Bell/PGM Support

PGMs must be assigned to one, some or all partitions. See section [009] for partition assignment.

NOTE: Bell PGM type requires supervision and follows arming squawks by partition

3.6.4 Communications

Account codes are assigned to all system and partition events.

For SIA communications, a single account code (programmed in section [310][000]) is used for all events. The partition is identified via Nri1-8. System events use Nri0.

When using communication formats other than SIA, individual account codes can be programmed for each partition. See [310] Account Codes on page 47.

3.6.5 Factory Defaults

Individual modules, as well as the alarm panel itself, can have their programming returned to factory default settings. Hardware is defaulted via the following Installer Programming sections:

- [991] Default Keypads
 - 000 – Default all keypad programming
 - 001-016 – Default keypads 1-8
- [993] Default alternate communicator
- [996] Default wireless receiver
- [999] Default system

See Defaults on page 54 for more information.

Default All labels

Use programming section [000][999]. The following labels are returned to factory default settings:

- Zone Label
- Partition Labels
- Module Labels
- Partition 1-8 Command Output 1 to 4 Labels
- Schedule 1 to 4 Labels
- Event Labels
- User Labels

System and module programming is not affected.

Hardware Reset Main Control Panel

Perform the following to restore the main control panel to default settings:

1. Power down the system.
2. Remove all wires between Zone 1 and PGM 1 on the alarm controller.
3. Connect a short between Zone 1 and PGM.
4. Power up the system (AC only) for 60 seconds.
5. Power down the system and remove the short.
6. Power up the system again. Factory defaults are restored. Hardware default is logged to the event buffer.

3.7 Alternate Communicator Setup

The alternate communicator is an optional wireless communications device that can be used as a backup to the PSTN connection or as a primary means of communication between the alarm panel and the central monitoring station. The alternate communicator communicates via 3G (HSPA) or Ethernet.

The following configuration steps are required to set up the alternate communicator:

- Install the alternate communicator and wire it to the alarm panel (use PCLINK_2 header)
- Enroll the alternate communicator with Connect 24
- Set the communication path: [300]
- Enable the alternate communicator: [382] option 5
- Enable event reporting: [307]/[308]
- Program communication delay timer: [377]
- Program DLS access: [401] option 07

Refer to the 3G2080(R)/ TL2803G(R)/ TL280(R) installation manual for details.

3.7.1 Real Time Clock

This feature synchronizes the alarm panel time and date with that of the alternate communicator, provided real time clock support is available. Time and date are updated at 4:05 PM or when the system time is lost. This feature is enabled/disabled in Installer Programming section [024] option 5.

3.7.2 Communication Paths

The path of communication between the alarm panel and the central station must be established through either the alarm panel's on-board Public Switched Telephone Network (PSTN) connection or through the alternate communicator (cellular or Ethernet) if equipped.

Paths to four receivers can be programmed in Installer Programming section [300] options 001 - 004.

For more information, see [300] Panel/Receiver Communication Paths on page 43.

3.7.3 Communications Options

The following alarm panel options must be programmed when configuring the alternate communicator:

[300] option 02: communication path (see page 43)

[380] option 01: communications enabled/disabled (see page 48)

[382] option 05: enable communicator and all associated options: telephone number, reporting code and call direction (see page 49)

[308][351]-[356] reporting codes (see page 46)

[401] option 7: DLS access (see page 46)

3.7.4 Communication Attempt Limit

If a telephone line monitoring (TLM) trouble is present, the number of PSTN dialing attempts is reduced from the programmed value to 0 attempts. See programming section [380] option 7 – Reduced Dialing Attempts on page 49 for details.

3.7.5 Supervision Restore

If the alarm system experiences a failure to communicate (FTC) with the central monitoring station, it automatically attempts to transmit the event when communications are restored.

3.7.6 Remote Firmware Upgrade

Firmware upgrades are automatically pushed to the alarm panel and modules from connect 24 or DLS. A message is displayed on LCD keypads indicating a firmware upgrade is available. On all keypads, the blue proximity tag bar flashes one second on - one second off. Users authorize the firmware upgrade through [*][6][master code][17].

During the update, a message indicating that a firmware upgrade is in progress is displayed on the LCD keypad. If the firmware update fails, an error message is displayed on LCD keypads.

Firmware updates are performed under the following conditions:

- The system is not armed
- No AC trouble is present
- No low battery trouble is present
- No FTC trouble is present
- Every alarm in memory has been viewed
- No events are being communicated
- An alternate communicator is present

Remote firmware upgrade is possible for the following modules:

- hardwired keypads, including RFK
- wireless transceivers
- alternate communicators

NOTE: For UL listed installations, do not use remote programming unless an installer is on the premises.

3.8 Local Firmware Upgrade

Alarm panel firmware can be upgraded locally via DLS. Firmware upgrade prevention rules are ignored when performing a local firmware upgrade.

To perform a local firmware upgrade:

1. Remove the front cover of the alarm panel and plug the DLS header into the PCLink 2 connector on the alarm controller.
2. Power down and power up the system.

NOTE: The DLS session must be initiated within 10 seconds of power up. Do not attempt to perform a firmware upgrade if low battery trouble is present.

3. Open the Flash Utility within DLS, select the latest firmware file from the Web or browse to a saved flash file on your hard drive. Follow the steps as prompted by the Flash Utility application. A message is displayed when download is complete.
4. Once the firmware update is complete, the system powers up.

3.9 Testing the System

3.9.1 Walk Test

Installer Walk Test

Walk test enables the installer to test the operation of each detector by tripping zones without causing an actual alarm. Enter section [901] to initiate a walk test. When a zone is tripped, all system sirens emit a tone to indicate that the zone is working correctly.

After 15 minutes without zone activity, the walk test terminates automatically. To manually exit walk test mode, enter [901] again.

3.9.2 Viewing the Event Buffer

The event buffer contains logs of events that have occurred on the alarm system beginning with the most recent. The capacity of the event buffer is scalable and can hold 500/1000 events (depending on panel model) before rolling over. The buffer displays events according to their time stamp, beginning with the most recent. The event buffer can be uploaded when it reaches 75% capacity.

NOTE: Each event displays the time and date, a description of the event, the zone label, access code number or any other pertinent information. To view the event buffer, press [*][6][master code][*][*].

Section 4: System Operation

4.1 Arming and Disarming

The following table describes the various arming and disarming methods available.

Table 4-1 Arming/Disarming Methods

Method	Description
Away Arm	for 2 seconds + [Access Code*]
Stay Arm	for 2 seconds + [Access Code*]
Night Arm	+ [Access Code*]
Disarm	[Access Code]
No-Entry Arming	+ [Access Code*]
Quick Arm/Quick Exit	

For detailed arming/disarming instructions, see the PowerSeries Neo User Manual.

4.2 Partition vs. Global Keypad

Keypads can be configured to control an individual partition or all partitions (see Keypad Partition Setup on page 12). Loaning a keypad to another partition does not require an access code; However, no function that requires an access code can be performed on that partition unless the user's code has sufficient permission.

Single Partition Operation

Single partition keypads provide access to alarm functionality for an assigned partition.

Single partition keypads behave as follows:

- Display the armed state of the partition
- Display open zones, if the zone belongs to the partition the keypad is on
- Display bypassed zones and allow zone bypassing or creating bypass groups of zones assigned to the keypad partition
- Display system troubles (system low battery, system component faults/tampers)
- Display alarms in memory that occurred on the partition
- Allow the door chime to be enabled/disabled
- Activate system test (sounds bells/PGMs assigned to the partition)
- Allow label programming (zone, partition and user labels for the partition)
- Control command outputs (those assigned to the partition, or global outputs such as smoke detector reset)
- Display temperature (not evaluated by UL)

Global/Multiple Partition Operation

1. Global keypads display a list of all active partitions or assigned partitions along with their current state. The Global status screen displays the following:
12345678 (RA!N----)
R = Ready
A = Armed
! = Alarm
N = Not Ready
- = Partition not enabled

In the following example, partition 1 is armed, partition 2 is disarmed and ready, partition 3 is disarmed and not ready, partition 4 is in alarm, and partitions 4-8 are not enabled.

```

1 2 3 4 5 6 7 8
A R N ! - - - -
    
```

Global keypads behave as follows:

- Troubles are displayed and sounded on the global keypad. Troubles can be viewed from the global keypad display by pressing the right scroll key then (*). The Troubles menu is displayed. An access code may be required to enter the [*][2] menu depending on system programming.
- Keypad function keys can be programmed for Global Stay Arm, Global Away Arm and Global Disarm.
- Multiple partition arming may be done from a global keypad assigned to the same partitions as the user.

4.3 Labels

Various custom labels can be created to make identification of the alarm system, partitions, zones and modules simpler. Labels are created by inputting text manually, by selecting words from the Word Library or by downloading/uploading using DLS and Connect 24 interactive software. See "[000] Label Programming" on page 26.

4.3.1 System Label

This feature is used to program a custom label for the security system. This label is used in the event buffer when system events occur. The maximum label size is 14 ASCII characters.

See page 27 for programming details.

4.3.2 Zone Labels

Customized labels can be created for each zone on the alarm system. These labels are used on various displays and events to identify the zone. The maximum label size is 14 x 2 ASCII characters.

See page 26 for more details.

4.3.3 Partition Labels

Each partition on the alarm system can have a unique label to identify it. This label is displayed on partition keypads and event messages. The maximum label size is 14 x 2 ASCII characters.

See page 27 for more details.

4.3.4 Module Labels

Labels can be created for the following optional system modules:

- keypads
- 8 zone expander modules
- 8 output expander modules
- wireless transceiver
- power supply
- 4 high-current output module
- alternate communicator module
- siren
- repeater

The maximum label size is 14 ASCII characters.

See page 27 for more details.

4.3.5 Event Labels

Customizable labels can be created for the following events:

- Fire alarm
- Fail to arm
- Alarm when armed
- CO alarm

The maximum label size is 14 ASCII characters. See page 27 for more details.

4.3.6 Partition Command Output Labels

This feature is used to program custom labels for command outputs. These labels are used with output activation events in the event buffer. The maximum label size is 14 x 2 ASCII characters. See page 27 for more details.

4.4 Annunciation

4.4.1 Door Chime

The keypad can be programmed to use one of four different door chime tones for each zone on the system. Chime is active only during the disarm state. Only one door chime option can be enabled for each zone.

- Beeps
- Bing-Bong
- Ding-Dong
- Alarm Tone

Chime is enabled/disabled on a partition using the [*][4] command.

4.4.2 Temperature Display

Indoor and outdoor temperature can be displayed on system keypads if configured in keypad programming section [861]-[876]>[023] option 7, and sections [041]-[042]. Temperature is detected using wireless temperature sensors installed on the system. Refer to Compatible Devices on page 2.

Global keypads only display outdoor temperature.

4.4.3 Low Temperature Warning

Keypads can be configured to detect low ambient temperature.

If the temperature at the keypad drops to $6^{\circ}\text{C} \pm 2^{\circ}\text{C}$ ($43^{\circ}\text{F} \pm 3^{\circ}\text{F}$), the keypad zone goes into alarm. When the temperature rises above $9^{\circ}\text{C} \pm 2^{\circ}\text{C}$ ($48^{\circ}\text{F} \pm 3^{\circ}\text{F}$), the keypad zone is restored.

When this option is enabled, the keypad's zone input functionality is disabled. The keypad's PGM output is not affected.

Refer to section [861]-[876]>[023] option 8 for more information.

NOTE: This feature has not been evaluated by UL/ULC.

4.5 Keypad Function Keys

Keypads have 5 programmable function keys that can be configured to perform one of the following actions:

Table 4-2 Function Key Programming Options

[00] Null Function Key	[17] Arm Interior
[02] Instant Stay Arm	[21]-[24] Command Output 1 to 4
[03] Stay Arm	[29] Bypass Group Recall
[04] Away Arm	[31] Local PGM Activate
[05] [*][9] No-Entry Arm	[32] Bypass Mode
[06] Chime On/Off	[33] Bypass Recall
[07] System Test	[34] User Programming [*][5]
[09] Night Arm	[35] User Functions [*][6]
[12] Global Stay Arm	[37] Time & Date Program
[13] Global Away Arm	[39] Trouble Display [*][2]
[14] Global Disarming	[40] Alarm Memory [*]3
[16] Quick Exit	[61]-[68] Partition 1 to 8 Select

To program a function key:

1. Enter Installer Programming [*][8].
2. Enter section [861] for function key programming.
3. Enter [001] to [005] to select a function key to program.
4. Enter a 2-digit number to assign a function key operation - [00] - [68]. See table above.
5. Continue from step 3 until all function keys are programmed.
6. Press the [#] key twice to exit Installer Programming.

Programmed function keys must be pressed for 2 seconds in order to activate the function.

4.5.1 Function Key Definitions

This section provides detailed descriptions of each programmable function key option.

[00] Null Function Key

This option deactivates the function key. The key does not perform any function when pressed.

[02] Instant Stay Arm

This feature is similar to the Stay Arm function key, except that no acknowledgment beeps are sounded, no exit delay is applied and the system arms immediately.

If no Stay/Away zone types are programmed, the alarm system arms in Away mode.

NOTE: Do not use this function with CP-01 installations.

[03] Stay Arm

Only perimeter zones are armed. Interior zones are bypassed regardless of whether or not delay zones are tripped during the exit delay.

[04] Away Arm

All interior and perimeter zones are armed. This option only works while the system is disarmed.

[05] No-Entry Arm [*][9]

All Delay 1 and Delay 2 zones become instant zones. If a door or window is opened the system goes immediately into alarm. This function is typically used when no occupants are expected to return to the site during the armed period. Activation of this function key requires an access code. This function only works while the system is disarmed.

See [*][9] No-Entry Arming on page 22 for more information.

[06] Chime On/Off

This function turns the door chime on or off and is the equivalent of pressing [*][4]. The alarm system must be disarmed to use this function. If option 7 in section [023] is enabled, this function key requires an access code.

[07] System Test

This function performs a system test when pressed and is the equivalent of entering [*][6][Access Code][4]. The alarm system must be disarmed to use this function. See System Test on page 21 for more information.

[09] Night Arm

All perimeter and interior zones, excluding Night zones, are armed. This key only works while the system is disarmed or armed in Stay mode.

If no Night type zones are programmed, the alarm system arms in Away mode with an audible exit delay. Exit delay is silent and no acknowledgment beeps are sounded.

Arming in this mode activates the Away Arming PGM output.

[12] Global Stay Arm

This function arms all partitions assigned to the user in Stay mode, provided they are ready to arm. If a partition is not ready, the system cannot be armed. An access code is required with this option.

[13] Global Away Arm

This function arms all partitions assigned to the user in Away mode, provided they are ready to arm. If a partition is not ready, the system cannot be armed. An access code is required with this option.

[14] Global Disarming

This function disarms all partitions assigned to the user. An access code is required with this option.

[16] Quick Exit

Pushing this key allows the user to exit the premises without disarming the system. This function is equivalent to entering [*][0] at the keypad while the partition is armed. If quick exit is not enabled on the system, or if the system is disarmed, pressing this key causes an error tone. An access code is not required to use this key. See 3 – Quick Exit on page 38 for more information.

[17] Arm Interior

This key removes or enables automatic bypass on all Stay/Away zones (equivalent to pressing [*][1] while armed).

If Night zones are programmed, the system arms in Night mode. If no Night zones are programmed, the system arms in Away mode. If the system is armed in Stay mode, the resulting armed mode depends on the presence of Night zones. If armed in Night or Away mode, this key switches the system back to Stay mode. Pressing this key does not switch the system from Night to Away.

This key only works while the system is armed and requires an access code entry if section [015] option 4 is disabled.

[21]-[24] Command Output 1 to 4

This function controls command outputs 1-4 and is the equivalent of entering [*][7][X], where X is 1, 3 or 4.

An access code is required to use this function.

Selecting command output 2 is the equivalent of pressing [*][7][2] sensor reset. See 103 – Sensor Reset [*][7][2] on page 34 for more information.

[29] Bypass Group Recall

This function bypasses all zones belonging to the bypass group.

Zones must be saved in the bypass group for this function key to operate. An access code is required to use this feature if section [023] option 4 is enabled.

[31] Local PGM Activate

This function controls a PGM connected to a keypad.

[32] Bypass Mode

This function places the keypad in Zone Bypass mode. Selecting this function is the equivalent of pressing [*][1] while disarmed. If an access code is required for bypassing, the user must enter the access code before using this function. An access code is required if section [023] option 4 is enabled.

[33] Bypass Recall

This function bypasses the same set of zones that were bypassed the last time the partition was armed. This function is equivalent to pressing [999] while in the [*][1] menu. An access code is required to use this feature if section [023] option 4 is enabled.

[34] User Programming

This function is the equivalent of entering [*][5]. An access code is required to use this function. This key only works while the system is disarmed.

[35] User Functions

This function puts the keypad in user programming mode and is the equivalent of entering [*][6]. An access code is required to use this function. If section [023] option 8 is off, only the Master code can access the [*][6] menu.

[37] Time & Date Program

This function places the keypad in date/time programming mode. A valid access code is required.

[39] Trouble Display

This function puts the keypad in trouble display mode and is equivalent to pressing [*][2]. This function only works while the system is disarmed. This function key requires a code if section [023] option 5 is enabled.

[40] Alarm Memory

This function puts the keypad in alarm memory display mode and is equivalent to pressing [*][3]. This function only works while the system is disarmed. This function key requires a code if section [023] option 6 is enabled.

[61]-[68] Partition 1 to 8 Select

This function selects partition 1-8 when the assigned key is pressed. Pressing and holding the key for 2 seconds selects the next partition.

4.6 Language Selection

The keypad can be programmed to display messages and labels in different languages. Perform the following from the Installer Programming menu:

1. Enter installer programming [*][8][installer code]
2. Enter section [000]>[000].
3. Select a language using the scroll buttons or by entering a hotkey:

Table 4-3 Languages

[01] – English	[15] – Greek
[02] – Spanish	[16] – Turkish
[03] – Portuguese	[18] – Croatian
[04] – French	[19] – Hungarian
[05] – Italian	[20] – Romanian
[06] – Dutch	[21] – Russian
[07] – Polish	[22] – Bulgarian
[08] – Czech	[23] – Latvian
[09] – Finish	[24] – Lithuanian
[10] – German	[25] – Ukrainian
[11] – Swedish	[26] – Slovakian
[12] – Norwegian	[27] – Serbian
[13] – Danish	[28] – Estonian
[14] – Hebrew	[29] – Slovenian

4. Press [#] to exit.

4.7 [*] Commands

[*] commands provide convenient access to alarm system features. The following commands are available:

- [*][1] Bypass zones
- [*][2] View troubles
- [*][3] View alarms in memory
- [*][4] Door chime on/off
- [*][5] User programming
- [*][6] User functions
- [*][7] Command output 1-4 on/off
- [*][8] Installer programming mode
- [*][9] No entry arming
- [*][0] Quick arm/Exit

While in a [*] command menu, use the [*] key to select an option and the [#] key to exit to the previous screen. On an LCD keypad, use the scroll keys to view options.

4.7.1 [*][1] Bypass or Stay/Away/Night Zones

The [*][1] command functions differently depending on whether the system is armed or disarmed.

NOTE: For UL/ULC listed installations, group bypass is not allowed.

When The Alarm System is Disarmed

Users can bypass individual zones or a programmed group of zones using the [*][1] keypad command. Zones are commonly bypassed if users want to have access to an area while the partition is armed, or to bypass a defective zone (bad contact, damaged wiring) until service can be provided. A bypassed zone does not cause an alarm.

When the partition is disarmed, all zones that were bypassed using [*][1] are no longer bypassed, except for 24-hr zones.

If the Code Required for Bypass option is enabled, an access code is required to enter bypass mode. Only access codes with the Bypass attribute enabled can bypass zones (see Access Code Attributes on page 20).

Bypassing zones with an LCD keypad:

1. Ensure the system is disarmed.
2. Press [*] to enter the function menu. The keypad displays “Press [*] for <> Zone Bypass.”
3. Press [1] or [*], then key in your access code (if required).
4. Scroll to a zone or key in the three-digit zone number. Only zones enabled for zone bypassing are displayed. Press [*] to bypass the zone.
“B” appears on the display to indicate the zone is bypassed. If a zone is open, “O” appears on the display. When an open zone is bypassed, the “O” is replaced by “B.”
5. To clear a bypassed zone, repeat the above procedure. The “B” disappears from the display indicating that the zone is no longer bypassed.
6. To exit bypass mode and return to the ready state, press [#].

Bypassing zones with a LED/ICON keypad:

1. Ensure the system is disarmed.
2. Press [*][1], then enter your access code (if required).
3. Enter the three-digit number of the zone(s) to be bypassed. The zone light turns on to indicate that the zone is bypassed.
4. To clear a bypassed zone, repeat the above procedure. On LED keypads, the zone light turns off to indicate that the zone is no longer bypassed.
5. To exit bypass mode and return to the ready state, press [#].

NOTE: LED Keypads display the bypass status of zones 1-16 only.

Other Bypass Features:

The following features are also available on the [*][1] zone bypass menu:

Bypass Open Zones

Displays all currently open or bypassed zones. Use the scroll keys to view zones. Open zones are indicated by an (O). To bypass a zone, press [*]. A bypassed zone is indicated by a (B).

NOTE: Zones with tampers or faults must be manually bypassed.

Bypass Group

Displays a programmed group of zones (bypass group) commonly bypassed. Press [*] to bypass all zones in the group.

Program Bypass Group

To program a bypass group, bypass all desired zones then select Bypass Options > Program Bypass Group. The selected zones are saved to the bypass group. When finished, press [#] to exit.

In order to program a bypass group, a master or supervisor code with access to the appropriate partition must be used.

Bypass Recall

Press [*] while in this menu to bypass the same group of zones that were bypassed the last time the partition was armed.

Clear Bypasses

Press [*] to clear all bypasses.

Shortcuts from the [*][1] base menu:

- 991 = bypass group
- 995 = program group 1
- 998 = bypass open zones
- 999 = bypass recall
- 000 = clear group

When The Alarm System is Armed

When the system is armed, pressing [*][1] toggles between stay, away or night arming. If a night zone is on the system, pressing [*][1] either prompts the user for an access code if required, or sounds an acknowledgment tone and changes the arming mode.

NOTE: If section [022], Option 5 [Stay/Away Toggle] is on, the system does not change from Away to Stay mode.

The zone attribute for zone bypassing must be enabled (see section [002] Zone Attributes, Option 04).

Holdup zones should not be part of bypass groups.

A zone that is manually bypassed via [*][1] will bypass the alarm, fault, and tamper conditions when DEOL is used.

If a 24-hour zone is bypassed, ensure that the zone is restored or disabled before removing the bypass.

4.7.2 [*][2] Trouble Display

This feature is used to view system troubles. If a trouble is present, the keypad Trouble indicator illuminates and an audible indication is emitted (two short beeps every 10 seconds, except while in AC failure). Silence the audible indicator by pressing [#].

Troubles may be viewed while the system is armed or disarmed. The system may be programmed to show all troubles while armed or only fire troubles. See section [13] option 3 on page 37 for details.

The system can be configured to require a user code to view [*][2] system troubles. See section [023] option 5.

To view trouble conditions:

- Press [*][2] to enter the Trouble menu.
On an LCD keypad, scroll to a trouble type then press [*] to view the specific trouble. The zone name and trouble condition for each trouble are displayed on the screen.
On LED/ICON keypads, zone indicator lights illuminate to identify existing trouble types (e.g., Zone light 1 represents Service Required trouble type). Press the number key corresponding to a zone light to view the specific trouble. Lights 1-12 illuminate to indicate the trouble as follows:

Table 4-4: Trouble Indications

Trouble 01 – Service Required:	
[01]	Bell Circuit Trouble: The bell circuit is open.
[02]	RF Jam: The HSM2HOSTx has detected an RF Jam condition.
[03]	Aux Supply Trouble: The alarm controller, HSM2204 or HSM2300 has an overcurrent condition on Aux.
[04]	Time and Date: System time and date require programming.
[05]	Output 1 Fault: An HSM2204 module has detected an open condition on output #1.

<p>Trouble 02 – Module Battery Trouble:</p> <p>[01] Panel Low Battery Trouble: The battery voltage (under load) is below 11.5V. Restores at 12.5V.</p> <p>[02] Panel No Battery: No battery connected to alarm controller.</p> <p>[04] HSM2204 01 - 04 Low Battery: An HSM2204 has a battery voltage less than 11.5V.</p> <p>[05] HSM2204 01 - 04 No Battery: No battery connected to HSM2204.</p> <p>[07] HSM2300 01 - 04 Low Battery: An HSM2300 has a battery voltage less than 11.5V</p> <p>[08] HSM2300 01 - 04 No Battery: No battery connected to HSM2300.</p>
<p>Trouble 03 – Bus Voltage:</p> <p>[01] HSM2HOSTx Bus Low Voltage: The HSM2HOSTx module has measured less than 6.3V on its Aux input.</p> <p>[02] Keypad 01 - 16 Bus Low Voltage: A hardwired keypad has a bus voltage of less than 6.9V for ICON/LCD (RF version) and 7.7V for non-RF models.</p> <p>[04] HSM2108 01 - 15 Bus Low Voltage: A zone expander has a bus voltage of less than 5.9V.</p> <p>[05] HSM2300 01 - 04 Bus Low Voltage: A power supply has a bus voltage of less than 6.9V.</p> <p>[06] HSM2204 01 - 04 Bus Low Voltage: A high current output module has a bus voltage of less than 6.9V.</p> <p>[08] HSM2208 01 - 16 Bus Low Voltage: The low current output module has detected a voltage less than 5.9V on its aux input.</p>
<p>Trouble 04 – AC Troubles:</p> <p>[01] Zone 001 - 128 AC Trouble: An AC trouble has been detected on a PGX934 PIR + Camera.</p> <p>[03] Siren 01 - 16 AC: A siren has an AC trouble.</p> <p>[04] Repeater 01 - 08 AC: A wireless repeater has an AC trouble.</p> <p>[05] HSM2300 01 - 04 AC: An HSM2300 has an AC trouble.</p> <p>[06] HSM2204 01 - 04 AC: An HSM2204 has an AC trouble.</p> <p>[07] Panel AC: The alarm controller has an AC failure condition.</p>
<p>Trouble 05 – Device Faults:</p> <p>[01] Zone 001 - 128: A zone is in fault. Additional information displayed on LCD keypads for the following troubles: Fire (2-W Smoke, PGX916, PGX926, PGX936), Heat (PGX946), Freeze (PGX905), CO (PGX913), and Probe Disconnected (PGX905). Also generated by a short on hardwired zones when DEOL is used or by a wireless supervisory fault.</p> <p>[02] Keypad 01 - 16: A wireless or hardwired keypad is in fault.</p> <p>[03] Siren 01 - 16: A siren is in fault.</p> <p>[04] Repeater 01 - 08: A wireless repeater is in fault (supervisory or loss of AC/DC).</p>
<p>Trouble 06 – Device Low Battery:</p> <p>[01] Zone 001- 128: Wireless zone has a low battery.</p> <p>[02] Keypad 01-16: Keypad has a low battery.</p> <p>[03] Siren 01 - 16: Siren has a low battery.</p> <p>[04] Repeater 01 - 08: Repeater has a low battery.</p> <p>[05] User 01 - 95: Wireless Key has a low battery.</p>
<p>Trouble 07 – Device Tamper:</p> <p>[01] Zone 001 - 128 Tamper: A wireless or hardwired zone configured for DEOL operation is in tamper.</p> <p>[02] Keypad 01 - 16 Tamper: A hardwired or wireless keypad is in tamper.</p> <p>[03] Siren 01 - 16 Tamper: A wireless siren is in tamper.</p> <p>[04] Repeater 01 - 08 Tamper: A wireless repeater is in tamper.</p>

<p>Trouble 08 – RF Delinquency Trouble:</p> <p>[01] Zone 001 - 128 RF Delinquency: No response from a wireless zone for 13 minutes. This trouble prevents arming until acknowledged or cleared using [*][2].</p> <p>[02] Keypad 01 - 16 RF Delinquency: No response from a wireless keypad for 13 minutes.</p> <p>[03] Siren 01 - 16 RF Delinquency: No response from a wireless siren for 13 minutes.</p> <p>[04] Repeater 01 - 16 RF Delinquency: No response from a wireless repeater for 13 minutes.</p>
<p>Trouble 09 – Module Supervisory Trouble:</p> <p>[01] HSM2HOSTx not responding.</p> <p>[02] Keypad 01 - 16 not responding.</p> <p>[04] HSM2108 01 - 15 not responding.</p> <p>[05] HSM2300 01 - 04 not responding.</p> <p>[06] HSM2204 01 - 04 not responding.</p> <p>[08] HSM2208 01 - 16 not responding.</p>
<p>Trouble 10 – Module Tamper Trouble:</p> <p>[01] HSM2HOSTx Tamper.</p> <p>[02] Keypad 01 - 16 Tamper.</p> <p>[04] HSM2108 01 - 15 Tamper.</p> <p>[05] HSM2300 01 - 04 Tamper.</p> <p>[06] HSM2204 01 - 04 Tamper.</p> <p>[08] HSM2208 01 - 16 Tamper.</p>
<p>Trouble 11 – Communications:</p> <p>[01] TLM: Telephone line disconnected from control panel.</p> <p>[02] Receiver 01-04 FTC Trouble: Failure to communicate using programmed receiver paths.</p> <p>[03] Alt. Comm SIM Lock: SIM card has incorrect or unrecognized PIN.</p> <p>[04] Alt. Comm Cellular: Radio or SIM card failure, low signal strength detected, or cellular network fault.</p> <p>[05] Alt. Comm Ethernet: Ethernet connection unavailable. A valid IP address is either not programmed or the module was unable to get an IP with DHCP.</p> <p>[06] Receiver 01-04 Absent: Alternate communicator unable to initialize a receiver.</p> <p>[07] Receiver 01-04 Supervision: Alternate communicator unable to communicate with a receiver.</p> <p>[09] Alt. Comm Fault: The alternate communicator has stopped responding.</p> <p>[10] Alt Comm FTC Trouble: The alternate communicator has failed to communicate an internal event not generated by the panel.</p>
<p>Trouble 12 – Not Networked Troubles:</p> <p>[01] Zone 001-128 Not Networked Trouble: Generated when a zone becomes out of sync with the wireless network or has not been synchronized with the network after enrollment.</p> <p>[02] Keypad 01-16 Not Networked Trouble: Generated when a keypad becomes out of sync with the wireless network or has not been synchronized with the network after enrollment.</p> <p>[03] Siren 01-16 Not Networked Trouble: Generated when a siren becomes out of sync with the wireless network or has not been synchronized with the network after enrollment.</p> <p>[04] Repeater 01-08 Not Networked Trouble: Generated when a repeater becomes out of sync with the wireless network or has not been synchronized with the network after enrollment.</p> <p>[05] Wireless Key 01-32 Not Networked Trouble: Generated when a wireless key becomes out of sync with the wireless network or has not been synchronized with the network after enrollment.</p>

4.7.3 [*][3] Alarm Memory Display

The Memory light flashes if an alarm, tamper or fault event occurred during the last armed period or while the panel was disarmed (24 hour zones). Press [*][3] to view zones in alarm memory. To clear the memory, arm and disarm the system. When viewing alarms in memory, LCD keypads indicate the last zone that has gone into alarm first, followed by other alarms in numerical order.

This feature can be programmed to require an access code. See section [023] option 6 for details.

A programmable function key may be configured to display alarms in memory. See “Keypad Function Keys” on page 15 for details.

If configured, alarms in memory must be cleared on 24-hour zones before arming.

4.7.4 [*][4] Door Chime Enable/Disable

When this feature is enabled, the keypad emits a tone whenever a zone programmed as a Chime type is opened or closed. Pressing [*][4] toggles between enabled and disabled. The door chime attribute for each zone is programmed in section [861]-[876], subsections 101-228.

A function key can also be programmed to enable/disable this feature. See “Keypad Function Keys” on page 15 for details. This feature may require an access code. See section [023], option 7 for details.

The following door chime sounds may be selected:

- 6 beeps
- "Bing-Bing"
- "Ding-Dong"
- Alarm tone

4.7.5 [*][5] Program Access Codes

Use this section to perform the following functions:

- press [1] to program user codes 02-95, and master code 01
- press [2] to enroll a proximity tag
- press [3] to enroll/assign a wireless key
- press [4] to add a custom label for each user
- press [5] to assign users to partitions
- press [6] to program user attributes

Assign Access Codes

In order to access alarm system functionality, users must be added to the system. This involves creating a unique access code and assigning attributes to each user. Access codes are programmed via the [*][5] menu.

Access Code Types

The alarm system provides the following access code types:

Code	Add User	Delete User	Arm	Disarm	[*][5]	[*][6]	[*][8]
Installer	No	No	No	No	No	No	Yes
Master	All*	All	Yes	Yes	Yes	Yes	No
Maintenance	No	No	Yes	Yes	No	No	No
User	No	No	Yes	Yes	No	No**	No
Supervisor	All but Master	All but Master	Yes	Yes	Yes	Yes	No
Duress	No	No	Yes	Yes	No	No	No
One-time user	No	No	Yes	1/day	No	No	No

* Can only change master code if section [015] option 6 is off.

** Yes if [023] option 8 is on.

The first two codes in the previous table are system codes. They can be changed but not deleted. The other codes are user-defined and can be added or deleted as necessary. By default, access codes have the same partition and attribute programming as the code used to program them.

Access codes are either 4 or 6 digits in length, depending on the setting of programming section [041]. Duplicate codes are not valid.

Installer Code

This code provides access to Installer Programming [*][8]. The installer code can access all partitions and perform any keypad func-

tion. This code can be programmed by the installer in section [006][003]. The default is 5555 (4-digit) or 555555 (6-digit).

Master Code - Access Code [01]

By default the master code can access all partitions and can perform any keypad function. This code can be used to program all access codes, including the supervisor and duress codes.

If section [015] option 6 is on, the master code can only be changed by the installer via Installer Programming.

The default is 1234 (4-digit) or 123456 (6-digit).

Maintenance Code

The maintenance code can only be used to arm and disarm the system. It cannot bypass zones. Use [*][9] to arm the system, cancel auto-arming, or perform [*][7] command functions. No arm/disarm bell squawks are sounded when the maintenance code is used. The Maintenance code can be programmed by the installer in programming section [006][003]. The default is AAAAAA.

User Codes - Access Codes [02] to [95]

This type of access code is used to arm and disarm assigned partitions and perform other functions as programmed. It can access the [*][6] menu if programming option [023] option 8 is on. This code cannot access the [*][5] and [*][8] menus.

User access codes are created by the master user or supervisor users.

Supervisor Codes - Access Codes [02] to [95]

A supervisor code is a user code with the Supervisor attribute enabled. Users with this attribute can access the [*][5] and [6] user code programming section for the partition they are assigned to. However, these codes can only program codes which have equal or lesser attributes. These attributes are changeable via the [*][5] menu. A supervisor code is created by the master user or other supervisor users.

Duress Codes - Access Codes [02] to [95]

Duress codes function the same as user access codes, except they transmit a duress reporting code when used to perform any function on the system.

Duress codes cannot be used to access [*][5], [*][6] or [*][8] menus.

Duress codes are created by the master user or supervisor users.

NOTE: Section [019] option 6 must be on to select the Duress Codes attribute.

One Time Use Code

A one time use code is a user code with the One Time User attribute enabled. This access code enables the user to arm the alarm system an unlimited number of times. However, a user with this code can only disarm the system once per day. The ability to disarm is reset at midnight or when the one time user code is keyed in by the master code user.

NOTE: One time use code cannot be applied to wireless keys.

One time use codes are created by the master user or supervisor users.

To add an access code using an LCD keypad:

1. Press [*][5][master/supervisor code] to edit access codes 02-95.
2. Use the scroll keys to select a user then press [*] to edit.
3. On the “Press (*) for Access Code” menu, press [*]. The current access code is displayed.
4. Key in the new access code. The code is saved when the last number is keyed in.
To erase an access code, select the user number and enter [*] as the first digit.

A “.” beside a user code indicates it is not programmed. A “P” indicates the code is programmed. A “T” indicates the code is programmed and a proximity tag is enrolled.

On an LED/ICON keypad:

1. Press [*][5][master/supervisor code]
2. Key in a 2-digit user number.

3. Press [1] to select access code.
4. Key in a new access code.

Access Code Attributes

Each user code has 6 attributes that can be toggled on or off.

The default attributes of an access code are the same as the code used to enter [*][5], whether a new code is programmed or an existing one is edited. The available attributes are as follows:

- Supervisor
- Duress code
- Zone bypassing
- Remote access
- Bell squawk
- One time user code

1 – Supervisor

Converts standard user into supervisor user. See Access Code Types on page 19 for details.

2 – Duress Code

Converts standard user code into duress code. See Access Code Types on page 19 for details.

3 – Zone Bypassing

Users with this attribute can bypass zones. Section [023] option 4, Access code required for [*][1], must be on to use this attribute.

4 – Remote Access

Users with this attribute can access the alarm system remotely via SMS.

7 – Bell Squawk

When this option is assigned, the main bell squawks when the alarm system is away armed. For example, use the arm/disarm bell squawk attribute to have wireless key access codes squawk the bell, while other codes are silent. To do this, enable this attribute on all access codes associated with wireless keys. This option is off by default for all access codes.

NOTE: 1 squawk indicates arming completed; two squawks indicates disarming completed.

NOTE: This feature is independent of the system option “Bell Squawk on Away Arming.” See page 39.

The master code cannot use the Bell Squawk attribute, but is required to enable it for other codes.

8 – One Time Use Code 'Maid's Code'

Converts standard user code into one time use code. See Access Code Types on page 19 for details. Do not apply this code to users with wireless keys assigned.

Using an LCD keypad:

1. Press [*][5][master code].
2. Use the scroll keys to choose a user (02-95) then press [*] to select.
3. Scroll to “Press [*] for User Options” then press [*] to select.
4. Scroll to a user attribute and press [*] to toggle it on or off.

Using an LED/ICON keypad:

1. Press [*][5][master code]
2. Key in the 2-digit number of the access code to edit. [5] for attribute programming.
3. Press the keypad number key corresponding to an attribute to toggle it on or off.

Add User Labels

Custom labels can be programmed for each user to more easily identify them on the alarm system. Labels can be a maximum of 16 characters.

Using an LCD keypad:

1. Press [*][5] then select a user (02-95).
2. On the “Press [*] for User Labels” screen, press [*].
3. Key in the custom user label. For instructions on how to input labels, see page 26.

Assigning Proximity Tags

This section is used to assign proximity tags to users.

NOTE: A proximity tag cannot be assigned to the master code.

Using an LCD keypad:

1. In the [*][5] menu, select a user or enter a user number.
2. Select “Press [*] for Prox Tag”, then pass the enrolled tag near the tag reader on the keypad. A proximity tag can only be assigned to one user at a time. Invalid (un-enrolled) proximity tags cannot be used.

To delete a proximity tag, select a user and then select Press [*] for Prox Tag. Press the [*] key when prompted to delete the proximity tag.

Using an LED/ICON keypad:

1. Press [*][5][Master/Supervisor Code].
2. Key in a 2-digit user code.
3. Key in [2].
4. Pass the enrolled tag near the tag reader on the keypad.

To increase authentication flexibility, user access can be achieved by entering a valid user code or by swiping a proximity tag. Alternatively, users can be required to enter a valid access code and present a proximity tag. See [040] User Authentication on page 42.

NOTE: A proximity tag can not be assigned to the Master code. If a user code with a proximity tag is deleted, the proximity tag must be re-enrolled.

Assigning Users to Partitions

Each user code must be assigned to a partition(s) in order for the user to be recognized by the alarm system. By default, each code has the attributes of the code used to program it.

Using an LCD keypad:

1. Press [*][5][master code] then select a user (02-95). An “N” indicates they are not yet assigned to a partition. A “Y” indicates they are assigned to a partition.
2. Scroll to the partition assignment screen then press [*].
3. Use the number keys to assign partitions.
4. Press [#] to exit.

NOTE: The master code has access to all partitions and cannot be modified.

Using an LED/ICON keypad:

1. Press [*][5][Master/Supervisor Code].
2. Key in the 2-digit access code of the user. Key in [4]. A zone light illuminates to indicate which partition the user is currently assigned to. (e.g., if zone light 1 is on, the code is assigned to partition 1).
3. Press the keypad number key corresponding to the appropriate partition (e.g., press 1 to assign the user to partition 1).

User Authentication Options

The alarm panel can be configured to accept one of two user authentication methods:

- 1) User code or proximity tag - the user can access the system by entering a valid code or by presenting a proximity tag.
- 2) User code and proximity tag - the user must enter a valid code and present a proximity tag to access the system. The user code and proximity tag must match. For example, if the tag is associated with user 04, user code 04 must be entered after presenting the tag. Any other user code is treated as invalid.

See [040] User Authentication on page 42.

NOTE: An access code does not have to be programmed in order for a proximity tag or wireless key to be operational.

4.7.6 [*][6] User Functions

The [*][6] command provides access to functions described below. If section [023] option 8 is on, any user code can access this menu. If option 7 is off, only the master code can access this menu.

Event Buffer

Menu: [*][6][master code] > Event Buffer

Keypad: [*][6][master code] > [*]

This option is used to view system events stored in the event buffer.

Events are listed in the order they occurred, starting with the most recent. The time and date are listed for all events. Some events may have a second screen with a description. An asterisk (*) on the first screen indicates that a second screen is available.

If programmed, the event buffer automatically uploads to DLS/SA when it reaches 75% capacity. See section [410] options 3 and 5.

System Test

Menu: [*][6][master code] > System Test

Keypad: [*][6][master code] + 04

Select this option to test the alarm system's bell output, keypad buzzer and lights, communicator and standby battery.

Time and Date

Menu: [*][6][master code] > Time and Date

Keypad: [*][6][master code] + 01

Use this section to program the alarm system clock.

Enter time and date using the following format: (HH:MM); (MM-DD-YY). Valid time entries are 00-23hours, 00-59 minutes. Valid date entries are 1-12 months, 1-31 days.

Other programming options that may effect this user function:
[901]/[902] – Daylight Savings Begin/End on page 30.

Auto-Arm/Disarm

Menu: [*][6][master code] > Auto Arm/Disarm

Keypad: [*][6][master code] + 02

With this feature enabled, the alarm system automatically arms in away mode (stay/away zones active) or disarms at a programmed time each day (see Auto-Arm Time below). The keypad emits three beeps to indicate the system is armed and one long beep to indicate it is disarmed.

All arming inhibit features such as latching tampers, AC inhibit, etc. also inhibit Auto Arming and send the Auto Arm Cancellation code.

Auto-Arm Time

Menu: [*][6][master code] > Auto Arm Time

Keypad: [*][6][master code] + 03

This function is used to program the time of day each alarm system partition automatically arms. To program an auto-arm time, select a day of the week and then key in the time. On LED/ICON keypads, zone lights 1-7 represent Sunday to Saturday. Valid time entries are 00-23 hours: 00-59 minutes.

At the programmed time, the keypad buzzers beep for a programmed duration (for ULC commercial burglary installations minimum duration is 10 minutes) to warn that automatic arming is in progress. The siren also squawks once every 10 seconds during this warning period if programmed to do so. When the warning period is complete, the exit delay elapses then the system arms in away mode.

Auto-arming can be canceled or postponed only by entering a valid access code during the programmed warning period. When a code is entered, the warning is silenced and auto-arming is canceled or postponed, depending on the auto-arm postpone timer. The Auto Arm Cancellation reporting code is transmitted (if programmed).

NOTE: Auto-arming will not silence an active bell.

NOTE: The Auto Arm Cancellation reporting code is also transmitted if arming is inhibited by one of the following:

- AC / DC Inhibit Arm
- Latching System Tampers
- Zone Expander Supervisory Fault

Other programming options that may effect this function:

[151]-[158] Partition Auto-Arm/Disarm on page 42

[014] System Option 2 on page 38

Enable DLS/Allow System Service

Menu: [*][6][master code] > System Serv/DLS

Keypad: [*][6][master code] + 05

This function enables and disables the DLS window for either 1 or 6 hours depending on the programming of section [025] option [7].

NOTE: DLS programming is not UL tested.

Other programming options that may effect this function:

[020] System Option 8, bit [021] System Option 9 on page 40

[025] System Option 13, bit 7 – 1 Hour DLS Window on page 41

User Call-up

Menu: [*][6][master code] > User Call-up

Keypad: [*][6][master code] + 06

When selected, this function makes a single attempt to call the downloading computer. The downloading computer must be waiting for the call before downloading can be performed. Only one call-up is attempted. If a DLS phone number is not programmed, the alarm panel attempts to reach the DLS computer via IP connection. If the communicator is not properly configured for IP, an error tone is sounded.

Late to Open

Menu: [*][6][master code] > Late To Open

Keypad: [*][6][master code] + 09

This function enables or disables the Late to Open option. This option sends a reporting code to the central monitoring station if the partition has not been disarmed by a programmed time.

Other programming options that may effect this function:

[201] Open/Close Events 1, option [211] Miscellaneous Open/Close Events on page 44.

Late to Open Time

Menu: [*][6][master code] > Late To Open Time

Keypad: [*][6][master code] + 10

This function is used to program the time of day the partition must be disarmed by when the Late to Open option is enabled. A separate time can be programmed for each day of the week. Valid data entries are 00:00 - 23:59. 99:99 disables the late to open feature for the selected day.

Select a day of the week by scrolling while in the Late to Open menu, or by using keys 1-7 to select Sunday to Saturday respectively.

SMS Programming

Menu: [*][6][master code] > SMS Programming

Keypad: [*][6][master code] + 11

This function is used to program up to 8 phone numbers for SMS command access and communications. SMS enables users to send commands to the alarm panel via a mobile device.

Leave an SMS phone number blank to disable it. SMS phone numbers are not related to phone numbers used to dial the central monitoring station.

NOTE: If SMS command and control features are disabled (section [382] option 5) then this function is not accessible. See the alternate communicator installation manual for more information.

Brightness Control

Menu: [*][6][master code] > Brightness Control

Keypad: [*][6][master code] + 12

This function is used to change the brightness level of keypad display backlighting. Use the scroll keys to increase and decrease brightness or enter a value from 00 to 15. Selecting 00 turns off keypad backlighting.

Contrast Control

Menu: [*][6][master code] > Contrast

Keypad: [*][6][master code] + 13

This function is used to change the contrast level of keypad displays. Use the scroll keys to increase and decrease contrast or enter a value from 00 to 15. Selecting 00 turns off keypad contrast.

Buzzer Control

Menu: [*][6][master code] > Buzzer Control

Keypad: [*][6][master code] + 14

This function is used to change the volume level of keypad buzzers. Use the scroll keys (LCD keypads) or the [*] key (LED/ICON keypads) to increase and decrease volume or key in a value from 00 to 15. Selecting 00 turns off the keypad buzzer.

NOTE: For UL/ULC listed installations, do not turn off the keypad sounder.

Authorize Firmware Update

Menu: [*][6][master code] > Authorize Update

Keypad: [*][6][master code] + 17

This function is used to give authorization to the system to start the firmware upgrade process after all firmware upgrade files for the keypads, HSM2HOST, control panel and alternate communicator have been fully downloaded.

Once this option is activated, the keypads and system automatically exit [*][6] and indicate that the firmware update is in progress.

4.7.7 [*][7] Command Outputs 1-4

Menu: [*][7][master code if required] > Output Control

Keypad: [*][7][master code if required]

This option is used to activate or deactivate command outputs 1 to 4 for each partition.

Using an LCD keypad:

1. Press [*][7] to enter Output Control mode.
2. Scroll to an output and press [*] to select it, or key in a PGM number. The output is toggled on or off.

Using an LED/ICON keypad:

1. Press [*][7] to enter Output Control mode.
2. Key in a command output number. The output is toggled on or off.

NOTE: If no command outputs are programmed this function is not available. Other programming options that may effect this user function: [009] PGM Types, options 121-124 – Command Outputs 1-4 on page 32.

4.7.8 [*][8] Installer Programming

Use this option to place the alarm system in Installer Programming mode. Installer Programming is used to manually program alarm panel and module options. An installer's code is required to access this function.

Installer Programming is exited automatically after 20 minutes of inactivity.

When viewing data in sections with an LCD keypad, use the [<] and [>] keys to scroll.

Other programming options that may effect this user function:

[990] Installer Lockout Enable/Disable on page 54.

4.7.9 [*][9] No-Entry Arming

This function is used to arm the alarm system while occupants are on the premises. Pressing [*][9] and then keying in an access code arms

the panel without an entry delay on delay type zones and bypasses stay/away and night type zones.

After the exit delay, delay 1 and delay 2 type zones behave the same as instant zones. Stay/away zones remain bypassed. The entry delay can be activated or deactivated at any time while the system is armed using [*][9].

NOTE: If the alarm system is armed using [*][9], disarming is only possible from a keypad inside the premises unless a wireless key is used.

NOTE: Entry of a valid access code is required following this key only when the system is disarmed. When armed, if programming section [015] option 4 (Quick Arming/Function Key) is off, an access code entry is required.

Global delay zones always have an entry delay, even if the system is armed using [*][9].

4.7.10 [*][0] Quick Arm/Exit

This feature operates differently depending on whether or not the alarm system is armed or disarmed.

When disarmed:

Pressing [*][0] arms the alarm system without having to enter an access code. This provides a fast method of arming for regular users and allows users without an access code to arm the system.

NOTE: The Quick Arm feature (section [015] option 4) must be enabled in order for this function to operate as intended.

When armed:

This feature provides a means to exit the premises while the alarm system is armed without having to disarm then rearm it.

Pressing [*][0] starts a 2-minute timer that enables any door programmed as a delay zone to be opened and closed once without triggering an alarm.

If the door is not closed at the end of the exit window, the entry delay sequence begins. Any additional activity on another zone triggers the associated alarm or delay sequence.

4.8 SMS Command and Control

The user can perform certain functions on the alarm panel by remote using SMS text messages. In addition, the system sends SMS messages to the user to confirm commands. SMS programming options are accessed through programming section [851].

The security system only responds to SMS messages sent from designated phone numbers (programmed in section [851]>[311]-[342]).

For more information on SMS command and control, and for a complete listing of communicator programming options, refer to the alternate communicator installation manual.

4.8.1 SMS Command and Control Functions

The following alarm system functions are controllable via SMS:

- Stay arm the system
- Away arm the system
- Night arm the system
- Disarm the system
- Activate/deactivate command output 1-4
- System status request
- Alarm memory request
- Zone bypass
- Zone unbypass

SMS text messages must be formatted as follows:

<function name><space><partition #><space><access code>

e.g., Stay Arm partition 1 1234

Once the command is received and executed by the alarm system, the user receives a confirmation text message.

4.9 Visual Verification

This feature enables the central station operator to view captured images of the premises in the event of an alarm event. Combination camera/motion detectors can be installed throughout the premises to provide visual verification coverage. The microphone on the camera PIR can be disabled.

Visual verification sessions are triggered by the following:

- Fire key
- Medical key
- Panic key

To set up video verification on a partition:

- Enroll the camera PIR; [804]
- Set video verification options; [804]>[841]:
 - [001] Visual Verification Enable/Disable
 - [002] View Time Window
 - [003] View Other Alarms
- Input a custom label to identify the camera PIR; [000]>[001]
- Enable this option on the alternate communicator (section [10] option 2).

Refer to the Camera PIR installation manual for more details.

NOTE: Visual Verification has not been evaluated by UL and shall be disabled for UL certified installations.

Section 5: Programming

5.1 How to Program

This section describes how to view alarm system programming options using the supported keypad types.

5.2 Programming Methods

The alarm system can be programmed using the following methods:

Table 5-1 Programming Methods

Method	Description	Procedure
Template programming	Use pre-defined templates to quickly apply basic programming and to set up DLS downloading.	Press [899] at the “Enter Section” screen. See Template Programming below for details.
DLS programming	Download and apply programming using DLS-V™ (v.1.4 or higher) software.	For local DLS, use a PC-Link cable and laptop with DLS-IV software installed. For remote DLS, use a telephone line, cellular network or the Internet.
Installer programming	Manually program all alarm system and device options.	Press [*][8][installer code] while the system is disarmed.

5.2.1 Template Programming

Template programming allows the installer to quickly program the minimum functions required for basic operation. The installer is prompted to enter a 5-digit code that selects predefined programming configurations:

Digit 1 – zone 1-8 definition options

Digit 2 – system EOL options

Digit 3 – alarm controller communications options

Digit 4 – alarm controller call directions

Digit 5 – DLS connection options

(see Appendix C: Template Programming Tables on page 105 for programming information).

Perform template programming after completing the hardware installation. Ensure you have the information listed below available.

Record this information in the programming worksheets for future reference:

- Monitoring station telephone number - provided by the alarm monitoring service.
- Monitoring station account code - provided by the alarm monitoring service.
- Downloading access code.
- Entry delay - installer defined.
- Exit delay - installer defined.
- Installer code - programmable, unique 4-digit code. The default value is [5555].

To perform template programming:

1. At the “Ready to Arm” screen, enter [*][8][installer code][899].
2. At the “Enter Data” screen, enter [00001] to accept the existing default programming.

Once this section has been entered, the installer cannot exit until all sections are completed. Enter new data and/or press the [#] key to accept the displayed data and proceed to the next section. Changing a single digit, then pressing the [#] key advances to the next section but

does not save the changed data. Enter all 5 digits or scroll to the end of template programming and exit to save data.

3. After entering [00001], the first telephone number is displayed. Enter the monitoring station telephone number after the “D.” Press [#] to complete the entry.
4. After programming the first telephone number, enter a system account code.
 - The system account code can be any 6-digit combination of numbers (0-9) and letters (A-F). If the system account code is 4-digits, the last two digits must be “FF.”
 - To enter letters A through F, press [*] then the numbers 1 through 6 for the letter A through F respectively. Press [*] again to revert back to decimal entry. E.g., to enter “1234FF” press [1234*66]. See “[310] Account Codes” on page 47 for additional details.
5. After programming the system account code, the downloading access code is displayed. Enter the new downloading access code or press [#] to proceed to the next step. See section [402] PSTN DLS Phone Number Programming on page 51 for additional details.
6. The entry delay is the amount of time given to disarm the alarm system, after entering the premises through a delay type zone, before an alarm is sounded. Press [>][>][>] to accept the default time of 30 seconds (030) or enter an entry delay between 001 and 255. E.g., Press 020 for a delay of 20 seconds. See “[005] System Times” on page 30 for additional details.
7. The exit delay is the amount of time given to exit the premises after the alarm system is armed. Press [>][>][>] to accept the default time of 120 seconds or enter an exit delay between 001 and 255. E.g., press 030 for a delay of 30 seconds. See “[005] System Times” on page 30 for additional details.
8. After programming the exit delay, enter a 4 or 6-digit installer code, depending on the value in section [041] Access Code Digits on page 42. See [006] Installer Defined Access Codes on page 30 for installer code details.
9. Press [#] to exit Template Programming.

5.2.2 DLS Programming

DLS programming involves downloading custom programming using DLS software and a computer. This can be done locally or by remote.

NOTE: For UL listed systems an installer must be on the premises.

Local Programming With PC-Link

Follow the steps below in the sequence indicated to set up local programming using DLS:

1. Connect AC Wiring.

In a new installation, the backup battery requires 24 Hrs. charging. AC Power is required for PC-Link Programming until the battery is charged.
2. Plug the PC-Link header into the alarm controller. A DLS session is initiated on the DLS computer.
3. When the session is complete, remove the PC-Link cable from the alarm controller.
4. Complete the installation.

Remote Programming

DLS programming can be performed remotely by connecting to the alarm system via telephone line, cellular network or Ethernet.

Refer to section [401] DLS/SA Options on page 50 for details.

NOTE: AC Power must be present for the alarm system to answer incoming calls from DLS.

5.2.3 Installer Programming

Installer Programming is used to manually program alarm system options. Access this mode by keying in [*][8][Installer Code]. Use the scroll keys to navigate through the menus or jump directly to a specific section by keying in a section number.

Programming consists of toggling on and off options in each section or by populating data fields. For descriptions of all programming options, see 5.3 Programming Descriptions on page 26.

5.2.4 Viewing Programming

Programming sections can be viewed from any system keypad. The method for viewing and selecting programming options using LCD, LED and ICON keypads depends on the keypad type used. See below for specific instructions on programming with each keypad type.

Generally, programming options are accessed in the following way:

1. Enter Installer Programming mode ([*][8]).
2. Navigate to a specific programming section.
3. Select an option to view or change it's programming.

All programming options are numbered and can be accessed by navigating through the menu (LCD) or by keying in the program section number. The programming worksheets and descriptions later in this section provide a place to record custom programming settings and are numerically listed to assist in locating specific sections.

Keypad Types

The sections below describe how programming is viewed and interpreted using each of the supported keypad types. For more information on each keypad type, see the instruction sheet included with the keypad.

LED and ICON

Both of these keypads use LEDs to communicate information. The programming icon illuminates to indicate the alarm system is in Installer Programming mode. The Armed light turns off and the Ready light turns on while in a programming section.

Programming sections fall under two categories: those that require options to be “toggled” on or off, and those that require data to be keyed in.

Toggle options are indicated across the top of the display using zone numbers 1-8. For example, if options 1 and 4 are on, the display appears as follows on the different keypads:

Figure: 4 LED and ICON displays



To enable or disable a toggle option, press the number key on the keypad corresponding to the option.

Sections requiring data input, such as phone numbers, display information in a binary format using zone LEDs 1-4 as described in the following chart:

Figure: 5

Please See Hex Data Entry
Instructions Below

Value	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
Zone 1	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Zone 2	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Zone 3	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Zone 4	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■

□ Zone Light OFF
■ Zone Light ON

When a section is entered, the keypad immediately displays the first digit of information programmed. Using the example in Figure 5 above, if zone 1 and 4 are illuminated, the first programmed digit in the section is 9. Use the scroll key [>] to advance to the next digit.

For sections that require multiple two or three-digit numbers, the keypad beeps three times after each entry and moves to the next item on the list. After the last digit in the section is entered, the keypad beeps rapidly eight times and exits the programming section. The Ready light turns off and the Armed light turns on.

To exit programming at any time, press the [#] key. All changes made up to that point are saved.

LCD Keypad

LCD keypads use a full-message display that provides visual and numerical navigation through the programming sections. The Armed light illuminates when Installer Programming mode is activated. Use the scroll keys to move through menu options and press [*] to select. Alternatively, enter a specific section number. The Armed light flashes to indicate a sub-section has been selected. Press [*] to select a sub-section. The Ready light illuminates and the information programmed in the section is displayed.

For programming sections with toggle options, press the corresponding number on the keypad to turn the option on or off. The display changes accordingly.

Sections requiring data input, such as phone numbers, display the full data in fields up to 32 characters long.

To input data, use the scroll keys to select a character then press the keypad button corresponding to the number/letter required. Scroll to the next character and repeat the procedure as needed.

For information on entering HEX data, see below.

A 2-second error tone is sounded if an invalid key is pressed.

Press the [#] key to exit the program section at any time. All changes made up to that point are saved.

5.2.5 Programming Hex and Decimal Data

Hexadecimal (HEX) digits may be required during programming. To program a HEX digit, press the [*] key while in a programming section that requires a data entry. HEX programming mode activates and the Ready light begins to flash.

The following table indicates which number should be pressed to enter the corresponding HEX digit:

Table 5-2 HEX Digit Programming

Value	Enter	Telephone Dialer
HEX [A]	Press [*][1][*]	Not supported
HEX [B]	Press [*][2][*]	Simulated [*] key
HEX [C]	Press [*][3][*]	Simulated [#] key
HEX [D]	Press [*][4][*]	Dial tone search
HEX [E]	Press [*][5][*]	Two-second pause
HEX [F]	Press [*][6][*]	End of number

The Ready light continues to flash after the HEX digit is entered. If another HEX digit is required press the corresponding number. If a decimal digit is required, press the [*] key again. The Ready light illuminates and the panel returns to regular decimal programming.

Example: To enter 'C1' for a closing by user 1, enter [*][3][*], [1]

[*] to enter hexadecimal mode (Ready light flashes)

[3] to enter C

[*] to return to decimal mode (Ready light is on)

[1] to enter digit 1

If an error is made while inputting data, press the [#] key to exit the section. Select that section again and re-enter the information correctly.

When using a pulse communications format, a decimal zero [0] does not transmit for account and reporting codes. Programming a zero [0] tells the alarm system not to send any pulses for that digit. Decimal zero [0] is a filler digit. To make a zero [0] transmit, it must be programmed as a Hexadecimal 'A.'

Example: For the 4-digit account number '4032', enter [4] [*] [1] [*] [3], [0].

[4] to enter the digit 4

[*] to enter Hexadecimal mode (Ready light flashes)

[1] to enter A

[*] to return to decimal mode (Ready light is solid)

[3] to enter the digit 3

[2] to enter the digit 2

5.3 Programming Descriptions

This section provides descriptions of all alarm controller options programmable by the installer.

5.3.1 Adding Labels

[000] Label Programming

Zone and other labels on the alarm system can be customized.

Program labels locally or download/upload using DLS and Connect 24 interactive software. Local label programming is done via a system keypad, as described below.

[000] Language Selection

(LCD keypads only)

Use this section to set the language displayed by LCD keypads. To select a language:

1. Enter Installer Programming: [*][8][Installer Code].
2. Enter programming section [000]>[000].
3. Key in the 2-digit number corresponding to the language required. See below:

01 = English	11 = Swedish	22 = Bulgarian
02 = Spanish	12 = Norwegian	23 = Latvian
03 = Portuguese	13 = Danish	24 = Lithuanian
04 = French	14 = Hebrew	25 = Ukrainian
05 = Italian	15 = Greek	26 = Slovakian
06 = Dutch	16 = Turkish	27 = Serbian
07 = Polish	18 = Croatian	28 = Estonian
08 = Czech	19 = Hungarian	29 = Slovenian
09 = Finnish	20 = Romanian	
10 = German	21 = Russian	

[001][001]-[128] Zone Labels

Customized labels can be created for each available zone. Labels can be programmed at the keypad or downloaded/uploaded using DLS and Connect 24 interactive software. The maximum label size is 14 x 2 ASCII characters.

Manual Labels

The following procedure describes how to add zone labels using the LCD keypad:

1. Enter Installer Programming: [*][8][Installer Code].
2. Press [*], scroll to Zone Labels and press [*] again. The first zone is displayed. Alternately, press [000][001].
3. Scroll to the zone label to be programmed or key in the zone number. (e.g., 001 for zone label 1).
4. Scroll to the desired character's location using the [<] [>] keys.
5. Enter the number of the corresponding character group until the desired character is displayed (see table below).
Example: Press the "2" key 3 times to enter the letter "F."
Press the "2" key 4 times to enter the number "2."
To delete a character, use the [<] [>] keys to move the cursor under the character, then press [0].

- If any key other than [<] or [>] is pressed before [0], the cursor moves one space to the right and deletes that character.
6. Press [#] to save the changes and exit.

Press	To Select/Display
[*]	[SELECT]
[#]	[ESCAPE] (note: exits without saving label)
[0]	[SPACE]
[1]	[A], [B], [C], [1]
[2]	[D], [E], [F], [2]
[3]	[G], [H], [I], [3]
[4]	[J], [K], [L], [4]
[5]	[M], [N], [O], [5]
[6]	[P], [Q], [R], [6]
[7]	[S], [T], [U], [7]
[8]	[V], [W], [X], [8]
[9]	[Y], [Z], [9], [0]

Zone Label Options

To access zone label options such as using ASCII characters, changing letter case and clearing the display, press [*] while in Zone Label programming. The Select Option menu is displayed. Use the [<] [>] keys to access the following options:

Option	Description
WORD ENTRY	Provides access to the Word Library, a collection of words commonly used when programming labels. See below for details.
ASCII ENTRY	Used to access uncommon characters or as a primary method for programming labels. 255 character entries are available. Use the [<] [>] keys to scroll through the characters or enter a 3-digit number from 000-255. Press [*] to select a character. See page 114 for available ASCII characters.
CHANGE CASE	This option toggles the letter between upper case (A, B, C) and lower case (a, b, c).
CLEAR TO END	This option clears the display from the cursor to the end of the display.
CLEAR DISPLAY	This option clears all characters.
SAVE	Saves the new label.

Word Library

The Word Library is a database of words commonly used when programming labels. Individual words can be combined as needed (e.g., Front + Door). Words that do not fit on the first line are automatically moved to the bottom line.

To program a custom label using the Word Library:

1. Enter Installer Programming: [*][8][Installer Code].
2. Press [*], scroll to Zone Labels and press [*] again. The first zone is displayed. Alternately, press [000][001].
3. Scroll to the zone label to be programmed or key in the zone number (e.g., 001 for zone label 1).
4. Press [*] to open the Select Option menu.
5. Press [*] again to select the Word Entry option.
6. Enter the 3-digit number corresponding to a word (see Appendix B: Word Library on page 104) or use the scroll keys [<][>] to view words in the library.
7. Press [*] to select the word.
8. To add another word, repeat the above procedure from step 4.
9. To add a space, press the right scroll key [>].
10. To clear characters, select Clear to End or Clear Display from the Select Options menu.

To save the current label, press [#] to exit label programming.

[051] Zone Tamper Label

This label is displayed when a zone is tampered. The maximum label size is 14 x 1 ASCII characters.

[052] Zone Fault Label

This label is displayed when a zone is in fault. The maximum label size is 14 x 1 ASCII characters.

[064] CO Alarm Message

Use this section to program a custom label that is displayed on keypads during a carbon monoxide alarm. The maximum label size is 14 x 2 characters.

[065] Fire Alarm Message

Use this section to program a custom label that is displayed on keypads during a fire alarm. The maximum label size is 14 x 2 characters.

[066] Fail To Arm Event Message

This message is displayed on all partition keypads if a user attempts to arm the system when it is not ready to arm. The message clears after five seconds. The maximum label size is 16 x 2 characters.

[067] Alarm When Armed Event Message

This message is displayed if an alarm occurred while the system was armed. The message is displayed when the system is disarmed and remains on the screen for 5 seconds. Following this, the zones that went into alarm are displayed. The maximum label size is 16 x 2 characters.

[100] System Label

Use this section to program a custom label for the security system. This label is used in the event buffer when system events occur. The maximum label size is 14 x 1 characters.

[101]-[108] Partition 1-8 Labels

Use this section to program a name for each partition for display on partition keypads and event messages. The maximum label size is 14 x 2 characters. See “Programming” on page 24 for specific instructions on how to program labels.

[201]-[208] Partition Command Output Labels

Use this section to program custom labels for command outputs. These labels are used with output activation events in the event buffer. Enter subsection [201] to [208] to select partition 1 to 8, then enter subsection [001] to [004] to select command output 1 to 4 label. The maximum label size is 14 x 2 characters. See “Programming” on page 24 for specific instructions on how to program labels.

[601]-[604] Schedule Labels

Use this section to program custom labels for command output schedules. These labels are used to identify schedules for PGM command outputs 1-4. The maximum label size is 16 characters. See “Programming” on page 24 for specific instructions on how to program labels.

[801] Keypad Labels

Use this section to create custom labels for keypads on the system. Select 001-016 for keypads 1-16.

[802][001]-[016] HSM2108 Zone Expander Labels

Use this section to create custom labels for Zone expanders on the system. Select 001-016 for zone expanders 1-16.

[803][001]-[016] HSM2208 Output Expander Label

Use this section to create a custom label for the output expander. Select 001 for HSM2208. Select 001-016 for zone expanders 1-16.

[806] HSM2HOSTx Label

Use this section to create a custom label for the 2-way wireless transceiver.

[809][001]-[004] HS2300 Power Supply Label

Use this section to create custom labels for power supplies on the system. Select 001-004 for power supply 1-4.

[810][001]-[004] HS2204 High-Current Output Supply Label

Use this section to create custom labels for high-current output supplies on the system. Select 001-004 for output supply 1-4.

[815] Alternate Communicator Label

Use this section to create a custom label for the alternate communicator.

[820][001]-[016] Siren Labels

Use this section to create custom labels for sirens on the system. Select 001-016 for sirens 1-16.

[821][001]-[008] Repeater Labels

Use this section to create custom labels for wireless repeaters on the system. Select 001-008 for output supply 1-8.

[999][Installer Code][999] Default Labels

This section is used to return all labels to factory settings. Installer code is required to verify deletion.

5.3.2 Zone Setup

The following section describes zone programming options.

[001] Zone Type

A zone type defines how a zone operates within the system and how it responds when triggered.

[001]-[128] Select Zone

Every zone on the system must be assigned a zone type. The available zone types are listed below.

000 – Null Zone

Assign to all unused zones.

001 – Delay 1

Commonly assigned to primary points of entry. Follows entry delay 1 and exit delay timers (section [005]). Arming the alarm system starts the exit delay timer. After the exit delay has expired, opening the door starts the entry delay timer. During entry delay, the keypad buzzer prompts the user to disarm the system.

002 – Delay 2

Commonly assigned to secondary points of entry (further from the keypad). Follows entry delay 2 timer (section [005]).

003 – Instant

Commonly used for perimeter doors and windows, this zone type follows the exit delay. The alarm is triggered instantly if the zone is tripped after the exit delay expires.

004 – Interior

Commonly assigned to interior motion sensors near a point of entry, such as a foyer or hallway, that must be accessed to reach the keypad. The alarm is activated if the system is armed and a delay type zone (e.g., front door) is not tripped first, or if the entry/exit timer expires before the alarm is disarmed. Otherwise, the zone is instant if tripped.

005 – Interior Stay/Away

Similar to Interior zone type except that the system bypasses the zone when armed in Stay mode. Commonly used to activate perimeter zones while permitting free movement throughout the interior.

006 – Delay Stay/Away

Similar to delay 1 except that the zone is bypassed when armed in Stay mode. Commonly used with motion detectors that cover an entry point.

007 – Delayed 24-Hour Fire

This zone is used with smoke detectors and functions similar to the standard fire zone, except the communicator delays the alarm memory and transmission by 30 seconds. If the alarm is acknowledged by pressing any key, the siren is silenced and the transmission aborted. If the smoke detector is not restored after the alarm has been acknowledged, the siren output activates after 90 seconds and another 30-second delay starts. A code is required to silence the alarm. A tamper or fault causes a fire trouble to log and transmit.

008 – Standard 24-Hour Fire

This zone is used with smoke detectors. The siren sounds instantly when the smoke detector is activated. If enabled, the communicator immediately transmits the alarm to the monitoring station. A tamper or fault of this zone type causes a fire trouble to log and transmit.

009 – Instant Stay/Away

Commonly assigned to interior motion sensors. This zone type is bypassed when armed in Stay mode, but functions like an Instant zone [003] when armed in Away mode.

010 – Interior Delay

Commonly assigned to interior motion sensors. When Away armed, this zone type functions like the Interior zone type. When Stay or night armed, tripping the zone activates entry delay 1. Tripping this zone during exit delay does not cause the system to arm in Away mode, as tripping a regular Delay type zone does.

011 – Day Zone

Commonly used in areas where immediate notification of entry is desired. When disarmed, tripping this zone activates the keypad buzzer but does not log or report the event. When armed, tripping this zone activates the siren then logs and reports the event.

NOTE: An alarm during exit delay causes the siren to activate and remain on when exit delay expires.

012 – Night Zone

Commonly assigned to interior motion detectors in areas accessed during the night. This zone functions like an Interior Stay/Away zone [005] when armed using any method except the following: If Stay armed, this zone is bypassed; if armed using [*][1], this zone is bypassed.

017 – 24-Hour Burglary

This zone type is active at all times. It reports an alarm if the alarm system is armed or disarmed. This zone type sounds the siren for the length of Bell time-out if the audible attribute is enabled.

018 – 24-Hour Bell/Buzzer

When the alarm system is armed and this type of zone is tripped, the siren activates for the duration of the bell time-out. If the alarm system is disarmed when this type of zone is tripped, the keypad buzzer activates until an access code is entered.

023 – 24-Hour Supervisory

This zone is active and reports alarms at all times when tripped. The siren and keypad buzzer do not activate.

024 – 24-Hour Supervisory Buzzer

When tripped, the keypad buzzer emits a steady tone until a valid access code is entered.

025 – Auto Verify Fire

(Hardwired smoke detectors)

When the zone is activated, a 30-second delay begins but no fire alarm sounds. If the same zone is activated again up to 60 seconds after the delay expires, the alarm is triggered immediately. If the same zone is activated after 60 seconds, the entire sequence begins again.

If a second fire zone is violated during the auto-verify sequence, both zones a fire alarm is immediately triggered.

(Wireless smoke detectors)

When the zone is activated, a 40-second delay begins. The alarm is triggered if the zone is still faulted after 30 seconds. If the zone is no longer in alarm, an 80-second verification timer begins. If any fire zone is activated during this period, the alarm is triggered.

If another fire zone is activated during the auto verify sequence, both zones go into alarm immediately.

Note: Wireless smoke detectors used with this zone type must have a built in siren to act as a pre-alert to the system alarm.

027 – Fire Supervisory

When this zone is tripped, the keypad buzzer activates and a supervisory alarm is sent to the monitoring station. A valid access code must be entered to silence the buzzer.

040 – 24-Hour Gas

Instant alarm when activated, audible alarm at default. This zone type may be assigned to any device type.

041 – 24-Hour CO

This zone type is used with CO detectors. In the event of an alarm, a distinctive siren cadence is sounded. This is followed by a 5-second pause and then repeated. After 4 minutes, the 5-second pause is extended to 60 seconds; however, BTO must be programmed with a value of 5 minutes or higher. The siren is silenced when an access code is entered or the siren times out.

042 – 24-Hour Holdup

Instant alarm when activated, silent alarm at default.

NOTE: Not for use in UL listed installations.

043 – 24-Hour Panic

Instant alarm when activated, audible alarm at default.

045 – 24-Hour Heat

Instant alarm when activated, audible alarm at default.

046 – 24-Hour Medical

Instant alarm when activated, audible alarm at default.

047 – 24-Hour Emergency

Instant alarm when activated, audible alarm at default.

048 – 24-Hour Sprinkler

Instant alarm when activated, audible alarm at default.

049 – 24-Hour Flood

Instant alarm when activated, audible alarm at default.

051 – 24-Hour Latching Tamper

Instant alarm when activated, audible alarm at default. The alarm system cannot be armed until Installer Programming is entered.

052 – 24-Hour Non-Alarm

This zone is active at all times but does not cause an alarm. Zone attributes such as Zone Bypassing and Door Chime affect the functionality of this zone. This zone type can also be assigned to a temperature sensor if indoor/outdoor temperature display is required without temperature warnings or alarm conditions.

056 – 24 Hour High Temperature

This zone type is used with temperature sensors and is activated when the temperature rises above a programmed threshold (set in section [804]-[828]). Instant alarm when activated, audible alarm at default. This zone type generates an alarm when the system is armed or disarmed.

NOTE: The temperature threshold includes a 2.5 °C (5 °F) difference between a given state and its restored condition. For example, an alarm at 6 °C is restored at 3.5°C (High temperature) or 8.5°C (Low temperature), depending upon the zone type selected.

The zone type for temperature sensors must be 24 Hour High/Low Temperature in order for the sensor to operate properly.

057 – 24 Hour Low Temperature

This zone type is used with temperature sensors and is activated when the temperature drops below a programmed threshold (set in section [804]-[828]). Instant alarm when activated, audible alarm at default. This zone type generates an alarm when the system is armed or disarmed.

060 – 24-Hour Non-Latching Tamper

This zone is always active and reports a tamper condition with no audible alarm when opened or tamper/faulted.

066 – Momentary Keyswitch Arm

Often used with a keyswitch module*, turning the key alternately arms and disarms the system and silences the alarms. Tampers and faults only initiate their respective trouble sequence. The keypad gives no indication when this zone type is activated.

NOTE: With audible alarm active, using the keyswitch when disarmed is the same as entering an access code at the keypad. Using the keyswitch during the first 30 seconds of a delayed fire alarm is the same as pressing a key at the keypad (the 90 second delay starts). Activation of a keyswitch zone arms or disarms the system. Activation of this zone type is NOT logged nor is the Police code transmitted. Bypassed zones of this type are not un-bypassed when the system is disarmed. When the zone is bypassed, a zone bypass event buffer log and communication occurs immediately, NOT when the system is armed.

*Keyswitch module not for use in UL/ULC listed installations.

067 – Maintained Keyswitch Arm

Often used with a keyswitch module, turning the key arms the system. The system cannot be disarmed by turning the key again. Tampers and faults only initiate their respective trouble sequence.

Note: DO NOT use for wireless zones. Activation of the zone does not log or transmit the Police code. Bypassed zones of this type are not un-bypassed when the system is disarmed. When the zone is bypassed, a zone bypass event buffer log and communication occurs immediately, NOT when the system is armed.

With an audible alarm active, using the keyswitch when disarmed is the same as entering an access code at the keypad. Activating this zone type during the first 30 seconds of a delayed fire alarm is the same as pressing a key at the keypad (the 90 second delay starts). If left in the open state, the system does not arm until the zone is restored and tripped again.

068 – Momentary Keyswitch Disarm

Use with a keyswitch module. Activating and restoring this zone disarms the partition and silences alarms. Tampers or faults do not disarm the zone.

Note: Do not use as a global zone.

069 – Maintained Keyswitch Disarm

Used with a maintained keyswitch. Activating this zone disarms the partition.

Tampers or faults on this zone do not disarm the partition.

071 – Doorbell Zone

This zone type sounds a chime through keypads on the partition when activated. No alarms are generated. Various chime tones can be programmed. Disabling door chime on the partition also disables the chime on this zone.

NOTE: Do not use as a global zone.

[002] Zone Attributes

Zone attributes are used to customize the operation of zones. When a zone type (section [001]) is programmed, the default zone attribute is automatically assigned.

When programming attributes using LED/ICON keypads:

Ready light ON: Program attributes [1-8]

Ready light and Armed light ON: Program attribute [9-16] (press [1] for option 9, press [6] for option 14 etc.)

Press [9] to switch between attributes [1-8] and attributes [9-16].

NOTE: These attributes override default settings. Do NOT change fire zone attributes from their default settings.

[001]-[128] Select Zone

The attributes listed below can be enabled and disabled for each zone.

01 – Bell Audible

ON: An alarm activates the siren.

OFF: Silent alarm.

02 – Bell Steady

ON: Siren output is steady when in alarm.

OFF: Siren output pulses when in alarm.

03 – Door Chime

ON: The keypad chimes when the zone is open and when the zone is secured.

OFF: The zone does not chime.

04 – Bypass Enabled

ON: The zone can be manually bypassed.

OFF: The zone cannot be bypassed.

05 – Force Arm

ON: The system can be armed with the zone open. The zone is temporarily bypassed and, when secured, is monitored by the system.

OFF: The system cannot be armed if the zone is open.

06 – Swinger Shut Down

ON: When the zone goes into alarm for the number of times programmed in the Swinger Shutdown Counter (see page 47), it shuts down with no further transmissions sent to the monitoring station.

The siren follows swinger shutdown if programmed.

OFF: Swinger shutdown is disabled. All alarms are transmitted.

07 – Transmission Delay

ON: Reporting of zone alarms is delayed for the programmed time in section 377 (see page 48). If a valid access code is entered within this time, no alarm signal is communicated.

OFF: When an alarm occurs, the reporting code is transmitted immediately.

08 – Burglary Verification

ON: Enabled for cross zoning/police code. Zone alarms are not communicated until a burglary verified event occurs.

OFF: Not enabled for cross zoning/police code.

09 – Normally Closed (NC)

ON: The zone requires a normally closed loop.

OFF: The zone follows programming in section [013] option 2.

See note after option 11.

10 – Single End of Line (SEOL) Resistors

ON: The zone requires a single end-of-line resistor (5.6K).
 OFF: The zone follows programming in section [013] option 2.
 See note after option 11.

11 – Double End of Line (DEOL)

ON: The zone requires two end-of-line resistors (5.6K).
 OFF: The zone follows programming in section [013] option 2.
NOTE: If more than 1 option is enabled for options 09, 10, and 11 the lowest attribute number takes precedence. If options 09 and 10 are both enabled the zone follows the normally closed loop configuration.

12 – Fast Loop/Normal Loop Response

ON: Follows a fast loop response of 50ms.
 OFF: Follows a normal loop response as programmed in the Zone Loop Response Time section.

5.3.3 System Times

This section describes how to program various timers applicable to the entire alarm system.

[005] System Times

This is the base menu used by installers to program timers, including system area [000], partition timers [001]-[008], and daylight saving time [901]/[902]

[000] – System Area

Bell Cutoff Time:

System sirens follow this timer. Fire alarms follow this timer if section [014] option 8 (Fire Bell Continues Option) is off. System tamperers follow this timer. The bell cutoff time is programmed in minutes. Valid entries are 001 to 255 minutes. Keypad buzzer alarms do not follow this timer.

Burglary Verification Timer:

If another zone with the Burglary Verification attribute enabled is violated within the duration of this timer, a burglary verified event is communicated and logged. “Burglary Verified” is displayed on the keypad when the system is disarmed.
 The burglary verification timer is programmed in minutes. Valid entries are 000 to 255 minutes.

Zone Loop Response Time

Loop response time is a 3-digit entry from 005 to 255 programmed in 10ms increments. The minimum available loop response time is 50ms (e.g., program 005 for 50ms).

Automatic Clock Adjust

This value adds or subtracts seconds from the system clock at the end of each day to compensate for inaccuracies. To determine the adjustment value, monitor the time lost or gained by the alarm system over a period of time and calculate the average gains or losses.
 Example #1: The clock loses an average of 9 seconds per day. Program the alarm controller to adjust the clock by 51 seconds for the last minute of each day. This speeds up the alarm controller’s clock by 9 seconds, correcting the problem.
 Example #2: The clock gains an average of 11 seconds per day. Program the alarm controller to adjust the clock by 71 seconds for the last minute of each day. This slows down the alarm controller’s clock by 11 seconds, correcting the problem.

If the Auto-arm time is set for 23:59, any change to the Clock Adjust option will directly affect the Auto-arm pre-alert time.

[001]-[008] Partition 1-8 Timers

The following timers can be applied to each partition.

NOTE: For UL installations, the Entry Delay plus the Communications Delay must not exceed 60 seconds.

Entry Delay 1:

This value determines the entry delay time for delay 1 type zones. Valid entries are 001 to 255 seconds.

Entry Delay 2:

This value determines the entry delay time for delay 2 type zones. Valid entries are 001 to 255 seconds.

NOTE: The system follows the entry timer that activates first.

Exit Delay:

This value determines the exit delay time when arming the system. During exit delay, both the Ready and Armed LEDs are on. When the exit delay expires, both LEDs turn off.

[901]/[902] – Daylight Savings Begin/End

Daylight Begin [001] and Daylight End [002]:

Set the date and time daylight savings starts and ends.

Month

Valid entries are 001-012 (January to December).

Week

Valid entries are 000-005

Enter “000” to program a specific date (1-31) in the Day field. Enter 001-005 to program the specific week of the month. 005 is the last week of the month.

Day

1-31 (if 000 is programmed in the Week field). 0-6 (Saturday-Sunday) if 001-005 is programmed in the Week field.

Hour

Valid entries are 0-23 hours. This is the time of day to advance or turn the clock back.

Increment:

Valid entries are 1 or 2 hours. This is the number of hours to advance or turn the clock back.

5.3.4 Access Codes

This section is used by installers to program the installer code, the master code and the maintenance code. For information on programming other access codes, see 4.7.5 [*][5] Program Access Codes on page 19.

[006] Installer Defined Access Codes

This is the base menu used by installers to program the installer code [001], the master code [002] and the maintenance code [003]. See below for details.

[001] – Installer Code

This code is used by the installer to gain access to Installer Programming [*][8]. Users with this access code have access to all levels of system programming.

[002] – Master Code

This code is used by the master user, a person designated to perform operational tasks beyond those of the standard user. The master code provides access to functionality in the [*][5] and [*][6] menus.

[003] – Maintenance Code

This code is usually assigned temporarily to maintenance personnel who must deactivate the alarm to enter the premises. The maintenance code can arm and disarm the system, but does not grant access to any other functionality.

5.3.5 PGM Configuration

This section describes how to set up and configure programmable outputs.

PGMs are used to send electrical current to external devices such as lights and sirens, usually when an alarm event occurs. The alarm controller provides up to three 50mA PGMs and one 300mA PGM.

PGM outputs can be expanded using the optional 8-output expander (HSM2208) and the 4 high-current output expander (HSM2204).

Programming an output is a four-step process:

1. Program the PGM
2. Assign the PGM to a partition.
3. Assign an output attribute.
4. Assign an output option.

Refer to [011] PGM Config. Options on page 70 for PGM slot alignment.

[007] PGM Programming

This is the base menu used by the installer to assign PGMs to the main bell and a partition.

[000] Main Bell Partition Assignment

This programming section is used to define which partitions activate the main bell when they go into alarm. All partitions are selected by default.

[001]-[164] PGM Partition Assignment

This option enables the installer to assign each PGM output to a partition. To assign a PGM to a partition, first select the PGM output (PGM 1-164), then select the partition (1-8).

NOTE: This field is only supported by PGM types that have multiple partition capabilities (e.g., command outputs, away arming). It does not affect system outputs (e.g., ground start pulse).

[008] PGM Timer Programming

[000] PGM Minutes/Seconds

This option determines if the timer is in minutes or seconds.

[001]-[164] PGM Timer

This timer programs the duration (in seconds or minutes) that PGMs 1-164 activate if programmed to follow the PGM Timer.

Select option 001-164 for PGM 1-164.

This option does not affect outputs programmed as Sensor Reset.

5.3.6 PGM Types

The output types described in this section can be assigned to alarm controller and output expander module PGMs.

[009] PGM Types

Each alarm controller supports up to 2 or 4 PGMs and can be expanded using HSM2208 output expander modules. PGM attributes are defined in section [010] PGM Attributes on page 33. Programmable Output Attributes.

[001]-[164] Select PGM

100 – Null PGM

This option deactivates the PGM output.

101 – Burglary and Fire Bell Follower

This PGM output follows:

- Fire pre-alerts
- Temporal three fire signal (if enabled)
- All audible burglary and fire alarms by partition
- Bell cut-off time

- Bell squawk conditions
- Audible exit fault

This output activates when the alarm output is active and turns off when the alarm output is silenced. The siren pattern matches the programmed cadence for the zone that went into alarm. Cadence priority is as follows:

- fire alarm cadence
- CO alarm cadence
- other alarm cadences

This output will NOT follow bell squawks of any kind. The main siren still activates for all alarms.

102 – Delayed Fire and Burglary

This output type operates the same as the Burglary and Fire Bell Follower (PGM type 01), but does not activate until the transmission delay time expires.

When a zone with transmission delay enabled is tripped, the Bell, Regular Fire and Burglary PGMs activate. At the end of the transmission delay, the delayed Fire and Burglary output activates.

This PGM is usually used to control outdoor sirens. If a false alarm occurs, the user has time to disarm the system before the external sirens activate.

NOTE: If a zone alarm occurs but does not follow transmission delay, this PGM activates immediately, even if transmission delay is active for a different zone alarm.

This output activates for audible exit fault and does not interfere with the operation of any other programmable output.

103 – Sensor Reset [*][7][2]

This output is normally active and deactivates for 5 seconds when a [*][7][2] fire reset command is entered or when an auto verify alarm is detected. This option is used to reset power for latching smoke detectors. The keypad buzzer does not sound for the 5-second period. Refer to page 8 for instructions on wiring smoke detectors.

104 – 2-Wire Smoke

When this PGM is programmed, the onboard PGM functions as an input instead of an output. 2-wire smoke detectors can be connected to this input, which means that a zone input does not need to be used.

The PGM is also supervised, and a trouble condition is generated if a 2.2KΩ resistor is not present between the PGM terminal and Aux+.

The 2-wire smoke detector input creates an instant and latching alarm.

109 – Courtesy Pulse

Courtesy pulse causes an output to activate for the entry and exit times, plus 2 minutes. This option is typically used to activate a courtesy light near the exit door for the duration of the entry/exit times.

111 – Keypad Buzzer Follow

PGM output activates with the keypad buzzer when triggered by the events below. The PGM output remains active for the duration of the keypad buzzer.

- 24-hour supervisory buzzer zone alarm
- No activity arm pre-alert
- Entry delay
- Audible exit fault
- Audible exit delay
- Door chime

This PGM type does not activate for local key presses or trouble beeps.

114 – Ready to Arm

This PGM activates when the system is ready to arm (all non-force armed zones on the system are restored). The PGM output deactivates when an access code is entered to arm the system and the exit delay begins. This PGM operates as described during walk test mode (if all zones are restored).

115 – System Armed Status

This output activates when all selected partitions are armed (end of the exit delay) in either Stay or Away modes. The output de-activates when the system is disarmed.

116 – Away Armed Status

This PGM switches on at the beginning of exit delay when the system is armed with stay/away zones activated. If the system is armed with the stay/away zones always active, then the away output is active.

117 – Stay Armed Status

This PGM output activates if the system is armed with the stay/away zones bypassed.

120 – Away Armed with No Zone Bypasses Status

When assigned to a single partition, this PGM output activates when the system is armed with stay/away and night zones active, and no zones are bypassed.

If assigned to multiple partitions, all partitions must be armed in away mode with no bypassed zones before the PGM activates. If a force armable zone is violated at the time of arming, the PGM does not activate. When the zone is restored, the PGM activates.

121-124 – Command Outputs 1-4

Command Outputs 1-4 are user-activated by entering [*][7][1-4] at any keypad. When an output is activated, three acknowledgment beeps are sounded.

PGM outputs of this type can be programmed to follow a pre-defined schedule (programmed in section [601]-[604] Programming Schedule 1-4 on page 52). Even if the output follows a schedule it can be manually turned ON, OFF or follow the schedule through [*][7].

To select a schedule for these PGM outputs to follow, see [009] PGM Types on page 31.

129 – Partition Status Alarm Memory

This feature is intended to be used on a keyswitch plate, with a light controlled by this PGM to indicate system status. The output activates (steady) at the beginning of exit delay when the partition is armed. If an alarm occurs on the armed partition, the output flashes for the remainder of the armed period. If an alarm occurs on a disarmed partition (24 Hr Zone), the output flashes until the alarm is acknowledged.

This output will not activate during a walk test or for FMP key, holdup or audible/silent PGM2 input alarms.

132 – Holdup Output

When a Holdup zone (Type [42]) goes into alarm, this output activates until the partition is either armed (access code, keyswitch, [*][0], etc.) or disarmed. A tamper or fault on a holdup zone type does not activate this output. This output does not activate in Walk Test mode. If a global holdup alarm occurs, each partition with holdup zones assigned must be armed or disarmed before the holdup output deactivates. If holdup alarms occur on multiple partitions, an access code must be entered at each partition before the output deactivates.

NOTE: Not for use with UL/ULC listed installations.

134 – 24-Hour Silent Input (PGM 2)

With this input the keypad does not indicate an alarm, the siren remains silent, and the signal is sent to the central station. This input does not follow swinger shutdown. A 2.2K Ω EOL resistor is required for this input (to Aux+). If a short or open occurs, an alarm is generated.

Not for use with UL installations.

135 – 24-Hour Audible Input (PGM 2)

LCD keypads indicate that the system is in alarm, the siren sounds for the duration of bell timeout, and the signal is sent to the central station. This input does not follow swinger shutdown. A 2.2K Ω EOL

resistor is required for this input (to Aux+). If a short or open occurs, an alarm is generated for all partitions and sirens. PGM partition assignment does not affect this PGM type.

146 – TLM and Alarm

This output activates when a telephone line fault condition is present AND an alarm occurs. The output remains active until an access code is entered to disarm or the TLM trouble is restored. The output activates for all audible and silent alarms (except duress) if a TLM trouble is present. If an alarm activates this output in the disarmed state, it will deactivate when the system is armed or the telephone line is restored. This output type also activates if alarms are in memory (not only for currently active alarms) when the TLM fault occurs. The alarms in memory must have exceeded the bell timeout.

147 – Kissoff

This PGM output activates for two seconds after the alarm system receives a kissoff signal from the central station.

148 – Ground Start

This output activates for two seconds before the alarm system attempts dialing to obtain a dial tone on Ground Start telephone equipment. Two 2-second pauses must be inserted at the beginning of the telephone number when using this option.

149 – Alternate Communicator

This output can be used to notify the home owner, before they enter the premises, that an alarm has occurred. This output can be programmed to activate when any of the following system events (alarms) occur on the system:

- Fire (Fire Key, Fire Zones)
- Panic (Panic Key and Panic Zones)
- Burglary (Delay, Instant, Interior, Stay/Away and 24-hour Burglary Zones)
- Opening/Closing Events
- Zone Auto-Bypass. (Please see 08 – Zone Auto-Bypass on page 35 for details).
- Medical (Medical Key, Medical and Emergency Zones)
- Burglary Verified
- Opening After Alarm
- Emergency Alarm
- Duress Alarm

In the armed state, this output deactivates when the system is disarmed. If an alarm activates this output in the disarmed state, the output deactivates if a valid access code is entered within the bell timeout or if the system is armed after the bell timeout has expired.

This output activates for silent and audible alarms or medical conditions only. It will not activate during pre-alert or delays.

NOTE: The PGM attributes for this option, programmed in section [010], differ from the standard selection of attributes normally programmed.

155 – System Trouble

This output can be programmed to activate when any of the following trouble conditions are present:

- Service Required
- Loss of Clock
- DC Trouble
- Bus Voltage
- AC Trouble
- Device Fault
- Device Low Battery
- Device Tamper
- RF Delinquency
- Module Supervisory
- Module Tamper
- Communications

- Not Networked

This output deactivates when all of the selected trouble conditions are cleared.

156 – Latched System Event (Strobe)

This output can be used to notify the home owner, before they enter the premises, that an alarm has occurred. This output can be programmed to activate when any of the following alarms occur on the system:

- Burglary (Delay, Instant, Interior, Stay/Away and 24-Hour Burglary Zones)
- Fire (Fire Key, Fire Zones)
- Panic (Panic Key and Panic Zones)
- Medical (Medical Key, Medical and Emergency Zones)
- Supervisory (Supervisory, Freezer and Water Zones)
- Priority (Gas, Heat, Sprinkler and 24-Hour Latching Zones)
- Holdup (Holdup zones)
- Output follows pulse timer (section [008] PGM Timer Programming on page 31).

This output does not activate during pre-alert or delays.

In the armed state, the output deactivates only once the system is disarmed.

If an alarm activates this output in the disarmed state, the output deactivates when a user enters a valid access code during bell timeout. The output also deactivates if someone arms the system after the bell timeout has expired.

If assigned to a single partition, the output activates when an enabled alarm event occurs on the assigned partition. When assigned to multiple partitions, the output activates when an alarm occurs on any partition and, if configured to latch, will deactivate when any partition is disarmed. (or a valid disarming procedure is used).

157 – System Tamper

This output activates when any tamper condition is present and deactivates when all tamper conditions are cleared (if set for steady operation). If set for a pulsed operation, the output deactivates when the PGM Output timer expires. These tampers include zone tampers (DEOL), case tampers, TLM trouble, RF jam, and all zone and device tampers.

161 – DC Trouble

This output activates when one of the following low battery conditions is detected:

- Alarm controller low or absent battery
- Module low or absent battery
- Wireless zone low battery
- Wireless keypad low battery
- Wireless siren low battery
- Wireless key low battery

The output can be configured to follow the state of the low battery trouble(s) or it can activate for a period of time and automatically restore.

165 – Proximity Tag Used

This output activates when the selected proximity tag is presented.

Assign this output to a user by entering a user number from 001 to 095. To enable this attribute for all proximity tags, enter 000 in PGM attribute [011]. See [011] PGM Configuration Options on page 37.

175 – Bell Status and Programming Access Output

This PGM activates when the siren, Installer Programming mode or DLS/SA is active. It deactivates after bell timeout, when Installer Programming is exited or when DLS/SA programming is disconnected.

176 – Remote Operation

This output is activated and deactivated remotely on command from DLS software.

NOTE: Not for use with UL/ULC listed installations.

184 – Open After Alarm

This output activates when the system has been disarmed after an alarm. It deactivates when a valid user code is entered or when the PGM Output timer expires.

200 – Zone Follower - PGM By Zone

This option allows the PGM to activate when the assigned zone is opened and deactivate when the zone is restored or, if programmed, when a valid access code is entered. This PGM follows the state of the assigned zone, regardless of the partition the zone or PGM is assigned to.

To program which zone the PGM will follow, see [011] PGM Configuration Options on page 37.

201-216 – Zone Follower (Zones 1-128)

This output type is assigned to a group of zones and is normally activated, but deactivates when a zone is tripped. Zones are assigned to this output in the following groups:

201 – Zones 1-8	209 – Zones 65-72
202 – Zones 9-16	210 – Zones 73-80
203 – Zones 17-24	211 – Zones 81-88
204 – Zones 25-32	212 – Zones 89-96
205 – Zones 33-40	213 – Zones 97-104
206 – Zones 41-48	214 – Zones 105-112
207 – Zones 49-56	215 – Zones 113-120
208 – Zones 57-64	216 – Zones 121-128

If multiple zones are enabled, any active zone in that group triggers the output. The PGM will not activate again until all zones are restored.

[010] PGM Attributes

The following options are used to program the operating characteristics of the main bell and PGM outputs.

[000] Main Bell Mask

This programming section is used to configure the types of audible alarms that trigger the main bell output on the alarm controller. All options are selected by default.

Fire Alarm

ON: Fire alarm ([F] key, Fire zones) activates the main siren.

OFF: Fire alarm does not activate the main siren.

CO Alarm

ON: CO alarm activates the main siren.

OFF: CO alarm does not activate the main siren.

Burglary Alarm

ON: Burglary alarm (Delay, Instant, Interior, Stay/Away, Night, Interior Delay, Instant Stay/Away, Day, 24-hour Burglary) activates the main siren.

OFF: Burglary alarm does not activate the main siren.

24-Hour Flood Alarm

ON: Main bell activates in the event of a 24-Hour Flood alarm.

OFF: Main bell does not activate in the event of a 24-Hour Flood alarm.

Bell Squawks

ON: Squawks activate the main siren. Bell squawks must be enabled to use the following options:

- Bell Squawk on arm (single)
- Bell Squawk on disarm (double)
- Bell Duration Auto-Arm (single every second)

- Bell Squawk on Exit (single every second)
- Bell Squawk on Entry (single every second)
- Bell Squawk on Trouble (single every 10 seconds)

OFF: Squawks do not activate the main siren.

[001]-[164] PGM 1-28 Attributes

The following PGM attributes can be assigned to a PGM. Each attribute has various toggle options, depending on the PGM type selected (section [009]).

101 – Fire and Burglary

01 – True output/Inverted

ON: deactivated during normal operation. Activated when triggered.

OFF: active during normal operation. Deactivated when triggered.

102 – Delay Fire and Burglary

01 – True output/Inverted

ON: deactivated during normal operation. Activated when triggered.

OFF: active during normal operation. Deactivated when triggered.

103 – Sensor Reset [*][7][2]

01 – True output/Inverted

ON: deactivated during normal operation. Activated when triggered.

OFF: active during normal operation. Deactivated when triggered.

03 – Access Code Required / No Code Required

ON – Access code required for activation

OFF – No access code required for activation

109 – Courtesy Pulse

01 – True output/Inverted

ON: deactivated during normal operation. Activated when triggered.

OFF: active during normal operation. Deactivated when triggered.

111 – Keypad Buzzer Follow

01 – True Output/Inverted

ON: deactivated during normal operation, activated when triggered.

OFF: activated during normal operation, deactivated when triggered.

02 – Timed Output / Latched Output

ON: output remains active until an access code is entered or certain criteria have been met, depending on the PGM type.

OFF: output remains active until the PGM output timer expires.

09 – Entry Delay

ON: activates on entry delay.

OFF: does not activate on entry.

10 – Exit Delay

ON: activates on exit delay.

OFF: does not activate on exit delay.

11 – Door Chime

ON: activates when chime is enabled.

OFF: does not activate when chime is enabled.

12 – Keypad Buzzer Zone

ON: activates when keypad buzzer goes into alarm.

OFF: does not activate when keypad buzzer goes into alarm.

13 – Audible Exit Fault

ON: activates when audible exit fault pre-alert begins.

OFF: does not activate when audible exit fault pre-alert begins.

14 – Auto-Arm Pre-Alert

ON: activates when auto-arming pre-alert begins.

OFF: does not activate when auto-arming pre-alert begins.

114 – Ready To Arm

01 – True output/Inverted

ON: deactivated during normal operation. Activated when triggered.

OFF: active during normal operation. Deactivated when triggered.

115 – Armed Status

01 – True output/Inverted

ON: deactivated during normal operation. Activated when triggered.

OFF: active during normal operation. Deactivated when triggered.

116 – Armed Away Mode

01 – True output/Inverted

ON: deactivated during normal operation. Activated when triggered.

OFF: active during normal operation. Deactivated when triggered.

117 – Armed Stay Mode

01 – True output/Inverted

ON: deactivated during normal operation. Activated when triggered.

OFF: active during normal operation. Deactivated when triggered.

121-124 – Command Output 1-4

01 – True Output/Inverted

ON: deactivated during normal operation, activated when triggered.

OFF: activated during normal operation, deactivated when triggered.

02 – Timed Output / Latched Output

ON: output remains active until an access code is entered or certain criteria have been met, depending on the PGM type.

OFF: output remains active until the PGM output timer expires.

03 – Access Code Required / No Code Required

ON – Access Code Required for Activation

OFF – No Access Code Required for Activation

129 – Partition Status Alarm Memory

01 – True output/Inverted

ON: deactivated during normal operation. Activated when triggered.

OFF: active during normal operation. Deactivated when triggered.

132 – Holdup Output

01 – True output/Inverted

ON: deactivated during normal operation. Activated when triggered.

OFF: active during normal operation. Deactivated when triggered.

146 – TLM Alarm

01 – True output/Inverted

ON: deactivated during normal operation. Activated when triggered.

OFF: active during normal operation. Deactivated when triggered.

147 – Kissoff Output

01 – True output/Inverted

ON: deactivated during normal operation. Activated when triggered.

OFF: active during normal operation. Deactivated when triggered.

148 – Ground Start

01 – True output/Inverted

ON: deactivated during normal operation. Activated when triggered.

OFF: active during normal operation. Deactivated when triggered.

149 – Alternate Communicator

01 – True Output/Inverted

ON: deactivated during normal operation, activated when triggered.

OFF: activated during normal operation, deactivated when triggered.

02 – Timed Output / Latched Output

ON: output remains active until an access code is entered or certain criteria have been met, depending on the PGM type.

OFF: output remains active until the PGM output timer expires.

04 – Fire Alarm

- ON: activates with fire alarm, [F] key, fire zones, 2-wire smoke.
OFF: does not activate with fire alarm.
- 05 – Panic Alarm
ON: activates with panic alarm, [P] key, panic zones.
OFF: does not activate with panic alarm.
- 06 – Burglary Alarm
ON: activates with burglary alarm.
OFF: does not activate with burglary alarm.
- 07 – Open/Close
ON: activates with opening or closing.
OFF: does not activate with opening or closing.
- 08 – Zone Auto-Bypass
ON: activates when a zone is automatically bypassed.
OFF: does not activate when a zone is automatically bypassed.
- 09 – Medical Alarm
ON: activates with medical alarm, [+] key, medical zones.
OFF: does not activate with medical alarm.
- 10 – Burglary Verified
ON: activates with burglary verified alarm (or police code).
OFF: does not activate with burglary verified alarm.
- 11 – Open After Alarm
ON: activates when the system is disarmed with an alarm in memory.
OFF: does not activate when the system is disarmed with an alarm in memory.
- 12 – Emergency Alarm
ON: activates with zone emergency alarm.
OFF: does not activate with zone emergency alarm.
- 13 – Duress Alarm
ON: activates with duress alarm.
OFF: does not activate with duress alarm.
- 155 – System Trouble**
- 01 – True Output/Inverted
ON: deactivated during normal operation, activated when triggered.
OFF: activated during normal operation, deactivated when triggered.
- 02 – Timed Output / Latched Output
ON: output remains active until an access code is entered or certain criteria have been met, depending on the PGM type.
OFF: output remains active until the PGM output timer expires.
- 04 – Service Required
ON: activates on service required trouble condition.
OFF: does not activate on service required trouble condition.
- 05 – Loss of Clock
ON: activates on loss of clock trouble condition.
OFF: does not activate on loss of clock trouble condition.
- 06 – DC Trouble
ON: activates if a panel low or no battery trouble is detected, or if an HSM2204/2300 1-4 low or no battery trouble is detected.
OFF: does not activate on DC Trouble condition.
- 07 – Bus Voltage
ON: activates when a system module has measured a low Aux voltage.
OFF: does not activate for a module low voltage trouble.
- 08 – AC Trouble
ON: activates when any system device detects an AC Failure condition.
OFF: does not activate for AC Failure conditions.
- 09 – Device Fault
ON: activates if one of the following device fault conditions is present:
 - zone 001 – 128 fault
 - keypad 01 -16 fault
 - siren 01 – 16 fault
 - repeater 01 – 08 fault
 - fire trouble
 - CO trouble
 - gas trouble
 - heat trouble
 - freeze trouble
 - probe disconnected trouble
OFF: does not activate if a device fault condition is present.
- 10 – Device Low Battery
ON: activates if any of the following device low battery conditions is present:
 - zone 001 – 128
 - keypad 01 – 16
 - siren 01 – 16
 - repeater 01 – 08
 - user 01 – 32 (wireless keys)
OFF: does not activate if a device low battery condition is present.
- 11 – Device Tamper
ON: activates if any of the following device tamper conditions is present:
 - zone 001 – 128
 - keypad 01 – 16
 - siren 01 – 16
 - repeater 01 – 08
OFF – does not activate if a device tamper condition is present.
- 12 – RF Delinquency
ON: activates if any of the following RF delinquency troubles is detected:
 - zone 001 – 128
 - keypad 01 – 16
 - siren 01 – 16
 - repeater 01 – 08
OFF – does not activate if an RF delinquency condition is present.
- 13 – Module Supervisory
ON – activates if any of the following module supervisory troubles is detected:
 - HSM2HOST
 - keypad 01 – 16
 - zone expander 01 – 15
 - HSM2204 1 – 4
 - HSM2300 1 – 4
 - HSM2208 01 – 16
OFF – does not activate if a module supervisory trouble is detected.
- 14 – Module Tamper
ON – activates if any of the following module tamper conditions is present:
 - HSM2HOST
 - Keypad 01 – 16
 - Zone expander 01 – 15
 - HSM2204 1 – 4
 - HSM2300 1 – 4
 - HSM2208 01 – 16 tamper troubles
OFF – does not activate if a module tamper condition is present.
- 15 – Communications
ON – activates if any of the following communications conditions is present:
 - TLM trouble
 - FTC receiver 1 – 4
 - SIM Lock trouble
 - Cellular Trouble
 - Ethernet Trouble

- Receiver 1 – 4 absent
- Receiver 1 – 4 supervision trouble
- SMS Configuration trouble
- Alt comm. Fault.

OFF – does not activate if a communications trouble condition is present.

16 – Not Networked

ON – activates if any of the following not networked conditions is present:

- Zone 001 – 128
- Keypad 01 – 16
- Siren 01 – 16
- Repeater 01 – 08
- User 01 – 95 (wireless keys) not networked troubles

OFF – does not activate if a not networked trouble condition is present

156 – Latched System Event

01 – True output/Inverted

ON: deactivated during normal operation. Activated when triggered.

OFF: activated during normal operation. Deactivated when triggered.

02 – Timed Output / Latched Output

ON: output remains active until the PGM output timer expires.

OFF: output remains active until an access code is entered or certain criteria have been met, depending on the PGM type.

04 – Fire Alarm

ON: activates with fire alarm, [F] key, fire zones, 2-wire smoke.

OFF: does not activate with fire alarm.

05 – Panic Alarm

ON: activates on panic alarm (audible or silent).

OFF: does not activate on panic alarm.

06 – Burglary Alarm

ON: activates on burglary alarm.

OFF: does not activate on burglary alarm.

07 – Medical Alarm

ON: activates on medical alarm.

OFF: does not activate on medical alarm.

08 – Supervisory

ON: activates on supervisory alarm.

OFF: does not activate on supervisory alarm.

09 – Priority Event

ON: activates on priority alarm.

OFF: does not activate on priority alarm.

10 – Holdup

ON: activates on Holdup alarm.

OFF: does not activate on Holdup alarm.

11 – Duress Alarm

ON: activates on duress alarm.

OFF: does not activate on duress alarm.

12 – Emergency Alarm

ON: activates on emergency alarm.

OFF: does not activate on emergency alarm.

13 – Fire Supervisory

ON: activates on fire supervisory alarm.

OFF: does not activate on fire supervisory alarm.

14 – Fire Trouble

ON: activates on fire trouble condition.

OFF: does not activate on fire trouble condition.

15 – CO Alarm

ON: activates on CO alarm.

OFF: does not activate on CO alarm.

157 – System Tamper

01 – True output/Inverted

ON: deactivated during normal operation. Activated when triggered.

OFF: activated during normal operation. Deactivated when triggered.

09 – System/Module Tamper

ON: activates when any module tamper condition occurs.

OFF: does not activate when any module tamper condition occurs.

10 – Zone Tamper

ON: activates when any zone tamper condition occurs.

OFF: does not activate when zone tamper conditions occur.

161 – DC Trouble

01 – True output/Inverted

ON: deactivated during normal operation. Activated when triggered.

OFF: activated during normal operation. Deactivated when triggered.

02 – PGM Timer

ON: output remains active until an access code is entered or certain criteria have been met, depending on the PGM type.

OFF: output remains active until the PGM output timer expires.

09 – Battery Low

ON: activates when a low battery trouble occurs.

OFF: does not activate when a low battery trouble occurs.

10 – Battery Absent

ON: activates when a battery absent trouble occurs.

OFF: does not activate when a battery absent trouble occurs.

165 – Prox Used

01 – True output/Inverted

ON: deactivated during normal operation. Activated when triggered.

OFF: activated during normal operation. Deactivated when triggered.

175 – Bell Prog Access

01 – True output/Inverted

ON: deactivated during normal operation. Activated when triggered.

OFF: activated during normal operation. Deactivated when triggered.

176 – Remote Operation

01 – True output/Inverted

ON: deactivated during normal operation. Activated when triggered.

OFF: activated during normal operation. Deactivated when triggered.

184 – Open After Alarm

01 – True output/Inverted

ON: deactivated during normal operation. Activated when triggered.

OFF: activated during normal operation. Deactivated when triggered.

201 – 216 Zone Follower Zones 1-128

01 – True Output/Inverted

ON: deactivated during normal operation. Activated when triggered.

OFF: activated during normal operation. Deactivated when triggered.

02 – Timed Output / Latched Output

ON: output remains active until an access code is entered or certain criteria have been met, depending on the PGM type.

OFF: output remains active until the PGM output timer expires.

09-016 – Zone Terminals 1-8

ON: zones associated with terminals 1-16 are enabled for zone follower operation.

OFF: zones are not enabled for zone follower operation.

[011] PGM Configuration Options

This section is used to configure PGM types that offer multiple options.

[001]-[164] Select PGM

The following options may be selected for each PGM:

Zone Follow PGM By Zone

This option is used to specify the zone that PGM type 200 follows. Enter 000-128 to select zone 1-128.

Proximity Tag Used

This option is used to define which proximity tag will activate PGM outputs programmed as [165] Prox Used. Enter 000 to enable this PGM attribute for all user proximity tags, or enter user number 002-095 to have this attribute activated by a specific user proximity tag.

Command Output 1-4

This option is used to assign a schedule, programmed in section [601]-[604], for the command output PGMs to follow.

[012] System Lockout

Keypad Lockout – Number of Invalid Local Attempts

This option controls the number of invalid access code entries allowed before the keypad is locked.

When keypad lockout occurs, the system is inaccessible by keypad for the programmed duration. If the number of invalid attempts is not reached within one hour, or if a valid access code is entered, the counter is reset to 0. Valid entries are 000 to 255 minutes. Entering 000 disables the feature. Presenting an invalid tag counts toward keypad lockout.

Keypad Lockout Duration

This programming option determines the length of time the keypad is locked out for. If the system cold starts while in keypad lockout, the lockout is removed. Valid entries are 000 to 255 minutes. Entering 000 disables keypad lockout.

Remote Lockout DLS

This programming option determines the number of invalid access code entries allowed via SMS or DLS before remote access is locked out for the programmed duration (see below). If the number of invalid attempts is not reached within one hour, or if a valid access code is entered through SMS or DLS, the counter is reset to 0. The valid entries are 003 to 255 attempts. Default is 6 attempts.

NOTE: DLS tries to connect using the programmed DLS Access code first and, if unsuccessful, using the default DLS access code. Two failed attempts are counted if both codes are incorrect.

Remote Lockout Duration

This programming option determines how long the remote lockout lasts for. If the system cold starts while in remote lockout, the lockout restarts for the programmed duration. Valid entries are 001 to 255 minutes. Entering 000 disables remote lockout.

5.3.7 System Options

[013] System Option 1

1 – NC Loop/EOL

ON: All zones are wired as normally closed circuits with returns connected to a COM terminal. The end-of-line resistor is not required. An alarm is generated when the circuit is opened.

OFF: All zones must be wired with an end-of-line resistor configuration, determined by option 2 below.

NOTE: The valid EOL value is 5600 Ohms (5.6K Ω).

2 – DEOL/SEOL

ON: All zones use Double-End-of-Line resistors, except Standard Fire, Delayed Fire, Auto-Verified Fire, Co and Supervisory zone types. DEOL resistors enable detection of zone faults and tampers. The tamper resistor (5.6K Ω) is placed in parallel across the alarm activating device, and the single EOL resistor (5.6K Ω) is placed between the alarm and tamper contacts.

This allows detection of zone faults (shorted zone), tampers (open zone), alarms (11.2K Ω), and restored zones (5.6K Ω).

If the zone is disarmed and placed in the tamper or fault state, trouble beeps sound on all system keypads until a key is pressed on each partition. A zone tamper is sent to the monitoring station if programmed. If the zone is armed and a tamper is activated, the tamper alarm and zone alarm are logged and transmitted.

OFF: All zones must have a 5.6K Ω resistor. If the zone is shorted or open, it is in the tripped state. If the zone is open and programmed as a fire zone, it is in the trouble state. The EOL and DEOL zone attributes override this system option.

NOTE: Zone Faults (Supervisories) on wireless zones do not cause an audible alarm while armed.

3 – Show All Troubles When Armed

ON: The Trouble LED illuminates when troubles are present on the system in both the armed and disarmed state.

OFF: The Trouble LED illuminates for all troubles while disarmed, but only for Fire Troubles while armed.

4 – Tamper/Faults Do Not Show As Open

ON: The zone LED does not illuminate if the zone is in the tamper or fault states. Only the Trouble LED illuminates.

OFF: The respective zone LED illuminates if the zone is in the tamper or fault states. The Trouble LED also illuminates.

5 – Auto-Arm Schedule in [*][6]

ON: The auto-arm schedules ([151] - [158]) are accessible to installers via [*][6] as well as Installer Programming.

OFF: The auto-arm schedules ([151] - [158]) are only accessible to installers via Installer Programming.

NOTE: This toggle controls access for all eight partitions.

6 – Audible Exit Fault

ON: If a delay type zone is violated after the exit delay has expired, an entry delay warning is sounded through the keypad and siren indicating that an improper exit was made. If the alarm system is disarmed within the entry delay period no signal is sent.

OFF: The entry delay warning is sounded only through the keypad.

7 – Event Buffer Follows Swinger

ON: Once an event reaches its swinger shutdown limit programmed in section [377] Communication Variables on page 47, it will no longer log events to the event buffer until the swinger shutdown is reset. This avoids filling the event buffer with false events.

OFF: The event buffer continues to log events to the buffer even after the event has gone into swinger shutdown.

8 – Temporal Three Fire Signaling

ON: All fire bells sound in the temporal three pattern. Cadence is as follows: (500ms ON, 500ms OFF, 500ms ON, 500ms OFF, 500ms ON, 1.5 sec. OFF).

OFF: All fire bells will sound with the standard 1 second on/1 second off fire bell cadence.

NOTE: Must be on for UL/ULC installations.

[014] System Option 2

1 – Bell Squawk

ON: The siren emits a single squawk when armed in any manner, including Auto-arm, and a double squawk when disarmed.

When the system is disarmed, the siren emits a series of three squawk pairs to indicate alarms in memory.

OFF: The siren does not squawk when arming or disarming.

NOTE: For UL/ULC, must be enabled if wireless keys are used with the alarm system.

2 – Bell Squawk on Auto-Arm

ON: The siren squawks once every 10 seconds during the auto-arm pre-alert time.

OFF: The siren does not squawk during auto-arm pre-alert.

3 – Bell Squawk On Exit

ON: The siren squawks once per second during exit delay, changing to 3 squawks per second for the final 10 seconds.

OFF: The siren does not squawk for exit delay conditions.

4 – Bell Squawk On Entry

ON: The siren pulses with the same timing as the keypad buzzer during entry delay, changing to 3 squawks per second for the final 10 seconds.

OFF: The siren does not activate during entry delay.

5 – Bell Squawk On Trouble

ON: When a trouble condition exists on the system, the siren squawks 2 times every 10 seconds (as per the keypad buzzer).

The siren is silenced when the keypad beeps are silenced (any key pressed on keypad).

OFF: The siren does not activate with a trouble condition.

6 – Not Used

7 – Exit Delay Termination

ON: The exit delay is reduced to 5 seconds once a Delay 1 zone is restored. Force-Arm Delay 1 type zones also end the exit delay.

OFF: The exit delay timer continues to count even after the delay zone is restored.

All audible options associated with the exit delay function are silenced until the time programmed for the exit delay has elapsed.

8 – Fire Bell Continues

ON: For all Fire type alarms, the siren sounds until an access code is entered to silence the alarm or disarm the system regardless of the time programmed for bell timeout.

OFF: For all Fire type alarms, the siren sounds for the length of Bell Timeout or until an access code is entered.

NOTE: Must be disabled for ULC installations.

[015] System Option 3

1 – [F] Key Enabled

ON: Pressing and holding the [F] key for 2 seconds triggers a Fire alarm.

OFF: The [F] key does not sound or report an alarm when pressed.

NOTE: Use only for residential fire installations.

2 – [P] Key Enabled

ON: When a valid [P] key alarm is generated, the keypad buzzer emits a series of 3 beeps to acknowledge the alarm and the siren sounds for the length of bell timeout.

OFF: When a valid [P] key alarm is generated, the keypad buzzer and the siren are silent, but the alarm is still transmitted (if programmed).

NOTE: Fire, Medical, and Panic key transmissions follow the partition 1 alarm/restore call direction options (Fire, Medical, and Panic key). The Fire, Medical, Panic keys operate even if keypad blanking and keypad lockout are active.

3 – Quick Exit

ON: When the system is armed, users may enter the [*][0] command to temporarily bypass a single Delay 1 or Delay 2 zone to exit the premises. Only one delay zone may be activated. Activity on another delay zone initiates the appropriate alarm sequence. If the delay zone is still open two minutes after the [*][0] command is entered, entry delay is initiated. If armed in the Stay mode, the automatic bypass on Stay/Away zones remains.

OFF: When the system is armed, users can not perform a quick exit using [*][0].

4 – Quick Arming /Function Key

ON: [*][0] arming and Stay/Away function keys may be used to arm the system without the entry of a valid access code.

OFF: [*][0] arming is not permitted. All arming functions require the entry of an access code to activate (including Stay/Away keys).

5 – Not Used

6 – Master Code Not User Changeable

ON: The master code (access code 01) may not be changed by the user and may only be programmed in Installer Programming.

OFF: The master code may be programmed by the user using the [*][5][Master Code] command. The master code may also be programmed in Installer Programming.

7 – Telephone Line Monitor Enable

ON: The TLM function is active and the system indicates a trouble condition when using the [*][2] View Trouble Conditions command.

OFF: The TLM function is deactivated and telephone line troubles are not indicated by the system.

NOTE: Must be ON for UL/ULC listed installations.

8 – Telephone Line Monitor Audible When Armed

ON: When the system is disarmed, a telephone line monitor trouble generates a trouble indication as described above. If the system is armed, a telephone line monitor trouble generates an audible alarm on the siren for the duration programmed for bell timeout or until an access code is entered to disarm.

OFF: Telephone line troubles generate a trouble indication, the Trouble LED illuminates, and the keypad buzzer beeps until a key is pressed.

[016] System Option 4

1 – AC Trouble Display

ON: If AC power fails, the condition is reported to the monitoring station and is indicated as a trouble condition on the system keypads.

OFF: If AC power fails, the condition is reported, but the Trouble light on the system keypads is off. The trouble is displayed in [*][2].

NOTE: Must be ON for UL/ULC listed installations.

2 – AC Trouble Light Flashes

ON: When AC power is lost, the Trouble light flashes in the base “Ready” and “Armed” mode within 30 seconds of power loss. When AC restores, the Trouble light stops flashing within 30 seconds. If enabled, this option overrides the AC display option.

OFF: When AC power is lost, the Trouble light illuminates but does not flash.

3 – Keypad Blanking

ON: If no keys are pressed for 30 seconds, all keypad lights except backlighting (if enabled) are shut off until the next keypress, entry delay, audible alarm or keypad buzzer condition.

Keypad function keys still operate when the keypad is blank, unless the function key is programmed to require an access code. Keypad Blanking While Armed overrides this feature. When a partition is armed and in alarm, entering a code to remove blanking silences the alarm and disarms the system.

OFF: The keypad lights remain ON at all times.

4 – Keypad Blanking Requires Code

ON: A valid access code must be entered before a blanked keypad can be used.

OFF: Pressing any key on a blanked keypad removes keypad blanking.

5 – Keypad Backlighting

ON: All keypads on the system have backlighting on at all times.

OFF: All keypads on the system have backlighting off.

6 – Power Save Mode

ON: If AC power fails, all keypad lights including backlighting are shut OFF. The keypad lights come back ON after a keypress, entry delay, audible alarm or keypad buzzer condition (except door chime). Keypad lights return to the off state after 30 seconds of inactivity.

OFF: If AC power fails, keypads do not go into power save mode.

7 – Bypass Display When Armed

ON: The Bypass status light is on if zones are bypassed when the system is armed.

OFF: The Bypass light is on only while the system is disarmed to indicate that zones on the system are bypassed. When the system is armed, the Bypass light is off.

The Bypass status light is on if Stay/Away zones are auto bypassed at the time of arming regardless of whether or not this option is enabled. This option only enables and disables manual bypass display.

8 – Keypad Tamper Enabled

ON: All keypads containing tamper switches generate tamper alarms and restores.

OFF: The tamper switches on all keypads do not generate tamper alarms.

NOTE: If this option is used, all keypads should be properly installed and secured (tamper restored) before enabling the option.

NOTE: Must be ON for UL/ULC commercial burglary listed installations.

[017] System Option 5

1 – Chime on Opening

ON: When a zone with the door chime attribute ON is opened, the system keypads and sirens (if enabled) sound door chime beeps.

OFF: When a zone with the door chime attribute ON is opened, the system keypads and sirens (if enabled) do not sound door chime beeps.

2 – Chime on Closing

ON: When a zone with the door chime attribute ON is closed, the system keypads and sirens (if enabled) sound door chime beeps.

OFF: When a zone with the door chime attribute ON is closed, the system keypads and sirens (if enabled) do not sound door chime beeps.

4 – Multi Hit

ON: Alarms from the same zone within the Burglary Verification Timer duration cause the police code or burglary verified to be

logged and transmitted. The number of zone trips required to create a confirmed alarm depends on the value of the programmable burglary verification counter.

OFF: Alarms from the same zone within the Burglary Verification Timer duration do not cause the police code or burglary verified to be logged and transmitted.

NOTE: This feature only applies to zones defined as Interior, Interior Delay, Interior Stay/Away, Instant Stay/Away, Delay Stay/Away, or Night Zones (PIR Zones).

5 – Late to Close

ON: Provides an audible warning if the alarm system has not been armed by a programmed time of day but does not arm the alarm system. The alarm system communicates and logs a Late to Close event at the end of the Auto-arm/Postpone pre-alert for each partition.

OFF: The alarm system will neither communicate nor log a Late to Close event at the time programmed for Auto-arm for each partition.

NOTE: If the Auto-arm toggle option is disabled, the Auto-arm Pre-alert still occurs when a time is programmed for that day (if enabled) and the event is logged and communicated. This option does not directly affect the functionality of Auto-arm. If Late to Close is enabled and Auto-arming is not, LCD keypads display “System Arming in Progress” during the Late to Close Pre-alert.

6 – Daylight Savings Time

ON: The alarm system adjusts between Daylight and Standard times according to the times programmed in System Timers ([005] options 001-002).

NOTE: Auto-arm and Test Transmissions should not be attempted between 0200 and 0300 hours, as they will be missed during a daylight savings clock adjust. Events programmed to occur between 0100 and 0200 will occur twice during a daylight savings clock adjust. Daylight Savings Time programming should not conflict with the Auto-arm and Test Transmissions programming.

OFF: The alarm system makes no automatic time adjustments for Daylight Saving time.

7 – Not Used

8 – Bell Squawk on Away Arm/ Disarm Only

ON: Bell Squawks are only heard when away arming, as well as when disarming from Away mode. This feature prevents the siren from activating when arming in stay and night modes.

OFF: Bell Squawks are heard during all types of arming and disarming.

NOTE: This option follows the “Bell Squawk Attribute” features if they are enabled.

[018] System Option 6

1 – Test Transmission Exception

ON: The alarm system does not send a test transmission if a transmission was sent to the receiver within the programmed interval as set in section [377] > [003] – Periodic Test Transmission Cycle on page 48.

OFF: Test transmissions are always sent at the programmed interval.

2 – Real-Time Bypass Reporting

ON: When a non-24-hour zone is bypassed in [*][1], the system immediately logs and communicates the bypass status of the zone.

Global Zones: 24-hour and non-24 hour zone bypasses are logged and communicated in real time. Non-24 hour zone unbypass events are generated when the last assigned partition is disarmed.

OFF: When a non 24-hour zone is bypassed in [*][1], the system logs and communicates the bypass status of the zone only after the partition is armed. This option is applied regardless of how zones are bypassed in [*][1], recall bypass group, clear all bypasses, bypass

open zones, bypass recall as well as other methods such as bypassing via ITv2 or DLS.

Global Zones: 24-hour zone bypasses are logged and communicated in real time. Non 24-hour zone bypass events are logged and communicated when armed. Non 24-hour zone unbypass events are logged and communicated when the last partition is disarmed.

3 – Not Used

4 – Not Used

5 – Keypad Buzzer Alarm

ON: The keypad buzzer activates with all bell activity for the selected partition.

OFF: The keypad buzzer only activates with alarms programmed to do so.

6 – Not Used

7 – Exit Delay Restart

ON: Opening a delay zone door after it has already been opened and closed during an exit delay restarts the exit delay timer. Further openings and closings do not restart the timer.

OFF: Delay zone openings and closings do not restart the exit delay.

8 – AC Fail Trouble Beeps

ON: System keypads beep when an AC trouble event occurs.

OFF: System keypads are silent during AC troubles.

[019] System Option 7

1 – Not Used

2 – Latching Troubles

ON: Troubles remain on the system until viewed via [*][2], even if they are restored. The trouble condition is cleared when the [#] key is pressed from the [*][2] menu. The Trouble LED turns off unless other troubles are present. The trouble is not cleared if the [*][2] menu times out before the [#] key is pressed.

OFF: Troubles are cleared once restored.

3 – Not Used

4 – Not Used

5 – Audible Bus Fault

ON: Corbus fault conditions activate the siren.

OFF: The siren does not activate when Corbus faults occur.

6 – Duress Codes

ON: The duress code attribute can be enabled/disabled from the [*][5] menu.

OFF: The duress code attribute is not accessible from the [*][5] menu.

7 – Temperature in Celsius

ON: Temperature is displayed in Celsius on LCD keypads.

OFF: Temperature is displayed in Fahrenheit on LCD keypads.

[020] System Option 8

3 – [*][8] Access While Armed

ON: This option ensures [*][8] installer programming is accessible from a keypad on a disarmed partition while other partitions on the system are still armed.

NOTE: For UL listed installations, this option must be disabled.

OFF: [*][8] installer programming is not available when any partition on the system is armed. All partitions must be disarmed and the siren must be off before [*][8] is accessible.

[021] System Option 9

1 – Not Used

2 – Not Used

3 – Auto-Arming Bypass

ON: All zones open at the end of the auto-arming exit delay are automatically force armed.

OFF: Only zones with the Force Arm attribute enabled are automatically force armed.

Force arming not used for UL/ULC listed installations (requires manual bypass).

4 – Not Used

5 – Not Used

6 – Not Used

7 – Not Used

8 – Audible Exit Delay for Stay Arming

ON: When the system is armed in Stay mode the exit delay is sounded by 1 beep every 3 seconds.

OFF: When the system is armed in Stay mode the exit delay is silent.

[022] System Option 10

1 – [F] Key Option

ON: When the [F] key is pressed, acknowledge beeps are only emitted from the keypad. The siren does not sound.

OFF: [F] key acknowledgment beeps are emitted from the keypad and the siren.

2 – Not Used

3 – Not Used

4 – Transmission Counter in Hours

ON: The alarm system sends a test transmission after the programmed number of hours in the test transmission cycle (Section [377], Option 003).

OFF: The alarm system sends a test transmission after the programmed number of days.

5 – Away to Stay Toggle

ON: The alarm system cannot be switched from Away to Stay mode by pressing the [Stay] function key.

OFF: The alarm system can be switched from Away to Stay mode by pressing the [Stay] function key.

7 – Trouble Beeps are Silent

ON: When a trouble is detected on the system, trouble beeps are not sounded at the keypad with the exception of Fire troubles.

OFF: When a trouble is detected on the system, trouble beeps are sounded at the keypad.

NOTE: This option must be OFF for UL Residential Fire applications.

8 – Keyswitch Arms in Away Mode

ON: Keyswitch arming arms the alarm system in away mode.

OFF: Keyswitch arming arms the alarm system in away mode if an entry/exit zone is violated during the exit delay.

[023] System Option 11

1 – Ready LED Flashes for Force Arm

ON: If a force arm capable zone is tripped, partition keypads flash the ready LED in the disarmed state instead of illuminating it

steadily. If a non-force arm capable zone is tripped, the ready LED turns off.

OFF: If a force arm capable zone is tripped, the Ready LED is illuminated steadily. If a non-force arm capable zone is tripped, the Ready LED turns off.

2 – Not Used

4 – Access Code Required for [*][1]

ON: When using the [*][1] Bypass Zones command, an access code must be input before zones are bypassed.

OFF: An access code is not required to bypass zones using [*][1].

5 – Access Code Required for [*][2]

ON: When using the [*][2] View Troubles command, an access code must be input before system troubles can be viewed.

OFF: An access code is not required to view troubles using [*][2].

6 – Access Code Required for [*][3]

ON: When using the [*][3] View Alarms in Memory command, an access code must be input before the alarm memory can be viewed.

OFF: An access code is not required to view alarms in memory using [*][3].

7 – Access Code Required for [*][4]

ON: When using the [*][4] Chimes command, an access code must be input before chimes can be toggled on and off.

OFF: An access code is not required to toggle chimes using [*][4].

8 – [*][6] Accessibility

ON: All user codes provide access to the [*][6] menu.

OFF: Only the master code provides access to the [*][6] menu.

[024] System Option 12

1 – 50Hz AC/60Hz AC

ON: Incoming AC power cycles at 50Hz.

OFF: Incoming AC power cycles at 60Hz.

NOTE: For UL/ULC listed systems, use only 60Hz setting.

2 – Crystal Timebase

ON: In situations where AC power input is unstable, the alarm controller's internal crystal is used as the time base.

OFF: The 50 or 60 Hz AC power input is used as the time base.

3 – AC/DC Inhibits Arming

ON: The system cannot be armed when an AC or DC trouble is present. This includes keypad, keyswitch, automatic, and DLS arming. An error tone is generated if the user attempts to arm the system during an AC/DC trouble.

NOTE: Displaying AC troubles ([016] option 2) is strongly recommended if this option is enabled.

OFF: The system can be armed, regardless of the presence of an AC or DC trouble and does not check the system battery upon arming.

4 – Tamper Inhibit Arming

ON: Tamper must be restored through Installer Programming before the system can be armed (including no-activity and keyswitch arming).

When this option is enabled, manual zone bypassing does not bypass the tamper or fault states (DEOL). This feature also applies to zone faults.

OFF: Tamper troubles do not latch and do not prevent arming.

5 – Real-Time Clock

ON: The alarm system sends a real-time clock request to the alternate communicator at 4:05pm or when system time is lost. The system uses the acquired time as system time.

OFF: The alarm system does not send a real-time clock request to the alternate communicator. Local time setting is used as the system time.

6 – Not Used

7 – Not Used

8 – DLS Disconnect

ON: All events except Periodic Test Transmission, Periodic Test with Trouble, and System Test are considered priority events. If DLS is active when an event occurs, the alarm system immediately terminates the connection in order to communicate the new events.

OFF: Only the following alarm type events terminate a DLS session :

- Zone alarms
- FMP key alarms
- Duress alarms
- Zone expander supervisory alarms
- 2-wire smoke alarms

[025] System Option 13

1 – European Dial

ON: Pulse dialing make/break ratio is 33/67.

OFF: Pulse dialing make/break ratio is 40/60.

2 – Force Dial

ON: The system dials the central station phone number even if no dial tone is present. The process is as follows:

1. Dial programmed phone number.
2. If no dial tone detected, terminate call.
3. Search for dial tone for 5 seconds.
4. If no dial tone detected, hang up for 20 seconds.
5. Search for dial tone for 5 seconds.
6. If no dial tone detected, dial anyway.

OFF: No attempt is made to contact the central station if dial tone is not present.

NOTE: Force Dial must be enabled for UL installations.

3 – Not Used

4 – Not Used

5 – I.D. Tone

ON: After the telephone number is dialed, the alarm system emits a tone (as specified by I.D. Tone Frequency option) for 500ms every two seconds to indicate that a digital equipment call is in progress.

OFF: I.D. tone is disabled.

6 – Tone Generated-2100Hz

ON: 2100 Hz I.D. tone.

OFF: 1300 Hz I.D. tone.

7 – 1 Hour DLS Window

ON: When DLS access is enabled ([*][6] option 5 ON), Installer Programming is accessible through DLS or the [*][8] menu only once during a 1-hour window.

OFF: When DLS access is enabled, Installer Programming is accessible through DLS or the [*][8] menu an unlimited number of times during a 6-hour window.

8 – FTC Audible Bell

ON: If a Failure to Communicate trouble is generated while the system is armed, the siren activates for the length of bell time-out or until the system is disarmed.

OFF: If a Failure to Communicate trouble is generated while the alarm system is armed, the siren does not activate but the keypad buzzer emits trouble beeps until a key is pressed.

[040] User Authentication

This feature enables the installer or master user to select one of two user authentication methods:

01 – User Code or Proximity Tag

The user can access the system by entering a valid code or by presenting a proximity tag.

02 – User Code and Proximity Tag

The user must enter a valid code and present a proximity tag whenever the system prompts for an access code. A proximity tag is not required to enter [*][8] Installer Programming.

[041] Access Code Digits

00 – 4-Digit Access Codes

User access codes are 4 digits long.

01 – 6-Digit Access Codes

User access codes are 6 digits long.

[042] Verified Events

Burglary Verified Counter

This option programs the number of zone activations required to verify an alarm. Valid entries are 000 to 255.

NOTE: Not for UL/ULC listed installations.

Burglary Verification Selection

Use this section to select one of the following burglary verification timer modes:

	Mode	Description
001	Police Code	The burglary verification timer operates in minutes.
002	Cross Zoning	The burglary verification timer operates in seconds. The first alarm in the sequence does not log or communicate the alarm or activate the bell.

5.3.8 Partition Setup

[151]-[158] Partition Auto-Arm/Disarm

Enter section 151 to 158 for partition 1 to 8 auto-arm/disarm configuration.

[001] – Partition Auto-Arming Times

Use this section to program the time of day a partition is automatically armed. A different auto-arming time can be programmed for each day of the week from Sunday to Saturday. Time is in 24-hour format (HH:MM) and valid entries are from 00:00 to 23:59.

Conditions that cancel auto-arming if enabled:

- Open zones (depending on the settings of the zone)
- AC/DC troubles
- System troubles
- Any valid disarming procedure - proximity tag, access code, disarm key, etc.

[002] – Partition Auto-Disarm Times

Use this section to program the time of day a partition is disarmed. A different auto-disarming time can be programmed for each day of the

week from Sunday to Saturday. Time is in 24-hour format (HH:MM) and valid entries are from 00:00 to 23:59.

NOTE: If entry delay is active at auto-disarm time, the system does not disarm. A valid disarming procedure is required by the user who initiated the entry delay.

[003] – Partition Auto-Disarming Holiday Schedules

Use this section to select a holiday schedule group.

See “[711]-[714] Holiday Schedules” on page 52 for more information.

[004] – Partition Auto-Arming Pre-Alert Timer

Use this section to program the duration of the auto-arm pre-alert. The system arms when the pre-alert timer expires. Valid entries are from 001 - 255 minutes.

If a valid access code is keyed in, this timer is postponed for the length of time programmed in Partition Auto-Arm Postpone timer (see below). The pre-alert timer can be postponed multiple times. Keyswitches and proximity tags can be used to cancel auto-arming.

[005] – Partition Auto-Arm Postpone Timer

Use this section to program the length of time the auto-arm pre-alert timer is postponed for. Valid entries are between 001 and 255 minutes. 000 cancels the postpone timer.

When the postpone timer expires, the Auto-arm pre-alert timer restarts (unless the partition is armed). If left uninterrupted the partition arms at the end of the pre-alert.

If a code is entered during the pre-alert, auto-arm cancel/postpone is logged and communicated and the postpone timer starts. When the postpone timer expires, pre-alert is sounded again and the cycle repeats. The Auto-arm may be postponed multiple times.

Conditions that cancel auto-arming:

- Open zones cancel arming / Auto Arm Force Arms Open Zones
- AC/DC Inhibit Arming
- Any valid disarming procedure – proximity tag, access code, disarm key

[006] – Partition No Activity Arming Timer

Use this section to program the duration of the No Activity timer. If this timer expires and no zones have been activated, the partition arms in Away mode (exit delay will not sound). When the timer expires, keypad buzzers activate for the time programmed in No Activity Arming Pre-Alert (see below).

The timer restarts when a delay type zone is restored. The timer does not restart when the system is disarmed. The timer stops if an un-bypassed zone is tripped, tampered or restored or with any keypad activity.

Separate No Activity Arming timers are provided for each partition. Valid entries are from 000 – 255 minutes. 000 disables this feature.

[007] – Partition No Activity Arming Pre-Alert Timer

Use this section to program the duration of the No Activity Arming pre-alert that sounds when the No-Activity timer for the partition expires. If any key is pressed or zone is activated or restored, the Auto-Arm pre-alert is aborted.

Valid entries are 000 - 255 minutes. 000 disables this feature.

[200] Partition Mask

A partition is a limited area of the premises which operates independently from the other areas. Partitions are added or removed from the system by applying or removing a partition mask.

[001] – Partition 1 to 8 Enable Mask

Select options 01-08 to enable or disable partitions.

Partition 1 is always enabled. Partitions 2 to 8 are selectable.

The number of available partitions depends on the model, as shown below:

Model	Zones	Partitions
HS2128	128	8
HS2064	64	8
HS2032	32	4
HS2016	16	2

[201]-[208] Partition Zone Assignment

Zones can be assigned to any partition. Global zones are zones assigned to more than one partition. A global zone is only armed when all assigned partitions are armed. The zone is disarmed when any of the assigned partitions is disarmed. By default, zones 1 through 8 are assigned to partition 1.

To assign zones to partitions, first select a partition [201]-[208], then select a zone group [001]-[016] and then a zone (1-8):

Zone Group	Zones	Zone Group	Zones
001	1-8	009	65-72
002	9-16	010	73-80
003	17-24	011	81-88
004	25-32	012	89-96
005	33-40	013	97-104
006	41-48	014	105-112
007	49-56	015	113-120
008	57-64	016	121-128

All zones assigned to a partition are supervised and operate according to the zone type programmed. If a zone is not assigned to a partition, it is not supervised and all activity on the zone is ignored by the system.

[300] Panel/Receiver Communication Paths

This section is used to select the path of communications between the alarm system and the central station. Paths can be established through either the alarm system's on-board Public Switched Telephone Network (PSTN) connection or through the alternate communicator (cellular or Ethernet) if equipped.

Paths to four receivers can be programmed using sections 001 - 004. The communications path for each receiver is defined by selecting one of the following six options:

[01] Phone Line

Events are communicated through the alarm system phone line programmed in section [301]. If Phone Line is selected for receiver 1, the phone number programmed in section [301] option [001] is used. If Phone Line is selected for receiver 2, the phone number programmed in section [301] option [002] is used, etc.

[02] Alternate Communicator Auto Routing (dual-path)

Selecting this option enables the alternate communicator to determine which communications path to use (Ethernet primary/secondary, cellular primary/secondary). See the alternate communicator manual for details.

[03] Alternate Communicator Receiver 1

Events are communicated through IP receiver 1.

[04] Alternate Communicator Receiver 2

Events are communicated through IP receiver 2.

[05] Alternate Communicator Receiver 3

Events are communicated through cellular receiver 1.

[06] Alternate Communicator Receiver 4

Events are communicated through cellular receiver 2.

To use PSTN as the communications path, program section [300] options 001 through 004 as [01] PSTN 1.

To use the alternate communicator to establish a communications path, program two of the receivers (section [300] options 001, 002, 003 or 004) as [03] and [04] for Ethernet, and two of the receivers as [05] and [06] for cellular.

[301] Phone Number Programming

Section [301] is used to program up to 4 telephone numbers used to communicate with the central station over PSTN.

[001] The phone number used to communicate with receiver 1

[002] The phone number used to communicate with receiver 2

[003] The phone number used to communicate with receiver 3

[004] The phone number used to communicate with receiver 4

All telephone numbers can be a maximum of 32 digits. Hexadecimal digits may be included to perform the following functions:

- HEX B ([*] [2] [*]) to dial "*"
- HEX C ([*] [3] [*]) - to dial "#"
- HEX D ([*] [4] [*]) - for an additional dial tone search, as required by PBX telephone systems.
- HEX E ([*] [5] [*]) - to insert a 2-second pause in the telephone number. This causes a static delay of 2 seconds before any additional dial tone search in a phone number.
- HEX F ([*] [6] [*]) - represents the end of the Phone Number (everything after F is ignored)
- Pressing [#] in these sections exits and saves the entire phone number.

The alarm system does not attempt to communicate using PSTN if no phone number is programmed.

[304] Call Waiting Cancel String

Use this section to program a string that, when pressed, disables call waiting on a phone line. Call waiting cancel is typically *70 in most areas. Dialing this string before a phone number disables call waiting for the duration of the call.

When this section is programmed and Call Waiting Cancel Options is ON (see [382] Communicator Option 3 on page 49), the alarm system dials this string before the phone number. This is only done on the first dialing attempt for each phone number.

This is a 6-digit field. Fill unused digits with Hex F.

5.3.9 Reporting

[307] Zone Reporting

Zone alarms, tampers and faults are transmitted to the central station using automatic contact ID or SIA formats. Reporting can be toggled on or off by zone using toggle options 1-6 in subsections 001-128. See Appendix A: Event Codes on page 98.

[308] Event Reporting

System events are transmitted to the central station using automatic contact ID or SIA formats. Reporting can be disabled by toggle options, programmable in the following sub-sections.

See Appendix A: Event Codes on page 98 for event code descriptions.

[001] Miscellaneous Alarm 1

The reporting codes in this section are sent to the Alarm & Restore call direction group.

1 – Duress Alarm

Sent when a duress code is used to perform any function on the system.

2 – Opening After Alarm

Sent during disarming if an alarm occurred during the previous armed period.

3 – Recent Closing Alarm

Sent if an alarm occurs within 2 minutes of the exit time expiration (for the first alarm only). Zone alarm transmission delays do not effect this reporting code.

4/5 – Zone Expander Supervisory Alarm/ Restore

Sent when the system loses communication with the following modules:

- Zone Expander Module
- Keypad with an on-board I/O configured as a zone

This reporting code is independent of the general system supervisory code sent to the maintenance call direction group.

6 – Burglary Verified

When using Cross Zoning, this reporting code is sent when two crossed zones go into alarm during the cross zone timer.

When using Police Code, this reporting code is sent when any two zones go into alarm. In both cases, only one reporting code is sent during each armed to armed period. Arming the system resets the zone alarm count for police code.

7 – Burglary Not Verified

When using Cross Zoning, this reporting code is sent if the cross zone timer is initiated by the first cross zone alarm, but is not verified by a second alarm before the timer expires.

8 – Alarm Cancel

Sent when a valid access code is entered during the communications cancel window. The central station acknowledges cancellation by providing a keypad ringback.

NOTE:**[011] Priority Alarms 1**

The reporting codes in this section are sent to the Alarm & Restore call direction group and apply to all system keypads.

1/2 – Keypad Fire Alarm-[F] Key Alarm/Restore

Sent when [F] Key alarms/restores occur.

3/4 – Keypad Medical Alarm-[M] Key Alarm/Restore

Sent when [M] Key alarms/restores occur. The keypad beeps 10 times when the medical alarm is successfully communicated to the alarm monitoring station.

5/6 – Keypad Panic Alarm-[P] Key Alarm/Restore

Sent when [P] Key alarms/restores occur.

7/8 – Auxiliary Input Alarm/ Restore

Sent when an alarm condition occurs/ is restored on PGM 2 (if configured as an input).

[021] Fire Alarms 1**3/4 – PGM 2 2-Wire Alarm/Restore**

When PGM 2 is programmed as a 2-wire smoke alarm, this reporting code is sent when an alarm condition is detected and when it is restored.

[101] Tamper Events**3/4 – Module Tamper/Restore**

This reporting code is transmitted when a system module enters a tamper alarm state and uses the System Tamper Alarm and Tamper Restore call direction.

5 – Keypad Lockout

Sent when a number of invalid access codes have been entered at a system keypad

This reporting code is sent to the system Tamper Alarm & Tamper Restore call direction group.

7 – Remote Lockout

Sent when a number of invalid access codes have been entered through DLS or Integration. This reporting code is sent to the system Tamper Alarm & Tamper Restore call direction group.

[201] Open/Close Events 1**1/2 – User Closing/Opening**

This reporting code is transmitted when a user arms/disarms a partition and uses the Opening and Closing call direction.

5/6 – Special Closing/Opening

This reporting code is transmitted when a partition is closed/opened using a keyswitch zone, downloading, quick arm ([*][0]), or Stay or Away function keys without an access code. The Opening and Closing call direction group is used for this reporting code.

[202] Open/Close Events 2**1 – Automatic Closing**

This reporting code is transmitted when a partition is automatically armed or schedule armed and uses the Opening call direction group.

3 – Auto Arm Cancellation/Postpone

This reporting code is transmitted when the automatic arm sequence is canceled during a pre-alert and uses the Opening and Closing call direction group.

[211] Miscellaneous Open/Close Events**1/2 – Late to Close/Open**

This reporting code is transmitted when a partition is not disarmed before the automatic disarm time, when the late to open option, ([*][6], option 9) is enabled. The Opening and Closing call direction group is used for this reporting code.

5 – Exit Fault

This reporting code is transmitted when an exit error occurs and entry delay expires before the system is disarmed. The Alarms and Restores call direction group is used for this reporting code.

If the delay zone that caused the exit error has cross zoning enabled, the exit fault and zone alarm transmits if a second zone is not tripped. The local alarm sequence follows cross zoning rules. The exit error is transmitted with the zone alarm that caused the fault, even if that zone has transmission delay enabled.

[221] Bypass Events**1/2 – Automatic Zone Bypass/Unbypass**

This reporting code is transmitted when a zone is automatically bypassed/unbypassed and uses the Opening and Closing call direction group.

03 – Partial Closing

This reporting code is transmitted if zones are manually bypassed at the time of arming or force armed by automatic arming. The Opening and Closing call direction group is used for this reporting code.

Automatic bypasses caused by stay arming do not cause transmission of this code.

[301] Panel Events 1**1/2 – Panel AC Fail Trouble/Restore**

This reporting code is transmitted when the alarm system AC supply fails or has been restored. A programmable delay applies to both the trouble and the restore. This reporting code is sent to the System Maintenance call direction group.

3/4 – Panel Low Battery Trouble/Restore

These reporting codes are transmitted when the panel battery voltage falls below 11.5VD or is restored. These reporting codes are sent to the System Maintenance call direction group.

5/6 – Panel Battery Absent Trouble/Restore

These reporting codes are transmitted when the panel battery voltage falls below 11.5VD or is restored. These reporting codes are sent to the System Maintenance call direction group and are transmitted when the panel battery is detected as absent.

[302] Panel Events 2**1/2 – Bell Circuit Trouble/Restore**

This reporting code is transmitted when a bell trouble condition occurs or is restored on the system. This reporting code is sent to the System Maintenance call direction group.

3/4 – Telephone Line Trouble and Restore

This reporting code is transmitted when an alarm controller TLM trouble occurs or is restored. The TLM trouble is communicated over an unaffected communication path if available.

This reporting code is sent to the System Maintenance call direction group.

5/6 – Auxiliary Power Supply Trouble/Restore

This reporting code is transmitted when an auxiliary voltage supply trouble occurs or is restored. This reporting code is sent to the System Maintenance call direction group.

NOTE: When the electronic fuse built in to the auxiliary power supply is tripped due to a short or high current draw, the alarm system must be powered down then back up to reset the fuse.

[305] Panel Events 5**3/4 – PGM 2 2-Wire Trouble/Restore**

This reporting code is transmitted when a trouble condition on PGM 2, configured as 2-wire smoke, occurs or is restored. This reporting code is sent to the System Maintenance call direction group.

[311] Maintenance Events 1**1/2 – RF Jam Trouble/Restore**

Sent when RF jam troubles occur/are restored. The following events cause RF jam troubles:

- Wireless repeater jamming
- RF jam

3/4 – Fire Trouble/Restore

Sent when a low sensitivity, tamper or internal fault condition/restore is detected on a wireless smoke detector.

5 – Cold Start

Sent when power is restored to the alarm system after total power failure. The code is sent after 2 minutes to allow the alarm controller to stabilize.

6 – Delinquency

When the Delinquency option is off (page 45), this code is transmitted if the alarm system has not been armed for the number of days programmed in the Delinquency Transmission Delay (page 48).

When the Delinquency option is on, this code is transmitted when no zone activity has been detected on the system for the number of hours programmed in Delinquency Transmission Delay.

[312] Maintenance Events 2**1/2 – Installer Lead In/ Lead Out**

The Installer Lead In and Lead Out reporting codes are sent when the alarm system enters and exits Installer Programming respectively.

When Installer Programming is automatically exited after PC-Link is activated, the Installer Lead Out event is not communicated until after the DLS session is complete.

3/4 – DLS Lead In/Lead Out

The DLS Lead In reporting code is sent:

- after DLS communication has been successfully established, but before the alarm system calls back the downloading computer. This code is only transmitted when call back is enabled
- on user-initiated call-up.

The DLS Lead Out reporting code is sent when a DLS session is successfully ended.

NOTE: If DLS is terminated by an alarm, the DLS Lead Out reporting code is not transmitted.

5/6 – SA Lead In/Lead Out

The SA Lead In reporting code is sent:

- after SA communication has been successfully established, but before the alarm system calls back the downloading computer. This code is only transmitted when call back is enabled.
- on user-initiated call-up.

The SA Lead Out reporting code is sent when an SA session is successfully ended. The SA Lead Out reporting code is still sent if the session is terminated by an alarm.

7 Event Buffer 75% Full

Sent when the event buffer reaches a threshold of 75% without being uploaded.

[313] Maintenance Events 3**1/2 – Firmware Update Begin/was Successful**

Sent when a remote firmware update is initiated/ is successfully completed.

3 – Firmware Update Fail

Sent after an unsuccessful remote firmware update.

[314] Maintenance Events 4**1/2 – Gas Trouble/Restore****3/4 – Heat Trouble/Restore****5/6 – Freeze Trouble/Restore****7/8 – Probe Disconnected Trouble/Restore****[321] Receiver Events****2/4/6/8 – Receiver 1 - 4 FTC Restore**

Sent when the panel detects an FTC trouble.

[331] Module Events 1**1/2 – Module AC Trouble/Restore**

This reporting code is transmitted when a module's AC supply fails or has been restored. A programmable delay applies to both the trouble and the restore. This reporting code is sent to the System Maintenance call direction group.

3/4 – Module Battery Trouble/Restore

These reporting codes are transmitted when a module's battery voltage falls below 11.5VDC or is restored. These reporting codes are sent to the System Maintenance call direction group.

5/6 – Module Battery Absent/Restore

These reporting codes are transmitted when a module's battery is detected as absent or restored. These reporting codes are sent to the System Maintenance call direction group.

[332] Module Events 2**1/2 – Module Low Voltage Trouble/Restore**

Sent when module voltage drops below acceptable levels or is restored.

3/4 – Module Supervisory Trouble/Restore

Sent when communication with a module is lost or restored.

5/6 – Module Aux Trouble/Restore

Sent when a high current output module or power supply module experiences an auxiliary voltage supply trouble.

[335] Module Events 5**1/2 – Output 1 Fault/Restore**

This reporting code is sent when the first output on the high-current output expander module goes into fault (open or short) or is restored. Only the first output on the high-current expander module is supervised.

[351] Alternate Communicator 1**1/2 – Alt. Comm Communications Fault/Restore**

Sent when the system loses or restores communications with the alternate communicator.

3/4 – Not used**5/6 – Not used****7/8 – Alt. Comm Radio/SIM Failure/Restore**

Sent when the alternate communicator experiences trouble or restore of the radio/SIM.

[352] Alternate Communicator 2**1/2 – 1/2 – Alt. Comm Network Fault/Restore**

Sent when the alternate communicator loses or restores communication with the network.

3/4 – Alt. Comm Low Signal Trouble/Restore

Sent when the alternate communicator experiences a network low signal trouble or restore.

5/6 – Alt. Comm Ethernet Trouble /Restore

Sent when the alternate communicator detects a network absent condition or DHCP failure or restore.

7/8 – Alt. Comm Lockout Trouble/Restore

Sent when the alternate communicator detects a SIM lock trouble or network lock trouble or when either condition is restored.

[354] Alternate Communicator 4**Receiver 1 to 4 Trouble and Restore**

Sent when the alternate communicator detects a trouble or restore condition on receiver 1-4.

1/2 – Receiver 1 Trouble/Restore**3/4 – Receiver 2 Trouble/Restore****5/6 – Receiver 3 Trouble/Restore****7/8 – Receiver 4 Trouble/Restore****[355] Alternate Communicator 5****Receiver 1 to 4 Supervision Failure and Restore**

Sent when the alternate communicator detects a supervision trouble for the Ethernet receiver (1, 2) or the GPRS receiver (3, 4).

1/2 – Receiver 1 Supervision Failure/Restore**3/4 – Receiver 2 Supervision Failure/Restore****5/6 – Receiver 3 Supervision Failure/Restore****7/8 – Receiver 4 Supervision Failure/Restore****[361] Wireless Device Events****1/2 – Wireless Device AC Failure/Restore**

These options are used to enable wireless device AC failure/restore reporting codes. These reporting codes are sent when a wireless device experiences an AC failure/restore.

3/4 – Wireless Device Low Battery Trouble/Restore

These options are used to enable wireless device low battery trouble/restore reporting codes. These codes are sent when a wireless device experiences a low battery trouble/restore.

5/6 – Wireless Device Fault/Restore

These options are used to enable wireless device fault/restore reporting codes. This reporting code is sent when a wireless device experiences a supervisory fault.

[401] System Test Events**1/2 – Walk Test Start/End**

Sent when installer walk test is initiated and terminated.

These reporting codes are in addition to the alarm reporting codes for the zones that are tripped during the walk test period, if configured in section [382] Communicator Option 3 on page 49.

3 – Periodic Test Transmission

Sent when the test transmission programmed in section [401] System Test Events on page 46 occurs.

4 – Periodic Test Transmission with Trouble

Sent when any of the following trouble conditions are present during a periodic test transmission:

- Fire Zone Trouble
- Battery Trouble
- Fire Zone Alarm (2-Wire Smoke)
- Aux Trouble
- Fire Trouble
- Bell Trouble
- Fire Tamper/Low Sensitivity (WLS)
- Module Supervisory
- Fire Zones Bypassed
- Ground Fault
- Fire Supervisory (Wireless)
- TLM Trouble
- AC Trouble
- FTC Trouble

This reporting code is sent in place of the standard Periodic Test Transmission code.

5 – System Test

Sent when a manual system test is performed ([*][6][Master Code][04]).

5.3.10 System Communications

The programming options in this section are used to configure communications between the alarm system and the central station.

[309] System Call Direction

Use this programming option to select the central station receivers that system events are communicated to. A system event can be sent to multiple receivers.

[001] Maintenance Events/Restores (all troubles except tampers)

These options control which receiver paths are enabled for maintenance events. To assign a maintenance event to a receiver, select from the following list:

- [01] Receiver 1
- [02] Receiver 2
- [03] Receiver 3
- [04] Receiver 4

[002] Test Transmissions

These options control which receiver paths are enabled for test transmission events. To assign a test transmission event to a receiver, select from the following list:

- [01] Receiver 1
- [02] Receiver 2
- [03] Receiver 3
- [04] Receiver 4

[310] Account Codes

These programming sections are used to set the system and partition account codes.

[000] System Account Code

The system account code is used to identify the alarm system when communicating system events to the central station. The system account code can be either 4 or 6 digits long. Program a 6-digit code only when using the SIA reporting format. SIA uses this account code for all partitions and system events. All other reporting formats use a 4-digit system account code to report system maintenance (e.g., low battery, zone fault) and test transmission events. To program a 4-digit code, add FF to the last two digits.

[001]-[008] Partition Account Codes

Use these sections to program account codes for each partition.

When using formats other than SIA, these account codes identify the alarm system to the central station when communicating partition-specific events.

NOTE: The system will not communicate if the account code is not programmed. When this condition occurs, Account Code Not Programmed is briefly displayed on the keypad when exiting Installer Programming mode.

NOTE: If no phone numbers are programmed, the error message does not occur.

[311]-[318] Partition Call Directions

Use this programming option to select the central station receivers that partition events are communicated to. Call directions can be programmed for each partition. Each event can be sent to one of four receivers.

[001] Alarm/ Restore

These options control which receiver paths are enabled for Partition 1-8 Alarm and Restore event reporting codes.

To assign an event to a receiver, select one of the following options:

- [01] Receiver 1
- [02] Receiver 2
- [03] Receiver 3

[04] Receiver 4

[002] Tampers (Including System Tampers)/ Restore

These options control which receiver paths are enabled for Partition 1-8 Tamper and Restore event reporting codes.

To assign an event to a receiver, select one of the following options:

- [01] Receiver 1
- [02] Receiver 2
- [03] Receiver 3
- [04] Receiver 4

[003] Openings/ Closing

These options control which receiver paths are enabled for Partition 1-8 Opening and Closing event reporting codes. To assign an event to a receiver, select one of the following options:

- [01] Receiver 1
- [02] Receiver 2
- [03] Receiver 3
- [04] Receiver 4

[350] Communicator Formats

Use this programming option to assign a communicator format to each of the four receivers programmed in section [301]. The available communicator formats are as follows:

03	DTMF Contact ID
04	SIA FSK

To assign a communications format, select a receiver (option [001]-[004]) then enter the 2-digit code corresponding to the chosen format. For detailed descriptions of each format, see page 98.

[377] Communication Variables

[001] – Swinger Shutdown

Alarms/Restores

This value defines the number of communication attempts made for alarm/restore events, per zone, before the zone goes into swinger shutdown. Valid entries are 000 to 014. For CP-01, entries are from 001-006.

Once the programmed number of alarm/restore events have been communicated, no further alarm/restore events for the zone are communicated until swinger shutdown is reset. The last restore event is not communicated until swinger is cleared. For example, if the swinger shutdown limit for zone alarms is set to [003], the cycle is as follows: alarm/restore, alarm/restore, alarm...8 hours or arm/disarm...restore.

The bell output is not activated for alarms on zones that have exceeded the swinger shutdown counter limit. Swinger shutdown on global zones log once to the system area.

NOTE: Swinger shutdown resets on all partitions when any partition on the system is armed or disarmed, or every day at midnight. For CP-01, swinger shutdown is restored after 8 hours of inactivity.

Once reset, the alarm system communicates normally.

NOTE: The event buffer can follow swinger shutdown if enabled.

Tampers/Restores

This value defines the number of times the same system tamper event occurs before going into swinger shutdown. Valid entries are 000 to 014.

Maintenance Troubles/Restores

This value defines the number of times the same system Maintenance (trouble) type event occurs before going into swinger shutdown. Fire troubles follow the Maintenance Swinger Shutdown variable.

[002] – Communication Delays**Transmission Delay (seconds)**

This value defines the delay before an alarm is transmitted.

The delay is for zones which have the Transmission Delay attribute enabled. Valid entries are from 000 to 255 seconds (0-45 seconds for CP-01). Each partition shares the same active timer. If the delay is already active due to an alarm on a different partition, any new activity on another partition does not restart the communications delay timer.

Burglary verified events are postponed until after the transmission delay expires. When a valid disarming procedure is used while the transmission delay is active, a communications canceled message is briefly displayed on the keypad when the delay is canceled.

For UL/ULC listed installations, the entry delay plus communication delay cannot exceed 45 seconds.

AC Failure Communication Delay (minutes or hours)

This value determines the delay before an AC failure or AC restore is reported. The AC failure or restore is still displayed immediately.

Valid entries are from 000 to 255 minutes/hours (max. 180 minutes for UL commercial installations). Selection of minutes or hours for the delay is set in section [382] Communicator Option 3 on page 49.

NOTE: If AC Failure Communications Delay is programmed as 000, the AC Failure Trouble reporting code is sent immediately.

NOTE: For ULC commercial fire monitoring, the setting shall be 180 minutes.

TLM Trouble Delay

Use this section to program the number of valid checks (3 second intervals) required before a telephone line trouble is generated. Valid entries are 000-255 for trouble annunciation and transmission delays of 3 to 765 Seconds (12.75 Minutes).

Wireless Zone Low Battery Transmission Delay (in days)

When a zone reports a low battery condition, the trouble is indicated immediately on the keypad, but the transmission to the monitoring station is delayed by the number of days programmed in this section. If the low battery condition is not corrected before the delay expires, the low battery condition is transmitted. The Low Battery Restore transmission is not delayed.

Delinquency Transmission Delay

The value in this section determines the period of time before a delinquency event is generated.

Delinquency delay is measured in days if using closing delinquency or hours if using activity delinquency as programmed in section [311] option 6. Valid entries are [001]-[255] or [000] to disable.

Communications Cancel Window

After the transmission Delay expires and a zone alarm is transmitted, the communications cancel window begins.

If an access code is entered during this window, a reporting code is communicated and logged. If the window expires without an access code entry or a code is entered after the window, the communications canceled event is not logged or communicated.

NOTE: The cancel window does not start after an [F][M][P] key alarm.

[003] – Periodic Test Transmission Cycle

This value determines the period between test transmissions. Valid entries are [000]-[255]. Whether this interval is in hours or days is determined by section [022], option 4.

NOTE: For UL/ULC listed installations, the test interval is 24 hours.

[004] – Periodic Test Transmission Time of Day

Enter a 4-digit time using the 24-hour clock format (HH:MM).

Valid entries are from 00 to 23 for the hours (HH) and 00 to 59 for the minutes (MM).

To disable the test transmission time of day, enter [9999] in this section.

NOTE: This time should not be set for the same time as Day Light Savings time.

[011] – Maximum Dialing Attempts

This section is used to program the number of dialing attempts made to each telephone number when communicating. Valid entries are 001-005.

For UL/ULC listed installations, this value must be set to 005.

[012] – Delay Between PSTN Attempts

This programmable timer adds a delay before the next call is attempted over PSTN. Valid entries are 000-255, with a default of 3 seconds (making a total of 8 seconds: 3-second delay + standard 5-second dial tone search).

[013] – Delay Between Force Attempts

This programming option is used to set the length of time the alarm system waits between the first dialing attempt and the force dial attempt.

Valid Entries are 001-255 seconds. Default is 020.

[014] – Post Dial Wait for Handshake

This option is used to program the length of time the communicator waits for a valid initial handshake from the receiver after dialing the programmed telephone number. Valid entries are 001 to 255 seconds.

NOTE: Maximum 45 seconds for UL installations.

[015] – T-Link Wait for Ack

This option is used to program the length of time the communicator waits for an acknowledge after transmitting via IP/GS. Valid entries are 001 to 255. Default is 60 seconds.

[016] – IP/Cellular Fault Check Timer

This section is used to program the number of poll commands sent without valid poll responses before the alarm system generates a trouble condition. The checks occur at 3-second intervals.

Valid entries are 003-255 for trouble annunciation and transmission. The trouble restore is not delayed.

[380] Communicator Option 1**1 – Communications Enabled/Disabled**

ON: (Default) The system communicator is enabled and all events with reporting codes are reported to the monitoring station. Refer to the Telephone Number, Reporting Code and Call Direction programming sections.

OFF: The system communicator is disabled and no events are reported to the monitoring station.

NOTE: Disabling the communicator clears all FTC troubles.

2 – Restore On Bell Timeout

ON: Zone restore reporting codes are not transmitted until the zone has been restored and the bell timeout has expired. If the zone is not restored when the bell cut-off time expires, the restore is transmitted when the zone physically restores or when the system is disarmed.

NOTE: 24-hour zones will not restore until the zone is physically restored

OFF: Zone restore reporting codes are transmitted when the zone is physically restored. If zones are still active when the system is disarmed, the restore codes are transmitted when the system is disarmed.

3 – Pulse Dialing

ON: The alarm system dials telephone numbers using pulse (rotary) dialing.

OFF: The alarm system dials telephone numbers using DTMF (dual tone multi-frequency) touch-tone dialing.

4 – Pulse Dial after 5th Attempt

ON: If DTMF dialing is enabled, the alarm system dials telephone numbers using DTMF dialing for the first 4 attempts. If unsuccessful, the alarm system switches to pulse (rotary) dialing for the remaining attempts.

OFF: If DTMF dialing is enabled, the alarm system dials telephone numbers using DTMF dialing for all dialing attempts.

5 – Parallel Communications

ON: Parallel communications is enabled. The alarm system attempts to communicate through all available receivers at the same time. Once acknowledgment is provided by any of the receivers, the alarm system communicates the next event. If more than one receiver is configured for PSTN, the backup procedure described below is followed.

OFF: Parallel communications is disabled. If receiver 1 fails, the alarm system attempts to communicate with the next available receiver (2-4) in sequence.

NOTE: See [384] Communicator Backup Options on page 50 for communicator backup programming.

6 – Alternate Dial

ON: After each failed dialing attempt, the communicator switches to the next backup receiver in the sequence:

- Receiver 2 backs up Receiver 1
- Receiver 3 backs up Receiver 2
- Receiver 4 backs up Receiver 3

This continues until communication is successful or the sequence has been repeated 5 times (depending on the number of maximum dialing attempts). If all 5 attempts fail, an FTC trouble for the primary phone number is logged. All backup receivers automatically use the same call directions and format as the primary receiver.

OFF: After 5 failed attempts to communicate with the primary receiver, the communicator switches to the next backup receiver in the sequence and makes up to 5 more attempts. This continues until communication is successful or until all backup receivers fail, at which point an FTC trouble for the primary number is logged.

7 – Reduced Dialing Attempts

ON: If a TLM trouble is present, the alarm system immediately attempts to call the backup receiver. This option only applies to PSTN. Backup communications must be enabled. See option 5, Parallel Communications.

A minimum of two receivers should be enabled for this feature to operate as intended.

OFF: If a TLM trouble is present, the number of dialing attempts programmed shall be attempted before moving on to the backup receiver.

8 – Activity Delinquency

ON: Inactivity on a partition for a programmed duration (section [377] option 002, Delinquency Transmission Delay) transmits a Delinquency code to the central station. This option is designed to help monitor the elderly or disabled. The counter is reset if zone activity is detected or if the system is armed. The Delinquency Transmission Delay is in hours.

NOTE: Delinquency code is not transmitted while Away armed. Activity on bypassed zones does not affect this timer.

OFF: The Delinquency reporting code is sent when the programmed number of days for delinquency (section [377]) expires without the partition being Armed. Once the code is sent, the timer is not started

again until the partition has been armed. Each day programmed in the counter represents one day plus the time it takes for the partition to reach midnight. To disable this feature, program 000 in section [377]>[002] option 5.

[381] Communicator Option 2

1 – Keypad Ringback

ON: When the Opening After Alarm reporting code is successfully transmitted to a programmed telephone number, the keypad emits a series of 8 beeps to confirm to the occupant that the code was sent and received. Ringback occurs for each successfully reported Opening After Alarm code.

OFF: When the Opening After Alarm reporting code is successfully transmitted to a programmed telephone number, the keypad does not sound ringback.

2 – Bell Ringback

ON: When the Opening After Alarm reporting code is successfully transmitted to a programmed telephone number, the siren emits a series of 8 squawks to confirm to the occupant that the code was sent and received. Ringback occurs for each successfully reported Opening After Alarm code.

OFF: When the Opening After Alarm reporting code is successfully transmitted to a programmed telephone number, the siren does not sound ringback.

4 – Closing Confirmation Enabled/Disabled

ON: When a Closing reporting code is successfully transmitted to a programmed telephone number, the keypad emits a series of 8 beeps to confirm to the occupant that the Closing Code was sent and received.

OFF: No keypad ringback is generated when a Closing reporting code is successfully transmitted.

8 – Communications Priority Enabled/Disabled

ON: Events follow the priority level indicated in ULC-S559 standard.

Concurrent event communications are prioritized in the following order (highest to lowest priority):

1. Fire Alarms
2. CO Alarm
3. Fire Supervisories
4. Fire Trouble
5. Monitoring (Medical, Panic or Security)
6. All others such as restorals for fire alarms, supervisories, troubles and monitoring.
7. FTC'ed events

OFF: Events are communicated in the order they occur.

NOTE: Must be ON for ULC commercial fire monitoring listed installations.

[382] Communicator Option 3

1 – Not Used

2 – Walk Test Communications

ON: Zone alarms that occur during Walk Test are communicated if programmed to do so.

OFF: Zone alarms during Walk Test are not communicated. FMP key alarms are still communicated.

4 – Call Waiting Cancel

ON: The call waiting cancel string (page 43) is used on the first attempt to dial each phone number. It is not used on any further dialing attempts.

OFF: The call waiting cancel string is not dialed.

5 – Alternate Communicator Enable/Disable

ON: The system communicates using the alternate communicator. All related programming options, reporting and supervision are enabled when programmed via PC-Link2.

OFF: The alternate communicator and all associated programming functionality are disabled. The auto time update feature is disabled.

NOTE: If alternate communicator troubles are present when the communicator is disabled, the troubles are logged, communicated, and cleared from [*][2]. When the communicator is re-enabled, the trouble conditions are again logged, communicated and indicated in [*][2].

6 – AC Failure Communication Delay in Hours/Minutes

ON: The AC failure communication delay (section [377]>[002] option 2) is programmed in hours.

OFF: The AC failure communication delay is programmed in minutes.

8 – Not Used

[383] Communicator Option 4

1 – Phone Number Account Code

ON: The account code communicated to the central station follows the phone number the event is programmed to communicate on (programmed in section [310] Account Codes on page 47):

- Receiver 1 all events will follow partition 1 account code
- Receiver 2 all events will follow partition 2 account code
- Receiver 3 all events will follow partition 3 account code
- Receiver 4 all events will follow partition 4 account code

OFF: Events follow the account code assigned to each partition when communicating.

NOTE: This feature only works with CID

2 – 4 or 6-Digit System Account Code

ON: The programmable account code in section [310][000] is 6 digits long (used for SIA format).

OFF: The programmable account code in section [310][000] is 4 digits long.

5 – Communicate FTC Events

ON: The alarm system communicates FTC (failure to communicate) events. The FTC Trouble/Restore reporting code transmission follows the call direction the events are assigned to.

OFF: FTC events are not communicated. FTC Trouble/Restore reporting codes are communicated to the Maintenance call direction group after the next successful communication.

6 – Not used

[384] Communicator Backup Options

2 – Receiver 2 Backup Option

ON: Receiver 2 backs up Receiver 1. Receiver 2 is only used if an FTC event is detected on Receiver 1.

Receiver 2 uses the same format programmed for Receiver 1.

OFF: Receiver 2 is independent and will communicate if a number and format are programmed.

3 – Receiver 3 Backup Option

ON: Receiver 3 backs up Receiver 2. Receiver 3 is only used if an FTC event is detected on Receiver 2.

Receiver 3 uses the same format programmed for Receiver 2.

OFF: Receiver 3 is independent and will communicate if a number and format are programmed.

4 – Receiver 4 Backup Option

ON: Receiver 4 backs up Receiver 3. Receiver 4 is only used if an FTC event is detected on Receiver 3.

Receiver 4 uses the same format programmed for Receiver 3.

OFF: Receiver 4 is independent and will communicate if a number and format are programmed.

5.3.11 DLS Programming

Downloading allows programming of the entire alarm system via a computer. All functions and features, changes and status, such as trouble conditions and open zones, can be viewed or programmed by downloading.

The following downloading options are available:

- 6-hour window on start up: When the alarm system is powered up, downloading access is available for 6 hours. This provides the option of downloading without having to complete any keypad programming.
- Double call method: The installer initiates a downloading window by calling the alarm system, hanging up, then calling back again.
- User enabled DLS window: The user initiates a downloading window using [*][6][Master code][05]. This can be a 6-hour window where the installer initiates and terminates downloading as many times as necessary, or it can be a 1-hour, 1 use window.
- User initiated call-up: the user can initiate a downloading session using [*][6][Master Code][06].
- On-site downloading using PC-Link: The installer connects a computer directly to the alarm system to perform on-site downloading.
- Auto event buffer upload: The Event buffer is automatically uploaded to the DLS/SA computer when it reaches 75% full.

Refer to the DLS/SA programming sections described below for configuration options.

[401] DLS/SA Options

1 – Double Call

ON: Calls for downloading or SA are answered if a successful double call routine is detected. Have the downloading computer call the system and let the telephone line ring once or twice. After 1 or 2 rings, hang up. If called back within the duration of the double call timer (section [405]), the alarm system answers on the first ring.

OFF: Incoming calls are not answered using the double call routine unless the user enables the DLS window.

NOTE: This feature controls the DLS window for PSTN connections only.

2 – User Enables/Disables DLS

ON: The [*][6][Master Code][05] command enables a 6-hour window where, on power-up, downloading calls are answered if a successful double call routine is detected.

OFF: The user cannot enable a downloading window.

3 – DLS CallBack

ON: When a downloading call is answered, both the computer and the alarm system hang up. The alarm system then calls the downloading computer back using the downloading telephone number and begins the DLS session.

NOTE: Disable this option if using more than one downloading computer.

OFF: After successful validation, the downloading computer gains immediate access to the alarm system.

4 – User Call-Up

ON: A single call attempt can be made to the downloading computer using [*][6][Master Code][06].

OFF: [*][6][Master Code][06] does not allow initiation of a downloading session.

6 – Panel Call-Up and Baud Rate

ON: When a DLS/SA session is initiated by the user, the initial header is sent at 300 baud.

OFF: When a DLS/SA session is initiated by the user, the initial header is sent at 110 baud. The alarm system will then switch to 300 baud in order to receive the response from the DLS computer.

7 – Alternate Communicator DLS

ON: When this feature is enabled, the alarm system responds to DLS requests through the alternate communicator IP or cellular paths at any time, regardless of whether the DLS window is active or not.

However, if a pre-defined number of consecutive incorrect DLS access codes is detected (See “Remote Lockout DLS” on page 37) while trying to establish a connection, alternate communicator DLS access is locked out until the next hour roll-over.

OFF: When this feature is disabled, the alarm system only responds to DLS requests through the alternate communicator IP or cellular paths when the DLS window is active.

The DLS/SA window is active following a power up or if enabled using [*][6][maser code][05] (System Service/DLS).

NOTE: This option controls DLS over alternate communicator only.

[402] PSTN DLS Phone Number Programming

This section is used to program the telephone number for DLS downloading over PSTN. This phone number is used for User Call Up, Periodic DLS and DLS Call back. If no phone number is programmed, the system attempts to use the alternate communicator IP path (if configured).

The maximum number length is 32 digits.

[403] DLS Access Code

This 6-digit hexadecimal code allows the alarm system to confirm the identity of the downloading computer.

If the code does not match the computer, the alarm system does not allow DLS access.

Once a DLS connection is established, the operator is allowed three attempts to enter the correct access code. If these attempts are unsuccessful, the alarm system disconnects and a new attempt must be made.

If cellular or IP paths are used for the DLS connection, a pre-programmed number of unsuccessful attempts causes a 1-hour DLS lockout. Number of attempts is programmed in section [012].

[404] DLS/SA Panel ID

This 10-digit hexadecimal code identifies the alarm system to the downloading computer.

[405] PSTN Double Call Timer

Use this section to program the amount of time that can elapse between the first and second call when using Double Call downloading. Valid entries are 001 to 255 (seconds).

[406] PSTN Number of Rings to Answer On

The value in this section determines how many rings are required in order to establish a DLS connection. Default value is 000 rings. Valid entries are [000]-[020].

NOTE: If Double-Call option and Number of Rings to Answer are enabled, either one will work depending on how the installer calls the alarm system.

[407] SA Access Code

This 6-digit hexadecimal code allows the alarm system to confirm the identity of the downloading computer.

If the code does not match the computer, the alarm system does not allow uploading/downloading.

Programming the access code as FFFFFFFF disables SA access.

Once an SA connection is established, multiple attempts to input the correct downloading access code (programmed in [012]) is allowed.

The operator is allowed three attempts to enter the correct access code. If these attempts are unsuccessful, the alarm system disconnects and a new attempt must be made.

If cellular or IP paths are used for the SA connection, up to 6 unsuccessful attempts causes a 1-hour SA lockout (See “Remote Lockout DLS” on page 37).

[410] Automatic DLS/SA Options

[001] – Auto DLS Options

1 – Periodic DLS

ON: Upload/download commands programmed in advance (batch files) are periodically downloaded to the DLS computer.

See below to program the times and days when this occurs.

NOTE: The computer must be waiting for a call in order for this feature to work.

OFF: The alarm system does not periodically call the downloading computer.

3 – DLS on Event Buffer %75 Full

ON: The alarm system automatically calls the downloading computer with DLS when the Event Buffer 75% full event occurs.

This option is independent of the actual transmission of the Event Buffer 75% full event (the event does not need to be transmitted for the panel to perform the automatic upload).

The panel first communicates the Event Buffer 75% full event (if enabled) using either PSTN or IP and then performs the automatic download.

OFF: The alarm system does not automatically call the downloading computer when the Event Buffer 75% full event occurs.

5 – SA on Event Buffer %75 Full

ON: The alarm system automatically calls the downloading computer with SA when the Event Buffer 75% full event occurs.

This option is independent of the actual transmission of the Event Buffer 75% full event (the event does not need to be transmitted for the panel to perform the automatic upload).

The panel first communicates the Event Buffer 75% full event (if enabled) using either PSTN or IP and then performs the automatic download.

OFF: The alarm system does not automatically call the downloading computer when the Event Buffer 75% full event occurs.

[002] Periodic DLS Days

This section is used to program the number of days between periodic DLS downloads. Valid entries are from 001 to 255 days.

[003] Periodic DLS Time

This section is used to program the time of day periodic DLS download takes place. Time is in 24-hour format and the default is 00:00 (midnight).

[007] Delay Call Window

This section is used to define a user call-up window. Users can only initiate a downloading session during this window. When a value is entered in this section, the setting in Periodic DLS Time (see the option above) is overridden. When 00:00 is entered in this field, the alarm system initiates a DLS call at the time programmed in Periodic DLS Time. Start and end times must be defined using 24-hour format (e.g., 13:30).

5.3.12 Schedule Programming

The sections described below are used for programming scheduled operating times for PGM command outputs 1-4.

[601]-[604] Programming Schedule 1-4

These sections are used to define schedules for PGM command outputs 1-4 operation. When a PGM is configured for timed output operation, it activates at the programmed start time and will turn off after the programmed duration. For example, 5 seconds.

Each schedule contains 4 intervals, for PGMs 1-4. Within each interval, a start time and end time can be programmed for each day of the week. Holiday schedules 1-4 can also be selected.

[101]-[102] Set Start Time/ End Time

Used to program the time of day the schedule interval begins and ends. (HH:MM). Valid entries are 0000-2359 and 9999. The end time must be equal to or greater than the start time. 9999 is used when an interval needs to extend past 24 hours. To do this, program the start time of the first interval then the end time with 9999. Program the start time of the second interval as 9999. Select the day of the week the schedule will end.

NOTE: If two intervals in a schedule are programmed with the same start time, the schedule follows the interval with the longest end time.

[103] Days Assignment

Used to program the day of the week that the schedule interval starts and ends. Use the scroll keys to select a day then toggle the option on. Multiple days of the week can be enabled.

[104] Holiday Assignment

Program PGMs to follow holiday schedule group 1-4. Select (Y) to enable. If all days of the week for an interval are disabled (N), the schedule activates on the enabled holidays.

[711]-[714] Holiday Schedules

Use this section to program holiday schedules. During holiday schedules, other scheduled events do not occur. Enter section 711 to 714 for holiday group 1 to 4.

Each of the four available holiday groups can have up to 99 holiday schedules programmed.

[001]-[099] Holiday Dates 1-99

Program holiday dates in the following format: MMDDYY

MM valid entries are 01 to 12

DD valid entries are 01 to 31

YY valid entries are 00 to 99

5.3.13 Wireless Programming**[804] Wireless Programming**

This programming section is used to enroll, program and delete wireless devices. Note that the HSM2HOSTx wireless transceiver or RF model keypad must be installed in order to enroll wireless devices.

[000] – Wireless Device Enrollment

To enroll a wireless device using this method, press and hold the Enroll button on the device for 2-5 seconds until the LED illuminates then release the button. The alarm system automatically discovers the device and the keypad displays a confirmation message. The device ID, type and the next available zone number are displayed. Press [*] to accept or scroll to another available zone number. Batteries must be installed in the wireless device in order to enroll.

NOTE: Ensure wireless signal strength is adequate before mounting the wireless device. See the instructions provided with the wireless device for details.

NOTE: For complete wireless device programming descriptions and worksheets, see the HSM2Hostx wireless transceiver installation manual.

[850] Cellular Signal Strength

This section is used to view both the cellular signal strength and the radio technology in use.

Table 5-3: Cellular Technology

Diaplay	Technology
GP	GPRS
ED	EDGE
HS	HSPA
H+	HSPA
CD	CDMA
EV	EVDO

5 bars indicate maximum signal strength. 0 bars indicate the communicator is not connected to the network.

[851] Alternate Communicator Programming

See the alternate communicator installation manual for programming instructions.

[860] Display Keypad Slot Number

The 2-digit slot number of the keypad being used is displayed in this read only section.

[861]-[876] Keypad Programming

Use section [861] to [876] to configure keypads 1 to 16. For information on keypad programming, refer to the installation sheet supplied with the keypad.

[899] Template Programming

Template programming allows quick programming of the minimum functions required for basic operation. This section is used to view current template programming options and to define certain system parameters. Press the (#) key to accept the displayed value and advance to the next option. The following options are available:

- 5-digit Template Code: Displays the current 5-digit template programming code (default: 0000). Each digit in the code selects a set of pre-defined programming options, as described below:
 - Digit 1 - zone 1-8 definition options

- Digit 2 - system EOL options
- Digit 3 - alarm controller communications options
- Digit 4 - reporting code configurations
- Digit 5 - DLS connection options
- Central Station Telephone Number: The phone number used to contact the central monitoring station (32 character limit).
- Central Station Account Code: The account code used in programming section [310]. This is a 4 or 6-digit entry.
- Partition Account Code: Used to identify partition-specific events. All 4 digits must be entered in order to complete the entry.
- This account code is entered into programming section [310][001].
- DLS Access Code: The 6-digit DLS access code used in programming section [403].
- Partition 1 Entry Delay: The 3-digit entry delay duration for partition 1, in seconds, used in programming [005][001]-[008] option 1.
- Partition 1 Exit Delay: The 3-digit exit delay duration for partition 1, in seconds, used in programming section [005][001]-[008] option 3.
- Installer Code: The 4 or 6-digit installer access code used in programming section [006][001].

For more information on template programming, see Appendix C: Template Programming Tables on page 105.

5.3.14 Systems Information

[900] System Information

[000] – Control Panel Version

This read-only section contains the model number, software version, hardware revision, of the alarm controller. For example, an entry of 1234 is read as version 12.34.

[001]-[524] – Module Information

This read-only section is used to view the model number, software version, and hardware revision information of the modules enrolled on the alarm system.

To view information for a specific module, scroll to the corresponding section:

- [001]-[016] keypads
- [101]-[116] 8-zone expansion module
- [201] 8-output expansion module
- [460] Alternate Communicator
- [461] HSM2Host module
- [501]-[504] 1A power supply module
- [521]-[524] high-current output modules 1-4

[901] Installer Walk Test Mode Enable/Disable

This mode tests the operation of each detector in the system. Enter section [901] to initiate a walk test. While in Walk Test mode, the Ready, Armed, and Trouble LED's on the keypad flash to indicate that the test is active. When a zone is tripped during the test, a 2-second tone sounds on all system keypads to indicate that the zone is working correctly.

After 10 minutes without zone activity, the alarm system emits 5 beeps every 10 seconds from all keypads. After another 5 minutes of inactivity, Walk Test terminates automatically.

To manually exit walk test mode, enter [901] again.

5.3.15 Module Programming

Use this section to add, remove and confirm the following modules:

- Keypads See Table 1-2 on page 2
- 8-zone expander module (HSM2108)

- 8-output expander module (HSM2208)
- Power supply (HSM2300)
- 4-output power supply (HSM2204)
- Wireless transceiver (HSM2HOSTx)

Once added, modules are supervised by the system.

[902] Add/Remove Modules

Modules can be enrolled automatically or manually. In either case, the serial number of the device is used as an identifier.

Select one of the enrollment options described below.

[000] – Auto Enroll Modules

When this mode is selected, the alarm system automatically enrolls all modules connected to the Corbus. The total number of modules currently enrolled are displayed on the keypad.

- Enter sub-section [000] to begin auto enrollment of all new modules. The auto enroll screen will show the following:
 - KP = Number of keypad type modules
 - IO = Number of zone and output type modules
 - M = Number of other type modules

Devices are assigned to the next available slot. The slot assignment can be modified using subsections [002] and [003].

[001] – Enroll Modules

To enroll modules individually:

1. Enter programming section [902]-[001].
2. When prompted, key in the serial number of the module found on the PCB. An error tone is sounded if an invalid serial number is used.
3. To cancel enrollment of a module, press [#].

[002] – Module Slot Assignment (LED, LCD, ICON)

This section is used to change the slot number a module is enrolled in. To change the slot number:

1. Enter programming section [902]-[002].
2. Key in the serial number of the module.
3. When prompted, key in the new two-digit slot number. The previous slot assignment is replaced with the new one. An error tone sounds if an invalid slot number is keyed in.

[003] – Edit Module Slot Assignment (LCD Keypad Only)

Like [002], this section is also used to change the slot number of a module. With this option, however, the serial number is not required.

To change the slot number:

1. Enter programming section [902]-[002].
2. Use the scroll keys to locate the module then press [*] to select.
3. Key in the new two-digit slot number. The previous slot assignment is replaced with the new one. An error tone sounds if an invalid slot number is keyed in.

Deleting Modules

The following sections are used to remove modules from the system:

- [101] – keypads
 - [102] – 8-zone expander modules
 - [103] – 8-output expander modules
 - [106] – HSM2Host
 - [109] – Power supply
 - [110] – 4 High Current Output
1. After entering section [902], scroll to the module type you want to delete (101-110).
 2. Press [*] to select the module type then scroll to the specific module you want to delete.
 3. Press [*] to select the module then, when prompted, press [*] again to delete.

[903] Confirm Module

The following sections are used to confirm enrollment of individual modules, their serial and slot numbers, and to locate them physically:

- 000 – View All Modules
- 101 – keypads
- 102 – 8-zone expander modules
- 103 – 8-output expander modules
- 106 – HSM2Host
- 109 – Power supply
- 110 – 4 High Current Output

To confirm a module:

1. Enter section [903]>[000] to view all enrolled modules or scroll to the module type you want to confirm (001-110).
2. Press [*] to select the module type then scroll to the specific module you want to confirm. Press [*] to enter Confirmation mode. The module's serial number and slot number are displayed on the keypad and the status LEDs on the device flash. This continues until confirmation mode for the device is exited via the [#] key. If communication with a module is lost at the time of confirmation, a warning message is displayed for 1 second before exiting the section.

NOTE: Keypad Blanking (section [016], option 3) must be disabled to confirm keypads.

5.3.16 Testing

[904] Wireless Placement Test

This test is used to determine RF signal status for wireless devices and can be performed at a system keypad or at the individual device. These instructions pertain to testing at the keypad. For instructions on placement testing at the device, refer to the installation sheet included with the wireless equipment.

The following test modes are available:

[001]-[128] Placement Test Zones 1-128

Test wireless devices individually by zone (LCD keypads only).

[521]-[528] – Placement Test Repeaters 1-8

Test each enrolled wireless repeater (LCD keypads only).

[551]-[566] – Placement Test Sirens 1-16

Test each enrolled wireless siren (LCD keypads only).

[601]-[632] Placement Test Wireless keys 1-32

Test individual wireless keys. Once in this section, press a button on the wireless key to begin the test (LCD keypads only).

[701]-[716] – Placement Test Wireless Keypads 1-16

Test each enrolled wireless keypad (LCD keypads only). Two test results are provided:

- 24-hour: Average status results received during a 24-hour period.
- Now: Signal status results of the current test.

During testing, the Ready and Armed LED's flash to indicate data is being received. A flashing Trouble LED indicates RF interference. The following status indicators may be displayed:

Table 5-4 Wireless Device Status Indications

Keypad	Status
Strong	Strong signal strength
Good	Good signal strength
Poor	Poor signal strength
1-Way	The device is operating in 1-way mode only. The alarm panel cannot configure or control the device
Not Test	Displayed as the Now result if no test was performed.
None	Always displayed as the 24-hour result when testing wireless keys.

[982] Battery Settings

[000] – Panel Battery Settings

01 – When disabled, the panel battery is charged at 400mA. When enabled, the battery is charged at 700mA.

[010] – High Current Output Battery

Enables and disables the high-current battery charge option for HSM2204 1-4.

[020] – 1A Power Supply Battery

Enables and disables the high-current battery charge option for HSM2300 1-4.

5.3.17 Defaults

[989] Default Master Code

This section is used to default the master code to the factory default. After entering this section, key in the installer code then 989.

[989][installer code][989] or [*].

[990] Installer Lockout Enable/Disable

When this option is enabled, an installer can not perform a hardware default; attempts to do so are logged to the event buffer.

An audible indication of installer lockout is provided when powering up the alarm system (the phone line relay clicks 10 times). Software default changes can still be made while installer lockout is enabled.

[990][installer code][990] or [*].

[991] Default Keypads

This programming option is used to return system keypads to factory default settings.

[999] – Default All Keypads

This section resets all system keypads to factory defaults. After entering this section, key in the installer code then (*) or 991.

[901]- [916] – Default Keypads 1-16

This section resets individual keypads to factory defaults. After entering this section, select the keypad to default, key in the installer code then 991 (or press [*]).

[993] Default Alternate Communicator

This section resets the alternate communicator to factory defaults. Enter [993][installer code][993 or *].

[996] Default Wireless Receiver

This section resets the wireless receiver (HSM2HOSTx) to factory defaults. Enter [996][installer code][996 or *].

[999] Default System

This section resets the alarm controller to factory defaults. Enter [999][installer code][999 or *].

Section 6: Programming Worksheets

This section provides a detailed list of all available programming options and a place to record custom settings. The index below lists all available programming sections in numerical order and includes page references to description and worksheet locations.

Programming Options Index

<u>Section</u>	<u>Page</u>	<u>Section</u>	<u>Page</u>
Label Programming		7 – Telephone Line Monitor Enable	38/73
000 Label Programming	26/57	8 – TLM Audible When Armed.....	38/73
000 – Language Selection	26/57	016 System Options 4	38/73
001 – 128 – Zone Labels	26/57	1 – AC Trouble Display	38/73
051 – Zone Tamper Label.....	27/58	2 – AC Trouble Light Flashes.....	38/73
052 – Zone Fault Label	27/58	3 – Keypad Blanking	38/73
064 – CO Alarm Message	27/58	4 – Keypad Blanking Requires Code.....	38/73
065 – Fire Alarm Message	27/58	5 – Keypad Back Lighting	38/73
066 – Fail to Arm Event Message.....	27/58	6 – Power Save Mode	38/73
067 – Alarm When Armed Event Message.....	27/58	7 – Bypass Display When Armed.....	38/73
100 – System Label	27/58	8 – Keypad Tamper Enabled	38/73
101-108 – Partition 1-8 Labels	27/58	017 System Options 5	39/73
201- 208 – Partition Command Output Labels	27/58	1 – Chime on Opening	38/73
601-604 – Schedule 1- 4 Labels	27/58	2 – Chime on Closing	38/73
801 – Keypad Labels	27/59	4 – Multi-Hit	38/73
802 – Zone Expander Labels.....	27/59	5 – Late to Close	38/73
803 – Output Expander Labels.....	27/59	6 – Daylight Savings Time.....	38/73
806 – HSM2HOSTx Label.....	27/59	8 – Bell Squawk on Away Arm/Disarm Only.....	38/73
809 – Power Supply Label	27/59	018 System Options 6	39/73
810 – High Current Output Supply Label	27/59	1 – Test Transmission Exception	39/73
815 – Alternate Communicator Label	27/59	2 – Realtime Bypass Reporting	39/73
820 – Siren Label	27/59	5 – Keypad Buzzer On Alarm	39/73
821 – Repeater Label.....	27/59	7 – Exit Delay Restart.....	39/73
999 – Default Labels	27/60	8 – AC Fail Trouble Beeps	39/73
Zone Programming		019 System Options 7	40/73
001 Zone Type	27/60	2 – Latching Troubles	39/73
002 – Zone Attributes	29/60	5 – Audible Bus Fault	39/73
System Times		6 – Duress Codes	39/73
005 System Times.....	30/62	7 – Temperature in Celsius	39/73
000 – System Area	30/62	020 System Options 8	40/73
001 – 008 System Times - Partition 1-8.....	30/62	3 – [*][8] Access While Armed.....	39/73
901-902 – Daylight Savings Begin/End.....	30/62	021 System Options 9	40/73
Access Codes		3 – Auto-Arming Bypass	40/73
006 Installer Defined Access Codes	30/63	8 – Audible Exit Delay for Stay Arm	40/73
PGM Programming		022 System Options 10	40/73
007 – PGM Programming.....	31/63	1 – [F] Key Option.....	40/73
000 – Main Bell Partition Assignment	31/63	4 – Test Transmission Counter in Hours.....	40/73
001- 028 – PGM 1-28 Partition	31/63	5 – Away to Stay Toggle	40/73
008 – PGM Timer Programming	31/65	7 – Trouble Beeps Are Silent.....	40/73
009 – PGM Types	31/66	8 – Keyswitch Arms in Away Mode.....	40/73
010 PGM Attributes		023 System Options 11.....	40/73
000 – Main Bell Mask	31/67	1 – Ready LED Flash for Force Arm.....	40/73
001-028 PGM 1-28 Attributes.....	34/67	4 – Access Code Required for [*][1].....	40/73
011 PGM Configuration Options.....	37/70	5 – Access Code Required for [*][2].....	40/73
012 System Lockout	37/73	6 – Access Code Required for [*][3].....	40/73
System Options		7 – Access Code Required for [*][4].....	40/73
013 System Options 1	37/73	8 – [*][6] Accessibility Option	40/73
1 – NC Loop/EOL	37/73	024 System Options 12	41/73
2 – DEOL/SEOL	37/73	1 – 50Hz AC / 60 Hz AC	40/73
3 – Show All Troubles when Armed.....	37/73	2 – Crystal Timebase.....	40/73
4 – Tamper/Faults Do Not show as open.....	37/73	3 – AC/DC Inhibits Arming.....	40/73
5 – Auto-Arm Schedule in [*][6]	37/73	4 – Tamper Inhibit Arming.....	40/73
6 – Audible Exit Fault	37/73	5 – Real Time Clock Option	40/73
7 – Event Buffer Follows Swinger	37/73	8 – DLS Disconnect	40/73
8 – Temporal Three Fire Signaling.....	37/73	025 System Options 13	40/73
014 System Options 2	38/73	1 – European Dial	40/73
1 – Bell Squawk	38/73	2 – Force Dial.....	40/73
2 – Bell Duration Auto-Arm	38/73	5 – ID Tone	40/73
3 – Bell Squawk on Exit.....	38/73	6 – Tone Generated-2100Hz.....	40/73
4 – Bell Squawk on Entry.....	38/73	7 – 1 Hour DLS Window	40/73
5 – Bell Squawk on Trouble.....	38/73	8 – FTC Audible Bell.....	40/73
7 – Exit Delay Termination	38/73	040 User Authentication.....	42/73
8 – Fire Bell Continues.....	38/73	01 – User Code/Prox Tag.....	42/73
015 System Options 3	38/73	02 – User Code and Prox Tag	42/73
1 – [F] Key	38/73	041 Access Code Digits	42/73
2 – [P] Key Annunciation.....	38/73	01 – 4-Digit Access Codes.....	42/73
3 – Quick Exit.....	38/73	02 – 6-Digit Access Codes.....	42/73
4 – Quick Arming/Function Key.....	38/73	042 Event Verification.....	42/74
6 – Master Code Not User Changeable.....	38/73	01 – Burglary Verified Counter.....	42/73

03 – Burglary Verification Selection	42/73	001 – Automatic DLS Toggle Options	51/85
151-158 Partition 1-8 Auto-Arm/Disarm	42/74	002 – Periodic DLS Days	51/85
001 – Auto-Arming Times	42/74	003 – Periodic DLS Time	52/85
002 – Auto-Disarm Times	42/74	007 – Delay Call Window	52/85
003 – Auto-Disarming Holiday Schedule	42/74	Schedule Programming	
004 – Auto-Arming Pre-Alert	42/74	601 Programming Schedule	52/85
005 – Auto-Arming Postpone Timer	42/74	711-714 Holiday Schedules.....	52/88
006 – No Activity Arming Timer	42/74	Wireless Programming	
007 – No Activity Arming Pre-Alert Timer	42/74	804 Wireless Programming	52/89
200 Partition Mask.....	42/77	850 Cellular Signal Strength	52/89
001 – Partition 1 to 8 Enable Mask	42/77	851 Alternate Communicator Programming	52/89
201-208 Partition 1-8 Zone Assignment	43/78	Keypad Programming	
300 Panel/Receiver Communications Path.....	43/79	860 Keypad Slot Number	52/89
301 Phone Number Programming	43/79	861-876 Keypad Programming	52/90
304 Call Waiting Cancel String	43/79	000 – Keypad Partition Mask	12/90
Event Reporting		001-005 – Function Key 1- 5 Assignment.....	52/90
307 Zone Reporting	43/81	011 – Keypad I/O	52/90
308 Event Reporting.....	43/81	012 – Local PGM Output Timer.....	52/90
001 – Miscellaneous Alarm 1	44/81	021 – Keypad Option 1.....	52/90
002 – Miscellaneous Alarm 2	44/81	022 – Keypad Option 2.....	52/90
011 – Priority Alarms	44/81	023 – Keypad Option 3.....	52/90
021 – Fire Alarms 1.....	44/81	030 – LCD Message.....	52/90
101 – Tamper Events	44/81	031 – Download LCD Message Duration.....	52/90
201 – Open/Close Events 1	44/81	041 – Indoor Temperature Zone Entry.....	52/90
202 – Open/Close Events 2	44/81	042 – Outdoor Temperature Zone Entry.....	52/90
211 – Miscellaneous Open/Close Events	44/81	101-228 – Door Chime Sound-Zone 1-128	52/90
221 – Bypass Events.....	44/81	899 Template Programming	52/91
301 – Panel Events 1	45/81	System Information and Testing	
302 – Panel Events 2	45/81	900 System Information	53/91
305 – Panel Events 5	45/81	901 Installer Walk Test.....	53/91
311 – Maintenance Events 1	45/81	Module Programming	
312 – Maintenance Events 2	45/81	902 Add/Remove Modules.....	53/91
313 – Maintenance Events 3	45/81	000 – Auto-Enroll All Modules	53/91
314 – Maintenance Events 4	45/81	001 – Enroll Modules	53/91
321 – Receiver Events	45/81	002 – Slot Assignment.....	53/91
331 – Module Events 1.....	45/81	003 – Edit Module Slot Assignment.....	53/91
332 – Module Events 2	46/81	101-110 – Delete Modules.....	53/91
335 – Module Events 5.....	46/81	903 Confirm Modules	54/92
351 – Alternate Communicator	46/82	Testing	
352 – Alternate Communicator 2	46/82	904 Wireless Placement Test.....	54/92
354 – Alternate Communicator 4	46/82	Battery Settings	
355 – Alternate Communicator 5	46/82	982 Battery Settings	54/92
361 – Wireless Device Events.....	46/82	000– Panel Battery Settings	54/92
401– System Test Events.....	46/82	010 – High Current Output Battery Settings	54/92
Communications		020 – 1A Power Supply Battery Settings	54/92
309 System Call Direction.....	46/82	Defaults	
001– Maintenance Events	47/82	989 Default Master Code	54/92
002 – Test Transmission Events	47/82	990 Installer Lockout Enable	54/92
310 Account Codes	47/82	991 Default Keypads	54/92
311-318 Partition 1-8 Call Direction	47/82	999 – Default all Keypads.....	54/92
350 Communicator Formats	47/84	901-916 – Default Keypad 1-16	54/92
377 Communication Variables.....	47/84	993 Default Alt Comm	54/92
001 – Swinger Shutdown Counters.....	47/84	996 Default Wireless Receiver.....	54/92
002 – Communication Delays	48/84	999 Default System	54/92
003 – Periodic Test Transmission Cycle	48/84		
004 – Periodic Test Transmission Time of Day	48/84		
011 – Maximum Dialing Attempts	48/84		
012 – Delay Between PSTN Attempts	48/84		
013 – Delay Between Force Attempts.....	48/84		
014 – Post Dial Wait for Handshake	48/84		
015 – T-Link Wait for Ack	48/84		
016 – IP/Cellular Fault Check Timer	48/84		
380 Communicator Option 1	48/84		
381 Communicator Option 2	49/84		
382 Communicator Option 3	49/84		
383 Communicator Option 4	50/84		
384 Communicator Backup Options.....	50/84		
DLS Programming			
401 DLS/SA Options	50/85		
402 PSTN DLS Phone Number	51/85		
403 DLS Access Code	51/85		
404 DLS/SA Panel ID.....	51/85		
405 PSTN Double Call Timer	51/85		
406 PSTN Number of Rings to Answer On	51/85		
407 SA Access Code.....	51/85		
410 Automatic DLS Options	51/85		

Label Programming

[000]	Label Programming	Description on page 26				
	000 – Language Selection	(2-digit decimal; Default: 01)				
	01 – English	06 – Dutch	11 – Swedish	16 – Turkish	21 – Russian	26 – Slovakian
	02 – Spanish	07 – Polish	12 – Norwegian	18 – Croatian	22 – Bulgarian	27 – Serbian
	03 – Portuguese	08 – Czech	13 – Danish	19 – Hungarian	23 – Latvian	28 – Estonian
	04 – French	09 – Finish	14 – Hebrew	20 – Romanian	24 – Lithuanian	29 – Slovenian
	05 – Italian	10 – German	15 – Greek		25 – Ukrainian	
[000]	001 – Zone Labels	(2 x 14 Characters) Description on page 26				
	001:	044:	087:			
	002:	045:	088:			
	003:	046:	089:			
	004:	047:	090:			
	005:	048:	091:			
	006:	049:	092:			
	007:	050:	093:			
	008:	051:	094:			
	009:	052:	095:			
	010:	053:	096:			
	011:	054:	097:			
	012:	055:	098:			
	013:	056:	099:			
	014:	057:	100:			
	015:	058:	101:			
	016:	059:	102:			
	017:	060:	103:			
	018:	061:	104:			
	019:	062:	105:			
	020:	063:	106:			
	021:	064:	107:			
	022:	065:	108:			
	023:	066:	109:			
	024:	067:	110:			
	025:	068:	111:			
	026:	069:	112:			
	027:	070:	113:			
	028:	071:	114:			
	029:	072:	115:			
	030:	073:	116:			
	031:	074:	117:			
	032:	075:	118:			
	033:	076:	119:			
	034:	077:	120:			
	035:	078:	121:			
	036:	079:	122:			
	037:	080:	123:			
	038:	081:	124:			
	039:	082:	125:			
	040:	083:	126:			
	041:	084:	127:			
	042:	085:	128:			
	043:	086:				

[000]	051 – Zone Tamper Label	(1 x 14 Characters):		
	052 – Zone Fault Label	(1 x 14 Characters):		
	064 – CO Alarm Message	(2 x 14 Characters):		
	065 – Fire Alarm Message	(2 x 14 Characters):		
	066 – Fail to Arm Event Message	(2 x 16 Characters):		
	067 – Alarm When Armed Event Message	(2 x 16 Characters):		
	100 – System Label	(1 x 14 Characters):		
[000]	101 – Partition 1 Label	(1 x 14 Characters):		
	102 – Partition 2 Label	(1 x 14 Characters):		
	103 – Partition 3 Label	(1 x 14 Characters):		
	104 – Partition 4 Label	(1 x 14 Characters):		
	105 – Partition 5 Label	(1 x 14 Characters):		
	106 – Partition 6 Label	(1 x 14 Characters):		
	107 – Partition 7 Label	(1 x 14 Characters):		
	108 – Partition 8 Label	(1 x 14 Characters):		
[000]	201 – Partition 1 Command Output Labels (2 X 14 ASCII) Descriptions on page 27	001 – Partition 1 Command Output 1:		
		002 – Partition 1 Command Output 2:		
		003 – Partition 1 Command Output 3:		
		004 – Partition 1 Command Output 4:		
	202 – Partition 2 Command Output Labels (2 X 14 ASCII)	001 – Partition 2 Command Output 1:		
		002 – Partition 2 Command Output 2:		
		003 – Partition 2 Command Output 3:		
		004 – Partition 2 Command Output 4:		
	203 – Partition 3 Command Output Labels (2 X 14 ASCII)	001 – Partition 3 Command Output 1:		
		002 – Partition 3 Command Output 2:		
		003 – Partition 3 Command Output 3:		
		004 – Partition 3 Command Output 4:		
	204 – Partition 4 Command Output Labels (2 X 14 ASCII)	001 – Partition 4 Command Output 1:		
		002 – Partition 4 Command Output 2:		
		003 – Partition 4 Command Output 3:		
		004 – Partition 4 Command Output 4:		
	205 – Partition 5 Command Output Labels (2 X 14 ASCII)	001 – Partition 5 Command Output 1:		
		002 – Partition 5 Command Output 2:		
		003 – Partition 5 Command Output 3:		
		004 – Partition 5 Command Output 4:		
	206 – Partition 6 Command Output Labels (2 X 14 ASCII)	001 – Partition 6 Command Output 1:		
		002 – Partition 6 Command Output 2:		
		003 – Partition 6 Command Output 3:		
		004 – Partition 6 Command Output 4:		
	207 – Partition 7 Command Output Labels (2 X 14 ASCII)	001 – Partition 7 Command Output 1:		
		002 – Partition 7 Command Output 2:		
		003 – Partition 7 Command Output 3:		
		004 – Partition 7 Command Output 4:		
	208 – Partition 8 Command Output Labels (2 X 14 ASCII)	001 – Partition 8 Command Output 1:		
		002 – Partition 8 Command Output 2:		
		003 – Partition 8 Command Output 3:		
		004 – Partition 8 Command Output 4:		
[000]	601 – Schedule 1 Label	(1 X 16 ASCII):	Descriptions on page 27	
	602 – Schedule 2 Label	(1 X 16 ASCII):		
	603 – Schedule 3 Label	(1 X 16 ASCII):		
	604 – Schedule 4 Label	(1 X 16 ASCII):		

[000]	801 – Keypad Labels	(1 X 14 ASCII)	Description on page 27
	001 – Keypad 1 Label:	009 – Keypad 9 Label:	
	002 – Keypad 2 Label:	010 – Keypad 10 Label:	
	003 – Keypad 3 Label:	011 – Keypad 11 Label:	
	004 – Keypad 4 Label:	012 – Keypad 12 Label:	
	005 – Keypad 5 Label:	013 – Keypad 13 Label:	
	006 – Keypad 6 Label:	014 – Keypad 14 Label:	
	007 – Keypad 7 Label:	015 – Keypad 15 Label:	
	008 – Keypad 8 Label:	016 – Keypad 16 Label:	
[000]	802 – Zone Expander Labels	(1 x 14 ASCII):	Description on page 27
	001– Zone Expander 1 Label:	009– Zone Expander 9 Label:	
	002– Zone Expander 2 Label:	010– Zone Expander 10 Label:	
	003– Zone Expander 3 Label:	011– Zone Expander 11 Label:	
	004– Zone Expander 4 Label:	012– Zone Expander 12 Label:	
	005– Zone Expander 5 Label:	013– Zone Expander 13 Label:	
	006– Zone Expander 6 Label:	014– Zone Expander 14 Label:	
	007– Zone Expander 7 Label:	015– Zone Expander 15 Label:	
	008– Zone Expander 8 Label:		
[000]	803 – Output Expander Label	(1 X 14 ASCII)	Description on page 27
	001– Output Expander 1 Label:	009– Output Expander 9 Label:	
	002– Output Expander 2 Label:	010– Output Expander 10 Label:	
	003– Output Expander 3 Label:	011– Output Expander 11 Label:	
	004– Output Expander 4 Label:	012– Output Expander 12 Label:	
	005– Output Expander 5 Label:	013– Output Expander 13 Label:	
	006– Output Expander 6 Label:	014– Output Expander 14 Label:	
	007– Output Expander 7 Label:	015– Output Expander 15 Label:	
	008– Output Expander 8 Label:	016– Output Expander 16 Label:	
[000]	806 – HSM2HOSTx Label:	(1 X 14 ASCII)	Description on page 27
[000]	809 – Power Supply Label (1 X 14 ASCII) Description on page 27	001 – Power Supply 1 Label:	
		002 – Power Supply 2 Label:	
		003 – Power Supply 3 Label:	
		004 – Power Supply 4 Label:	
[000]	810 – High-Current Output Supply Label (1 X 14 ASCII): Description on page 27	001 – High-Current Output Supply 1 Label:	
		002 – High-Current Output Supply 2 Label:	
		003 – High-Current Output Supply 3 Label:	
		004 – High-Current Output Supply 4 Label:	
[000]	815 – Alt. Comm Label:	(1 X 14 ASCII)	Description on page 27
[000]	820 – Siren Labels (1 X 14 ASCII): Description on page 27		
	001– Siren 1 Label:	009– Siren 9 Label:	
	002– Siren 2 Label:	010– Siren 10 Label:	
	003– Siren 3 Label:	011– Siren 11 Label:	
	004– Siren 4 Label:	012– Siren 12 Label:	
	005– Siren 5 Label:	013– Siren 13 Label:	
	006– Siren 6 Label:	014– Siren 14 Label:	
	007– Siren 7 Label:	015– Siren 15 Label:	
	008– Siren 8 Label:	016– Siren 16 Label:	
[000]	821 – Repeater Label (1 X 14 ASCII): Description on page 27	001– Repeater 1 Label:	
		002– Repeater 2 Label:	
		003– Repeater 3 Label:	
		004– Repeater 4 Label:	
		005– Repeater 5 Label:	

		006– Repeater 6 Label:
		007– Repeater 7 Label:
		008– Repeater 8 Label:
[000]	999 – Default Labels Description on page 27	

Zone Setup

[001] Zone Type					
Available Zone Types	000 – Null Zone	012 – Night Zone	043 – 24-Hour Panic	057 – 24 Hour Low Temperature	
Default = 000	001 – Delay 1	017 – 24-Hour Burglary	045 – 24-Hour Heat	060 – 24-Hour Non-Latching Tamper	
Description on page 27	002 – Delay 2	018 – 24-Hour Bell/Buzzer	046 – 24-Hour Medical	066 – Momentary Key-switch Arm	
* Not UL evaluated	003 – Instant	023 – 24-Hour Supervisory	047 – 24-Hour Emergency	067 – Maintained Key-switch Arm	
	004 – Interior	024 – 24-Hour Supervisory Buzzer	048 – 24-Hour Sprinkler*	068 – Momentary Key-switch Disarm	
	005 – Interior Stay/Away	025 – Auto Verified Fire	049 – 24-Hour Flood	069 – Maintained Key-switch Disarm	
	006 – Delay Stay/Away	027 – Fire Supervisory	051 – 24-Hour Latching Tamper	071 – Door Bell	
	007 – Delayed 24-Hour Fire	040 – 24-Hour Gas	052 – 24-Hour Non-Alarm		
	008 – Standard 24-Hour Fire	041 – 24-Hour CO	056 – 24-Hour High Temperature		
	009 – Instant Stay/Away	042 – 24-Hour Holdup*			
	010 – Interior Delay				
	011 – Day Zone				

[002] Zone Attributes															
Available Zone Attributes	1 – Bell Audible			6 – Swinger Shutdown			11 – Double EOL								
See next page for defaults	2 – Bell Steady			7 – Transmission Delay			12 – Fast Loop/Normal Loop Response								
Description on page 29	3 – Door Chime			8 – Burglary Verification											
	4 – Bypass Enabled			9 – Normally Closed											
	5 – Force Arm			EOL											
				10 – Single EOL											
Record Zone Settings:															
Zone	Type	Att.	Zone	Type	Att.	Zone	Type	Att.	Zone	Type	Att.	Zone	Type	Att.	
001:			027:			053:			079:			105:			
002:			028:			054:			080:			106:			
003:			029:			055:			081:			107:			
004:			030:			056:			082:			108:			
005:			031:			057:			083:			109:			
006:			032:			058:			084:			110:			
007:			033:			059:			085:			111:			
008:			034:			060:			086:			112:			
009:			035:			061:			087:			113:			
010:			036:			062:			088:			114:			
011:			037:			063:			089:			115:			
012:			038:			064:			090:			116:			
013:			039:			065:			091:			117:			
014:			040:			066:			092:			118:			
015:			041:			067:			093:			119:			
016:			042:			068:			094:			120:			
017:			043:			069:			095:			121:			
018:			044:			070:			096:			122:			
019:			045:			071:			097:			123:			
020:			046:			072:			098:			124:			
021:			047:			073:			099:			125:			
022:			048:			074:			100:			126:			
023:			049:			075:			101:			127:			
024:			050:			076:			102:			128:			
025:			051:			077:			103:						
026:			052:			078:			104:						

Zone Attribute Defaults (Description on page 29)

		Zone Attributes										
Zone Type		1 – Bell Audible	2 – Bell Steady	3 – Chime Function	4 – Bypass Enabled	5 – Force Arm	6 – Swinger Shutdown	7 – Transmission Delay	9 – Normally Closed EOL	10 – Single EOL	11 – Double EOL	12 – Fast/Normal Loop Response
000	Null Zone											
001	Delay 1	✓	✓	✓	✓		✓	✓				
002	Delay 2	✓	✓	✓	✓		✓	✓				
003	Instant	✓	✓	✓	✓		✓	✓				
004	Interior	✓	✓		✓		✓	✓				
005	Interior Stay/Away	✓	✓		✓	✓	✓	✓				
006	Delay Stay/Away	✓	✓		✓	✓	✓	✓				
007	Delayed 24-Hour Fire	✓	✓		✓							
008	Standard 24-Hour Fire	✓	✓		✓		✓					
009	Instant Stay/Away	✓						✓				
010	Interior Delay	✓						✓				
011	Day Zone	✓	✓		✓		✓					
012	Night Zone	✓	✓		✓		✓	✓				
016	Final Door Set	✓	✓		✓	✓	✓	✓				
017	24-Hour Burglary	✓	✓		✓	✓	✓	✓				
018	24-Hour Bell/Buzzer	✓	✓		✓		✓	✓	✓			
023	24-Hour Supervisory		✓		✓		✓	✓				
024	24-Hour Supervisory Buzzer	✓					✓	✓				
025	Auto Verify Fire	✓										
027	Fire Supervisory											
040	24-Hour Gas	✓					✓	✓				
041	24-Hour CO	✓										
042	24-Hour Holdup		✓				✓	✓				
043	24-Hour Panic	✓	✓				✓	✓				
045	24-Hour Heat	✓					✓					
046	24-Hour Medical	✓	✓				✓	✓				
047	24-Hour Emergency	✓	✓				✓	✓				
048	24-Hour Sprinkler	✓	✓				✓	✓				
049	24-Hour Flood	✓					✓	✓				
051	24-Hour Latching Tamper	✓	✓				✓	✓				
052	24-Hour Non-Alarm					✓						
056	24 Hour High Temperature	✓	✓		✓							
057	24 Hour Low Temperature	✓	✓		✓							
060	24-Hr Non-Latching Tamper	✓	✓				✓	✓				
066	Momentary Keyswitch Arm					✓						
067	Maintained Keyswitch Arm					✓						
068	Momentary Keyswitch Disarm					✓						
069	Maintained Keyswitch Disarm					✓						
071	Door Bell					✓						

System Times

[005] System Times		
Description on page 30	000 – System Area (3-Digit Decimal)	Bell Cutoff (Default: 004):
		Burglary Verification Timer (Default: 060):
		Zone Loop Response Time (Default: 250):
		Automatic Clock Adjust (Default: 060):
	001 – Partition 1 Timer	Entry Delay 1 (Default: 030):
		Entry Delay 2 (Default: 045):
		Exit Delay (Default: 120):
	002 – Partition 2 Timer See partition 1 for defaults	Entry Delay 1:
		Entry Delay 2:
		Exit Delay:
	003 – Partition 3 Timer See partition 1 for defaults	Entry Delay 1:
		Entry Delay 2:
		Exit Delay:
	004 – Partition 4 Timer See partition 1 for defaults	Entry Delay 1:
		Entry Delay 2:
		Exit Delay:
	005 – Partition 5 Timer See partition 1 for defaults	Entry Delay 1:
		Entry Delay 2:
		Exit Delay:
	006 – Partition 6 Timer See partition 1 for defaults	Entry Delay 1:
		Entry Delay 2:
		Exit Delay:
007 – Partition 7 Timer See partition 1 for defaults	Entry Delay 1:	
	Entry Delay 2:	
	Exit Delay:	
008 – Partition 8 Timer See partition 1 for defaults	Entry Delay 1:	
	Entry Delay 2:	
	Exit Delay:	
901 – Daylight Savings Begin	Month:	
	Week:	
	Day:	
	Hour:	
	Increment:	
902 – Daylight Savings End	Month:	
	Week:	
	Day:	
	Hour:	
	Increment:	

Access Codes

006 Installer-Defined Codes (4/6-Digit Decimal) Description on page 30	001 – Installer Code	(Default:555555):
	002 – Master Code	(Default:123456):
	003 – Maintenance Code	(Default: AAAA00):

PGM Programming

[007] PGM Programming								
000 – Main Bell Partition Assignment (001-164)		1 2 3 4 5 6 7 8 Y Y Y Y Y Y Y Y						
001 – PGM Partition Assignment Default: Partition 1 on. All others off Description on page 31	PGM	Partition	PGM	Partition	PGM	Partition	PGM Partition	
	001:	1 2 3 4 5 6 7 8 Y N N N N N N N	014:	1 2 3 4 5 6 7 8 Y N N N N N N N	027:	1 2 3 4 5 6 7 8 Y N N N N N N N	040:	1 2 3 4 5 6 7 8 Y N N N N N N N
	002:	1 2 3 4 5 6 7 8 Y N N N N N N N	015:	1 2 3 4 5 6 7 8 Y N N N N N N N	028:	1 2 3 4 5 6 7 8 Y N N N N N N N	041:	1 2 3 4 5 6 7 8 Y N N N N N N N
	003:	1 2 3 4 5 6 7 8 Y N N N N N N N	016:	1 2 3 4 5 6 7 8 Y N N N N N N N	029:	1 2 3 4 5 6 7 8 Y N N N N N N N	042:	1 2 3 4 5 6 7 8 Y N N N N N N N
	004:	1 2 3 4 5 6 7 8 Y N N N N N N N	017:	1 2 3 4 5 6 7 8 Y N N N N N N N	030:	1 2 3 4 5 6 7 8 Y N N N N N N N	043:	1 2 3 4 5 6 7 8 Y N N N N N N N
	005:	1 2 3 4 5 6 7 8 Y N N N N N N N	018:	1 2 3 4 5 6 7 8 Y N N N N N N N	031:	1 2 3 4 5 6 7 8 Y N N N N N N N	044:	1 2 3 4 5 6 7 8 Y N N N N N N N
	006:	1 2 3 4 5 6 7 8 Y N N N N N N N	019:	1 2 3 4 5 6 7 8 Y N N N N N N N	032:	1 2 3 4 5 6 7 8 Y N N N N N N N	045:	1 2 3 4 5 6 7 8 Y N N N N N N N
	007:	1 2 3 4 5 6 7 8 Y N N N N N N N	020:	1 2 3 4 5 6 7 8 Y N N N N N N N	033:	1 2 3 4 5 6 7 8 Y N N N N N N N	046:	1 2 3 4 5 6 7 8 Y N N N N N N N
	008:	1 2 3 4 5 6 7 8 Y N N N N N N N	021:	1 2 3 4 5 6 7 8 Y N N N N N N N	034:	1 2 3 4 5 6 7 8 Y N N N N N N N	047:	1 2 3 4 5 6 7 8 Y N N N N N N N
	009:	1 2 3 4 5 6 7 8 Y N N N N N N N	022:	1 2 3 4 5 6 7 8 Y N N N N N N N	035:	1 2 3 4 5 6 7 8 Y N N N N N N N	048:	1 2 3 4 5 6 7 8 Y N N N N N N N
	010:	1 2 3 4 5 6 7 8 Y N N N N N N N	023:	1 2 3 4 5 6 7 8 Y N N N N N N N	036:	1 2 3 4 5 6 7 8 Y N N N N N N N	049:	1 2 3 4 5 6 7 8 Y N N N N N N N
	011:	1 2 3 4 5 6 7 8 Y N N N N N N N	024:	1 2 3 4 5 6 7 8 Y N N N N N N N	037:	1 2 3 4 5 6 7 8 Y N N N N N N N	050:	1 2 3 4 5 6 7 8 Y N N N N N N N
	012:	1 2 3 4 5 6 7 8 Y N N N N N N N	025:	1 2 3 4 5 6 7 8 Y N N N N N N N	038:	1 2 3 4 5 6 7 8 Y N N N N N N N	051:	1 2 3 4 5 6 7 8 Y N N N N N N N
	013:	1 2 3 4 5 6 7 8 Y N N N N N N N	026:	1 2 3 4 5 6 7 8 Y N N N N N N N	039:	1 2 3 4 5 6 7 8 Y N N N N N N N	052:	1 2 3 4 5 6 7 8 Y N N N N N N N

[008] PGM Timer Programming		000 – PGM Timers Minutes or Seconds: <input type="checkbox"/> Minutes <input type="checkbox"/> Seconds			
(3-Digit Decimal) Valid Range: 001-255 Default: 005 Description on page 31	001 – PGM 1:	042 – PGM 42:	083 – PGM 83:	124 – PGM 124:	
	002 – PGM 2:	043 – PGM 43:	084 – PGM 84:	125 – PGM 125:	
	003 – PGM 3:	044 – PGM 44:	085 – PGM 85:	126 – PGM 126:	
	004 – PGM 4:	045 – PGM 45:	086 – PGM 86:	127 – PGM 127:	
	005 – PGM 5:	046 – PGM 46:	087 – PGM 87:	128 – PGM 128:	
	006 – PGM 6:	047 – PGM 47:	088 – PGM 88:	129 – PGM 129:	
	007 – PGM 7:	048 – PGM 48:	089 – PGM 89:	130 – PGM 130:	
	008 – PGM 8:	049 – PGM 49:	090 – PGM 90:	131 – PGM 131:	
	009 – PGM 9:	050 – PGM 50:	091 – PGM 91:	132 – PGM 132:	
	010 – PGM 10:	051 – PGM 51:	092 – PGM 92:	133 – PGM 133:	
	011 – PGM 11:	052 – PGM 52:	093 – PGM 93:	134 – PGM 134:	
	012 – PGM 12:	053 – PGM 53:	094 – PGM 94:	135 – PGM 135:	
	013 – PGM 13:	054 – PGM 54:	095 – PGM 95:	136 – PGM 136:	
	014 – PGM 14:	055 – PGM 55:	096 – PGM 96:	137 – PGM 137:	
	015 – PGM 15:	056 – PGM 56:	097 – PGM 97:	138 – PGM 138:	
	016 – PGM 16:	057 – PGM 57:	098 – PGM 98:	139 – PGM 139:	
	017 – PGM 17:	058 – PGM 58:	099 – PGM 99:	140 – PGM 140:	
	018 – PGM 18:	059 – PGM 59:	100 – PGM 100:	141 – PGM 141:	
	019 – PGM 19:	060 – PGM 60:	101 – PGM 101:	142 – PGM 142:	
	020 – PGM 20:	061 – PGM 61:	102 – PGM 102:	143 – PGM 143:	
	021 – PGM 21:	062 – PGM 62:	103 – PGM 103:	144 – PGM 144:	
	022 – PGM 22:	063 – PGM 63:	104 – PGM 104:	145 – PGM 145:	
	023 – PGM 23:	064 – PGM 64:	105 – PGM 105:	146 – PGM 146:	
	024 – PGM 24:	065 – PGM 65:	106 – PGM 106:	147 – PGM 147:	
	025 – PGM 25:	066 – PGM 66:	107 – PGM 107:	148 – PGM 148:	
	026 – PGM 26:	067 – PGM 67:	108 – PGM 108:	149 – PGM 149:	
	027 – PGM 27:	068 – PGM 68:	109 – PGM 109:	150 – PGM 150:	
	028 – PGM 28:	069 – PGM 69:	110 – PGM 110:	151 – PGM 151:	
	029 – PGM 29:	070 – PGM 70:	111 – PGM 111:	152 – PGM 152:	
	030 – PGM 30:	071 – PGM 71:	112 – PGM 112:	153 – PGM 153:	
	031 – PGM 31:	072 – PGM 72:	113 – PGM 113:	154 – PGM 154:	
	032 – PGM 32:	073 – PGM 73:	114 – PGM 114:	155 – PGM 155:	
	033 – PGM 33:	074 – PGM 74:	115 – PGM 115:	156 – PGM 156:	
	034 – PGM 34:	075 – PGM 75:	116 – PGM 116:	157 – PGM 157:	
	035 – PGM 35:	076 – PGM 76:	117 – PGM 117:	158 – PGM 158:	
	036 – PGM 36:	077 – PGM 77:	118 – PGM 118:	159 – PGM 159:	
	037 – PGM 37:	078 – PGM 78:	119 – PGM 119:	160 – PGM 160:	
	038 – PGM 38:	079 – PGM 79:	120 – PGM 120:	161 – PGM 161:	
	039 – PGM 39:	080 – PGM 80:	121 – PGM 121:	162 – PGM 162:	
	040 – PGM 40:	081 – PGM 81:	122 – PGM 122:	163 – PGM 163:	
	041 – PGM 41:	082 – PGM 82:	123 – PGM 123:	164 – PGM 164:	

Section 6: Programming Worksheets

<p>[009] PGM Types (3-Digit Decimal) Description on page 31</p> <p>100 – Null PGM 101 – Burg and Fire Bell Follow lower 102 – Delayed Fire/ Burg 103 – Sensor Reset[*][7][2] 104 – 2-Wire Smoke 109 – Courtesy Pulse 111 – Keypad Buzzer Follow</p> <p>(3-Digit Decimal) Valid Range: 001-255 Default: 005</p> <p>Description on page 31</p>	<p>114 – Ready To Arm 115 – System Armed Status 116 – Away Armed Status 117 – Stay Armed Status 120 – Away Armed/no Bypass Status 121 – Command Output 1 122 – Command Output 2 123 – Command Output 3 124 – Command Output 4 129 – Partition Status Alarm Memory</p>	<p>132 – Holdup Output 134 – 24Hr Silent 135 – 24Hr Audible Input 146 – TLM and Alarm 147 – Kissoff 148 – Ground Start 149 – Alt. Communicator 155 – System Trouble 156 – Latched System Event 157 – System Tamper 161 – DC Trouble 165 – Prox Used</p>	<p>175 – Bell Status and Programming Access Output 176 – Remote Operation 184 – Open After Alarm 200 – Zone Follower 201 – Follower-Zones 1-8 202 – Follower-Zones 9-16 203 – Follower-Zones 17-24 204 – Follower-Zones 25-32 205 – Follower-Zones 33-40</p>	<p>206 – Follower-Zones 41-48 207 – Follower-Zones 49-56 208 – Follower-Zones 57-64 209 – Follower-Zones 65-72 210 – Follower-Zones 73-80 211 – Follower-Zones 81-88 212 – Follower-Zones 89-96 213 – Follower-Zones 97-104 214 – Follower-Zones 105-112 215 – Follower-Zones 113-120 216 – Follower-Zones 120-128</p>
	001 – PGM 1:	042 – PGM 42:	083 – PGM 83:	124 – PGM 124:
	002 – PGM 2:	043 – PGM 43:	084 – PGM 84:	125 – PGM 125:
	003 – PGM 3:	044 – PGM 44:	085 – PGM 85:	126 – PGM 126:
	004 – PGM 4:	045 – PGM 45:	086 – PGM 86:	127 – PGM 127:
	005 – PGM 5:	046 – PGM 46:	087 – PGM 87:	128 – PGM 128:
	006 – PGM 6:	047 – PGM 47:	088 – PGM 88:	129 – PGM 129:
	007 – PGM 7:	048 – PGM 48:	089 – PGM 89:	130 – PGM 130:
	008 – PGM 8:	049 – PGM 49:	090 – PGM 90:	131 – PGM 131:
	009 – PGM 9:	050 – PGM 50:	091 – PGM 91:	132 – PGM 132:
	010 – PGM 10:	051 – PGM 51:	092 – PGM 92:	133 – PGM 133:
	011 – PGM 11:	052 – PGM 52:	093 – PGM 93:	134 – PGM 134:
	012 – PGM 12:	053 – PGM 53:	094 – PGM 94:	135 – PGM 135:
	013 – PGM 13:	054 – PGM 54:	095 – PGM 95:	136 – PGM 136:
	014 – PGM 14:	055 – PGM 55:	096 – PGM 96:	137 – PGM 137:
	015 – PGM 15:	056 – PGM 56:	097 – PGM 97:	138 – PGM 138:
	016 – PGM 16:	057 – PGM 57:	098 – PGM 98:	139 – PGM 139:
	017 – PGM 17:	058 – PGM 58:	099 – PGM 99:	140 – PGM 140:
	018 – PGM 18:	059 – PGM 59:	100 – PGM 100:	141 – PGM 141:
	019 – PGM 19:	060 – PGM 60:	101 – PGM 101:	142 – PGM 142:
	020 – PGM 20:	061 – PGM 61:	102 – PGM 102:	143 – PGM 143:
	021 – PGM 21:	062 – PGM 62:	103 – PGM 103:	144 – PGM 144:
	022 – PGM 22:	063 – PGM 63:	104 – PGM 104:	145 – PGM 145:
	023 – PGM 23:	064 – PGM 64:	105 – PGM 105:	146 – PGM 146:
	024 – PGM 24:	065 – PGM 65:	106 – PGM 106:	147 – PGM 147:
	025 – PGM 25:	066 – PGM 66:	107 – PGM 107:	148 – PGM 148:
	026 – PGM 26:	067 – PGM 67:	108 – PGM 108:	149 – PGM 149:
	027 – PGM 27:	068 – PGM 68:	109 – PGM 109:	150 – PGM 150:
	028 – PGM 28:	069 – PGM 69:	110 – PGM 110:	151 – PGM 151:
	029 – PGM 29:	070 – PGM 70:	111 – PGM 111:	152 – PGM 152:
	030 – PGM 30:	071 – PGM 71:	112 – PGM 112:	153 – PGM 153:
	031 – PGM 31:	072 – PGM 72:	113 – PGM 113:	154 – PGM 154:
	032 – PGM 32:	073 – PGM 73:	114 – PGM 114:	155 – PGM 155:
	033 – PGM 33:	074 – PGM 74:	115 – PGM 115:	156 – PGM 156:
	034 – PGM 34:	075 – PGM 75:	116 – PGM 116:	157 – PGM 157:
	035 – PGM 35:	076 – PGM 76:	117 – PGM 117:	158 – PGM 158:
	036 – PGM 36:	077 – PGM 77:	118 – PGM 118:	159 – PGM 159:
	037 – PGM 37:	078 – PGM 78:	119 – PGM 119:	160 – PGM 160:
	038 – PGM 38:	079 – PGM 79:	120 – PGM 120:	161 – PGM 161:
	039 – PGM 39:	080 – PGM 80:	121 – PGM 121:	162 – PGM 162:
	040 – PGM 40:	081 – PGM 81:	122 – PGM 122:	163 – PGM 163:
	041 – PGM 41:	082 – PGM 82:	123 – PGM 123:	164 – PGM 164:

[010] PGM Attributes			
000 – Main Bell Mask Description on page 33	<input checked="" type="checkbox"/> 01 – Fire Alarm <input checked="" type="checkbox"/> 02 – CO Alarm	<input checked="" type="checkbox"/> 03 – Burglary Alarm <input checked="" type="checkbox"/> 04 – Flood Alarm	<input checked="" type="checkbox"/> 06 – Bell Squawks
001-164 PGM Attributes PGM 1-164:	100 – Null PGM		
	101 – Fire and Burglary	<input checked="" type="checkbox"/> 01 – True Output	
	102 – Delay Fire and Burg	<input checked="" type="checkbox"/> 01 – True Output	
	103 – Sensor Reset [*][7][2]	<input type="checkbox"/> 03 – Code Required	
	109 – Courtesy Pulse	<input checked="" type="checkbox"/> 01 – True Output	
	111 – Keypad Buzzer Follow	<input checked="" type="checkbox"/> 01 – True Output <input type="checkbox"/> 02 – Timed Output <input checked="" type="checkbox"/> 09 – Entry Delay <input checked="" type="checkbox"/> 10 – Exit Delay	<input checked="" type="checkbox"/> 11 – Door Chime <input checked="" type="checkbox"/> 12 – Keypad Buzzer Zone <input checked="" type="checkbox"/> 13 – Audible Exit Zone <input checked="" type="checkbox"/> 14 – Auto-Arm Pre-Alert
	114 – Ready To Arm	<input checked="" type="checkbox"/> 01 – True Output	
	115 – Armed Status	<input checked="" type="checkbox"/> 01 – True Output	
	116 – Armed Away Mode	<input checked="" type="checkbox"/> 01 – True Output	
	117 – Armed Stay Mode	<input checked="" type="checkbox"/> 01 – True Output	
	121 – Command Output 1	<input checked="" type="checkbox"/> 01 – True Output <input checked="" type="checkbox"/> 02 – Timed Output <input checked="" type="checkbox"/> 03 – Code Required	<input checked="" type="checkbox"/> Schedule 00
	122 – Command Output 2	<input checked="" type="checkbox"/> 01 – True Output <input checked="" type="checkbox"/> 02 – Timed Output <input type="checkbox"/> 03 – Code Required	<input checked="" type="checkbox"/> Schedule 00
	123 – Command Output 3	<input checked="" type="checkbox"/> 01 – True Output <input checked="" type="checkbox"/> 02 – Timed Output <input type="checkbox"/> 03 – Code Required	<input checked="" type="checkbox"/> Schedule 00
	124 – Command Output 4	<input checked="" type="checkbox"/> 01 – True Output <input checked="" type="checkbox"/> 02 – Timed Output <input type="checkbox"/> 03 – Code Required	<input checked="" type="checkbox"/> Schedule 00
	129 – Partition Status Alarm Memory	<input checked="" type="checkbox"/> 01 – True Output	
	132 – Holdup Output	<input checked="" type="checkbox"/> 01 – True Output <input type="checkbox"/> 02 – Timed Output	
	146 – TLM And Alarm	<input checked="" type="checkbox"/> 01 – True Output	
	147 – Kissoff Output	<input checked="" type="checkbox"/> 01 – True Output	
	148 – Ground Start	<input checked="" type="checkbox"/> 01 – True Output	
	149 – Alternate Communicator	<input checked="" type="checkbox"/> 01 – True Output <input checked="" type="checkbox"/> 02 – Timed Output <input type="checkbox"/> 04 – Fire Alarm <input type="checkbox"/> 05 – Panic Alarm <input type="checkbox"/> 06 – Burglary Alarm	<input type="checkbox"/> 07 – Open/Close <input type="checkbox"/> 08 – Zone Auto Bypass <input type="checkbox"/> 09 – Medical Alarm <input type="checkbox"/> 10 – Burglary Verified <input type="checkbox"/> 11 – Open After Alarm <input type="checkbox"/> 12 – Emergency Alarm <input type="checkbox"/> 13 – Duress Alarm <input type="checkbox"/> 14 – Holdup Verified
	155 – System Trouble	<input checked="" type="checkbox"/> 01 – True Output <input type="checkbox"/> 02 – Timed Output <input checked="" type="checkbox"/> 04 – Service Required <input checked="" type="checkbox"/> 05 – Loss of Clock	<input checked="" type="checkbox"/> 06 – AC Fail <input checked="" type="checkbox"/> 07 – DC Fail <input checked="" type="checkbox"/> 08 – TLM Trouble <input checked="" type="checkbox"/> 09 – FT <input checked="" type="checkbox"/> 11 – Zone Fault <input checked="" type="checkbox"/> 12 – Zone Tamper <input checked="" type="checkbox"/> 13 – Zone Low Battery <input checked="" type="checkbox"/> 10 – Ethernet
	156 – Latched System Event	<input checked="" type="checkbox"/> 01 – True Output <input type="checkbox"/> 02 – Timed Output <input checked="" type="checkbox"/> 04 – Fire Alarm <input checked="" type="checkbox"/> 05 – Panic Alarm <input checked="" type="checkbox"/> 06 – Burglary Alarm	<input checked="" type="checkbox"/> 07 – Medical Alarm <input checked="" type="checkbox"/> 08 – Supervisory <input checked="" type="checkbox"/> 09 – Priority Event <input checked="" type="checkbox"/> 10 – Holdup <input checked="" type="checkbox"/> 11 – Duress Alarm <input checked="" type="checkbox"/> 12 – Emergency Alarm <input checked="" type="checkbox"/> 13 – Fire Supervisory <input checked="" type="checkbox"/> 14 – Fire Trouble <input checked="" type="checkbox"/> 15 – CO Alarm
	157 – System Tamper	<input checked="" type="checkbox"/> 01 – True Output <input type="checkbox"/> 02 – Timed Output	<input checked="" type="checkbox"/> 09 – Module Tamper <input checked="" type="checkbox"/> 10 – Zone Tamper
	161 – DC Trouble	<input checked="" type="checkbox"/> 01 – True Output <input type="checkbox"/> 02 – Timed Output	<input checked="" type="checkbox"/> 09 – Battery Low <input checked="" type="checkbox"/> 10 – Battery Absent
	165 – Prox Used	<input checked="" type="checkbox"/> 01 – True Output	
	175 – Bell Prog Access	<input checked="" type="checkbox"/> 01 – True Output	
	176 – Remote Operation	<input checked="" type="checkbox"/> 01 – True Output	

[010]	PGM Attribute Assignment:			
(3-Digit Decimal) Valid Range: 001-255 Default: 005 Description on page 33	001 – PGM 1:	042 – PGM 42:	083 – PGM 83:	124 – PGM 124:
	002 – PGM 2:	043 – PGM 43:	084 – PGM 84:	125 – PGM 125:
	003 – PGM 3:	044 – PGM 44:	085 – PGM 85:	126 – PGM 126:
	004 – PGM 4:	045 – PGM 45:	086 – PGM 86:	127 – PGM 127:
	005 – PGM 5:	046 – PGM 46:	087 – PGM 87:	128 – PGM 128:
	006 – PGM 6:	047 – PGM 47:	088 – PGM 88:	129 – PGM 129:
	007 – PGM 7:	048 – PGM 48:	089 – PGM 89:	130 – PGM 130:
	008 – PGM 8:	049 – PGM 49:	090 – PGM 90:	131 – PGM 131:
	009 – PGM 9:	050 – PGM 50:	091 – PGM 91:	132 – PGM 132:
	010 – PGM 10:	051 – PGM 51:	092 – PGM 92:	133 – PGM 133:
	011 – PGM 11:	052 – PGM 52:	093 – PGM 93:	134 – PGM 134:
	012 – PGM 12:	053 – PGM 53:	094 – PGM 94:	135 – PGM 135:
	013 – PGM 13:	054 – PGM 54:	095 – PGM 95:	136 – PGM 136:
	014 – PGM 14:	055 – PGM 55:	096 – PGM 96:	137 – PGM 137:
	015 – PGM 15:	056 – PGM 56:	097 – PGM 97:	138 – PGM 138:
	016 – PGM 16:	057 – PGM 57:	098 – PGM 98:	139 – PGM 139:
	017 – PGM 17:	058 – PGM 58:	099 – PGM 99:	140 – PGM 140:
	018 – PGM 18:	059 – PGM 59:	100 – PGM 100:	141 – PGM 141:
	019 – PGM 19:	060 – PGM 60:	101 – PGM 101:	142 – PGM 142:
	020 – PGM 20:	061 – PGM 61:	102 – PGM 102:	143 – PGM 143:
	021 – PGM 21:	062 – PGM 62:	103 – PGM 103:	144 – PGM 144:
	022 – PGM 22:	063 – PGM 63:	104 – PGM 104:	145 – PGM 145:
	023 – PGM 23:	064 – PGM 64:	105 – PGM 105:	146 – PGM 146:
	024 – PGM 24:	065 – PGM 65:	106 – PGM 106:	147 – PGM 147:
	025 – PGM 25:	066 – PGM 66:	107 – PGM 107:	148 – PGM 148:
	026 – PGM 26:	067 – PGM 67:	108 – PGM 108:	149 – PGM 149:
	027 – PGM 27:	068 – PGM 68:	109 – PGM 109:	150 – PGM 150:
	028 – PGM 28:	069 – PGM 69:	110 – PGM 110:	151 – PGM 151:
	029 – PGM 29:	070 – PGM 70:	111 – PGM 111:	152 – PGM 152:
	030 – PGM 30:	071 – PGM 71:	112 – PGM 112:	153 – PGM 153:
	031 – PGM 31:	072 – PGM 72:	113 – PGM 113:	154 – PGM 154:
	032 – PGM 32:	073 – PGM 73:	114 – PGM 114:	155 – PGM 155:
	033 – PGM 33:	074 – PGM 74:	115 – PGM 115:	156 – PGM 156:
	034 – PGM 34:	075 – PGM 75:	116 – PGM 116:	157 – PGM 157:
	035 – PGM 35:	076 – PGM 76:	117 – PGM 117:	158 – PGM 158:
	036 – PGM 36:	077 – PGM 77:	118 – PGM 118:	159 – PGM 159:
	037 – PGM 37:	078 – PGM 78:	119 – PGM 119:	160 – PGM 160:
	038 – PGM 38:	079 – PGM 79:	120 – PGM 120:	161 – PGM 161:
	039 – PGM 39:	080 – PGM 80:	121 – PGM 121:	162 – PGM 162:
	040 – PGM 40:	081 – PGM 81:	122 – PGM 122:	163 – PGM 163:
	041 – PGM 41:	082 – PGM 82:	123 – PGM 123:	164 – PGM 164:

Section 6: Programming Worksheets

[011] PGM Config. Options		(4-Digit Decimal) Valid Range: 000-028		Description on page 37	
	PGM	Zone Follower by Zone (000-128; Default 000)	Prox. Used (000-095; Default 000)	Command Output (000-004; Default 000)	
Alarm Panel	001 PGM 1				
	002 PGM 2				
	003 PGM 3				
	004 PGM 4				
HSM2204 #1	005 PGM 5				
	006 PGM 6				
	007 PGM 7				
	008 PGM 8				
HSM2204 #2	009 PGM 9				
	010 PGM 10				
	011 PGM 11				
	012 PGM 12				
HSM2204 #3	013 PGM 13				
	014 PGM 14				
	015 PGM 15				
	016 PGM 16				
HSM2204 #4	017 PGM 17				
	018 PGM 18				
	019 PGM 19				
	020 PGM 20				
HSM2208 #1	037 PGM 37				
	038 PGM 38				
	039 PGM 39				
	040 PGM 40				
	041 PGM 41				
	042 PGM 42				
	043 PGM 43				
	044 PGM 44				
HSM2208 #2	045 PGM 45				
	046 PGM 46				
	047 PGM 47				
	048 PGM 48				
	049 PGM 49				
	050 PGM 50				
	051 PGM 51				
	052 PGM 52				

Section 6: Programming Worksheets

	PGM	Zone Follower by Zone (001-128; Default 000)	Prox. Used (000-095; Default 000)	Command Output (001-004; Default 000)	
HSM2208 #3	053 PGM 53				
	054 PGM 54				
	055 PGM 55				
	056 PGM 56				
	057 PGM 57				
	058 PGM 58				
	059 PGM 59				
	060 PGM 60				
HSM2208 #4	061 PGM 61				
	062 PGM 62				
	063 PGM 63				
	064 PGM 64				
	065 PGM 65				
	066 PGM 66				
	067 PGM 67				
	068 PGM 68				
HSM2208 #5	069 PGM 69				
	070 PGM 70				
	071 PGM 71				
	072 PGM 72				
	073 PGM 73				
	074 PGM 74				
	075 PGM 75				
	076 PGM 76				
HSM2208 #6	077 PGM 77				
	078 PGM 78				
	079 PGM 79				
	080 PGM 80				
	081 PGM 81				
	082 PGM 82				
	083 PGM 83				
	084 PGM 84				
HSM2208 #7	085 PGM 85				
	086 PGM 86				
	087 PGM 87				
	088 PGM 88				
	089 PGM 89				
	090 PGM 90				
	091 PGM 91				
	092 PGM 92				
HSM2208 #8	093 PGM 93				
	094 PGM 94				
	095 PGM 95				
	096 PGM 96				
	097 PGM 97				
	098 PGM 98				
	099 PGM 99				
	100 PGM 100				
HSM2208 #9	101 PGM 101				
	102 PGM 102				
	103 PGM 103				
	104 PGM 104				
	105 PGM 105				
	106 PGM 106				
	107 PGM 107				
	108 PGM 108				

Section 6: Programming Worksheets

	PGM	Zone Follower by Zone (001-128; Default 000)	Prox. Used (000-095; Default 000)	Command Output (001-004; Default 000)	
HSM2208 #10	109 PGM 109				
	110 PGM 110				
	111 PGM 111				
	112 PGM 112				
	113 PGM 113				
	114 PGM 114				
	115 PGM 115				
HSM2208 #11	116 PGM 116				
	117 PGM 117				
	118 PGM 118				
	119 PGM 119				
	120 PGM 120				
	121 PGM 121				
	122 PGM 122				
HSM2208 #12	123 PGM 123				
	124 PGM 124				
	125 PGM 125				
	126 PGM 126				
	127 PGM 127				
	128 PGM 128				
	129 PGM 129				
HSM2208 #13	130 PGM 130				
	131 PGM 131				
	132 PGM 132				
	133 PGM 133				
	134 PGM 134				
	135 PGM 135				
	136 PGM 136				
HSM2208 #14	137 PGM 137				
	138 PGM 138				
	139 PGM 139				
	140 PGM 140				
	141 PGM 141				
	142 PGM 142				
	143 PGM 143				
HSM2208 #15	144 PGM 144				
	145 PGM 145				
	146 PGM 146				
	147 PGM 147				
	148 PGM 148				
	149 PGM 149				
	150 PGM 150				
HSM2208 #16	151 PGM 151				
	152 PGM 152				
	153 PGM 153				
	154 PGM 154				
	155 PGM 155				
	156 PGM 156				
	157 PGM 157				
HSM2208 #16	158 PGM 158				
	159 PGM 159				
	160 PGM 160				
	161 PGM 161				
	162 PGM 162				
	163 PGM 163				
	164 PGM 164				

System Lockout

[012] System Lockout	
(3-Digit Decimal)	Keypad Lockout: (Range: 000-255; Default 000)
Description on page 37	Keypad Lockout Duration: (Range: 001-255; Default 000)
	Remote Lockout: (Range: 003-255; Default 006)
	Remote Lockout Duration: (Range: 001-255; Default 060)

System Options

[013] System Options 1 Description on page 37	<input type="checkbox"/> 1 – NC Loop/EOL <input type="checkbox"/> 2 – DEOL/SEOL <input checked="" type="checkbox"/> 3 – Show All Troubles When Armed <input type="checkbox"/> 4 – Tamper/Faults Do Not Show As Open <input checked="" type="checkbox"/> 5 – Auto-Arm Schedule in [*][6] <input checked="" type="checkbox"/> 6 – Audible Exit Fault <input checked="" type="checkbox"/> 7 – Event Buffer Follows Swinger <input type="checkbox"/> 8 – Temporal Three Fire Signaling	[014] System Options 2 Description on pg 38	<input type="checkbox"/> 1 – Bell Squawk <input type="checkbox"/> 2 – Bell Duration Auto-Arm <input type="checkbox"/> 3 – Bell Squawk on Exit <input type="checkbox"/> 4 – Bell Squawk on Entry <input type="checkbox"/> 5 – Bell Squawk on Trouble <input type="checkbox"/> 6 – Not Used <input type="checkbox"/> 7 – Exit Delay Termination <input type="checkbox"/> 8 – Fire Bell Continues
[015] System Options 3 Description on page 38	<input checked="" type="checkbox"/> 1 – [F] Key <input type="checkbox"/> 2 – [P] Key Annunciation <input type="checkbox"/> 3 – Quick Exit <input checked="" type="checkbox"/> 4 – Quick Arming/Function Key <input type="checkbox"/> 5 – Not Used <input type="checkbox"/> 6 – Master Code Not User Changeable <input checked="" type="checkbox"/> 7 – Telephone Line Monitor Enable <input type="checkbox"/> 8 – TLM Audible When Armed	[016] System Options 4 Description on pg 38	<input checked="" type="checkbox"/> 1 – AC Trouble Display <input type="checkbox"/> 2 – AC Trouble Light Flashes <input type="checkbox"/> 3 – Keypad Blanking <input type="checkbox"/> 4 – Keypad Blanking Requires Code <input checked="" type="checkbox"/> 5 – Keypad Backlighting <input type="checkbox"/> 6 – Power Save Mode <input type="checkbox"/> 7 – Bypass Display When Armed <input type="checkbox"/> 8 – Keypad Tamper Enabled
[017] System Options 5 Description on page 39	<input type="checkbox"/> 1 – Chime on Opening <input type="checkbox"/> 2 – Chime on Closing <input type="checkbox"/> 3 – Not Used <input type="checkbox"/> 4 – Multi-Hit <input type="checkbox"/> 5 – Late to Close <input type="checkbox"/> 6 – Daylight Savings Time <input type="checkbox"/> 7 – Not Used <input type="checkbox"/> 8 – Bell Squawk on Away Arm/Disarm	[018] System Options 6 Description on pg 39	<input type="checkbox"/> 1 – Test Transmission Exception <input type="checkbox"/> 2 – Real-Time Bypass Reporting <input type="checkbox"/> 3 – Not Used <input type="checkbox"/> 4 – Not Used <input type="checkbox"/> 5 – Keypad Buzzer Alarm <input type="checkbox"/> 6 – Not Used <input type="checkbox"/> 7 – Exit Delay Restart <input type="checkbox"/> 8 – AC Fail Trouble Beeps
[019] System Options 7 Description on page 40	<input type="checkbox"/> 1 – Not Used <input type="checkbox"/> 2 – Latching Troubles <input type="checkbox"/> 3 – Not Used <input type="checkbox"/> 4 – Not Used <input type="checkbox"/> 5 – Audible Bus Fault <input type="checkbox"/> 6 – Duress Code <input checked="" type="checkbox"/> 7 – Temperature in Celsius <input type="checkbox"/> 8 – Not Used	[020] System Options 8 Description on pg 40	<input type="checkbox"/> 1 – Not Used <input type="checkbox"/> 2 – Not Used <input type="checkbox"/> 3 – [][8] Access While Armed <input type="checkbox"/> 4 – Not Used <input type="checkbox"/> 5 – Not Used <input type="checkbox"/> 6 – Not Used <input type="checkbox"/> 7 – Not Used <input type="checkbox"/> 8 – Not Used
[021] System Options 9 Description on page 40	<input type="checkbox"/> 1 – Not Used <input type="checkbox"/> 2 – Not Used <input type="checkbox"/> 3 – Auto-Arming Bypass <input type="checkbox"/> 4 – Not Used <input type="checkbox"/> 5 – Not Used <input type="checkbox"/> 6 – Not Used <input type="checkbox"/> 7 – Not Used <input type="checkbox"/> 8 – Audible Exit Delay for Stay Arm	[022] System Options 10 Description on pg 40	<input type="checkbox"/> 1 – [F] Key Option <input type="checkbox"/> 2 – Not Used <input type="checkbox"/> 3 – Not Used <input type="checkbox"/> 4 – Transmission Counter in Hours <input type="checkbox"/> 5 – Away to Stay Toggle <input type="checkbox"/> 6 – Not Used <input type="checkbox"/> 7 – Trouble Beeps Are Silent <input type="checkbox"/> 8 – Keyswitch Arms in Away Mode
[023] System Options 11 Description on page 40	<input type="checkbox"/> 1 – Ready LED Flash for Force Arm <input type="checkbox"/> 2 – Not Used <input type="checkbox"/> 3 – Not Used <input type="checkbox"/> 4 – Access Code Required for [][1] <input type="checkbox"/> 5 – Access Code Required for [][2] <input type="checkbox"/> 6 – Access Code Required for [][3] <input type="checkbox"/> 7 – Access Code Required for [][4] <input type="checkbox"/> 8 – [][6] Accessibility Option	[024] System Options 12 Description on pg 41	<input type="checkbox"/> 1 – 50Hz AC / 60 Hz AC <input type="checkbox"/> 2 – Crystal Timebase <input type="checkbox"/> 3 – AC/DC Inhibits Arming <input type="checkbox"/> 4 – Tamper Inhibit Arming <input type="checkbox"/> 5 – Real Time Clock Option <input type="checkbox"/> 6 – Not Used <input type="checkbox"/> 7 – Not Used <input type="checkbox"/> 8 – DLS Disconnect
[025] System Options 13 Description on page 41	<input type="checkbox"/> 1 – European Dial <input checked="" type="checkbox"/> 2 – Force Dial <input type="checkbox"/> 3 – Not Used <input type="checkbox"/> 4 – Not Used <input type="checkbox"/> 5 – ID Tone <input type="checkbox"/> 6 – Tone Generated-2100Hz <input type="checkbox"/> 7 – 1 Hour DLS Window <input type="checkbox"/> 8 – FTC Audible Bell		
[040] User Authentication Description on page 42	<input checked="" type="checkbox"/> 1 – User Code or Prox. Tag <input type="checkbox"/> 2 – User Code and Prox. Tag		

[041] Access Code Digits Description on page 42	<input checked="" type="checkbox"/> 00 – 4-Digit Access Codes <input type="checkbox"/> 01 – 6-Digit Access Codes	
[042] Event Verification Description on page 42	01 – Burglary Verified Counter (Default: 002); 03 – Burglary Verification Selection:	001 – Police Code (Default) 002 – Cross Zoning
[151] Partition 1 Auto-Arm/Disarm Description on page 42 (3-digit decimal) (000-255 minutes)	001 – Partition 1 Auto-Arming Times: (4-digit HH:MM) Default: 9999 002 – Partition 1 Auto-Disarm Times: (4-digit HH:MM) Default: 9999 003 – Partition 1 Auto-Disarming Holiday Schedule: 004 – Partition 1 Auto-Arming Pre-Alert (Default: 004): 005 – Partition 1 Auto-Arming Postpone Timer (Default: 000): 006 – Partition 1 No Activity Arming Timer (Default: 000): 007 – Partition 1 No Activity Arming Pre-Alert Timer (Default: 001):	24-Hour: Sunday: Thursday: Monday: Friday: Tuesday: Saturday: Wednesday: 24-Hour: Sunday: Thursday: Monday: Friday: Tuesday: Saturday: Wednesday: Holiday 1: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off Holiday 2: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off Holiday 3: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off Holiday 4: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off
[152] Partition 2 Auto-Arm/Disarm (3-digit decimal) (000-255 minutes)	001 – Partition 2 Auto-Arming Times: (4-digit HH:MM) Default: 9999 002 – Partition 2 Auto-Disarm Times: (4-digit HH:MM) Default: 9999 003 – Partition 2 Auto-Disarming Holiday Schedule: 004 – Partition 2 Auto-Arming Pre-Alert (Default: 004): 005 – Partition 2 Auto-Arming Postpone Timer (Default: 000): 006 – Partition 2 No Activity Arming Timer (Default: 000): 007 – Partition 2 No Activity Arming Pre-Alert Timer (Default: 001):	24-Hour: Sunday: Thursday: Monday: Friday: Tuesday: Saturday: Wednesday: 24-Hour: Sunday: Thursday: Monday: Friday: Tuesday: Saturday: Wednesday: Holiday 1: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off Holiday 2: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off Holiday 3: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off Holiday 4: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off
[153] Partition 3 Auto-Arm/Disarm Descriptions on page 42	001 – Partition 3 Auto-Arming Times: (4-digit HH:MM) Default: 9999	24-Hour: Sunday: Thursday: Monday: Friday: Tuesday: Saturday: Wednesday:

(3-digit decimal) (000-255 minutes)	002 – Partition 3 Auto-Disarm Times: (4-digit HH:MM) Default: 9999	24-Hour: Sunday: Thursday: Monday: Friday: Tuesday: Saturday: Wednesday:	
	003 – Partition 3 Auto-Disarming Holiday Schedule:	Holiday 1: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off Holiday 2: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off Holiday 3: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off Holiday 4: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off	
	004 – Partition 3 Auto-Arming Pre-Alert (Default: 004):		
	005 – Partition 3 Auto-Arming Postpone Timer (Default: 000):		
	006 – Partition 3 No Activity Arming Timer (Default: 000):		
	007 – Partition 3 No Activity Arming Pre-Alert Timer (Default: 001):		
	[154] Partition 4 Auto-Arm/Disarm		
	Descriptions on 42	001 – Partition 4 Auto-Arming Times: (4-digit HH:MM) Default: 9999	24-Hour: Sunday: Thursday: Monday: Friday: Tuesday: Saturday: Wednesday:
	(3-digit decimal) (000-255 minutes)	002 – Partition 4 Auto-Disarm Times: (4-digit HH:MM) Default: 9999	24-Hour: Sunday: Thursday: Monday: Friday: Tuesday: Saturday:
		003 – Partition 4 Auto-Disarming Holiday Schedule:	Holiday 1: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off Holiday 2: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off Holiday 3: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off Holiday 4: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off
004 – Partition 4 Auto-Arming Pre-Alert (Default: 004):			
005 – Partition 4 Auto-Arming Postpone Timer (Default: 000):			
006 – Partition 4 No Activity Arming Timer (Default: 000):			
007 – Partition 4 No Activity Arming Pre-Alert Timer (Default: 001):			
[155] Partition 5 Auto-Arm/Disarm			
Descriptions on 42	001 – Partition 5 Auto-Arming Times: (4-digit HH:MM) Default: 9999	24-Hour: Sunday: Thursday: Monday: Friday: Tuesday: Saturday: Wednesday:	
(3-digit decimal) (000-255 minutes)	002 – Partition 5 Auto-Disarm Times: (4-digit HH:MM) Default: 9999	24-Hour: Sunday: Thursday: Monday: Friday: Tuesday: Saturday: Wednesday:	
	003 – Partition 5 Auto-Disarming Holiday Schedule:	Holiday 1: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off Holiday 2: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off Holiday 3: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off Holiday 4: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off	
	004 – Partition 5 Auto-Arming Pre-Alert (Default: 004):		
	005 – Partition 5 Auto-Arming Postpone Timer (Default: 000):		

	006 – Partition 5 No Activity Arming Timer (Default: 000):	
	007 – Partition 5 No Activity Arming Pre-Alert Timer (Default: 001):	
[156] Partition 6 Auto-Arm/Disarm	001 – Partition 6 Auto-Arming Times: (4-digit HH:MM) Default: 9999	24-Hour: Sunday: Thursday: Monday: Friday: Tuesday: Saturday: Wednesday:
Descriptions on 42	002 – Partition 6 Auto-Disarm Times: (4-digit HH:MM) Default: 9999	24-Hour: Sunday: Thursday: Monday: Friday: Tuesday: Saturday: Wednesday:
	003 – Partition 6 Auto-Disarming Holiday Schedule:	Holiday 1: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off Holiday 2: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off Holiday 3: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off Holiday 4: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off
(3-digit decimal) (000-255 minutes)	004 – Partition 6 Auto-Arming Pre-Alert (Default: 004):	
	005 – Partition 6 Auto-Arming Postpone Timer (Default: 000):	
	006 – Partition 6 No Activity Arming Timer (Default: 000):	
	007 – Partition 6 No Activity Arming Pre-Alert Timer (Default: 001):	
[157] Partition 7 Auto-Arm/Disarm	001 – Partition 7 Auto-Arming Times: (4-digit HH:MM) Default: 9999	24-Hour: Sunday: Thursday: Monday: Friday: Tuesday: Saturday: Wednesday:
Descriptions on 42	002 – Partition 7 Auto-Disarm Times: (4-digit HH:MM) Default: 9999	24-Hour: Sunday: Thursday: Monday: Friday: Tuesday: Saturday: Wednesday:
	003 – Partition 7 Auto-Disarming Holiday Schedule:	Holiday 1: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off Holiday 2: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off Holiday 3: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off Holiday 4: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off
(3-digit decimal) (000-255 minutes)	004 – Partition 7 Auto-Arming Pre-Alert (Default: 004):	
	005 – Partition 7 Auto-Arming Postpone Timer (Default: 000):	
	006 – Partition 7 No Activity Arming Timer (Default: 000):	
	007 – Partition 7 No Activity Arming Pre-Alert Timer (Default: 001):	
[158] Partition 8 Auto-Arm/Disarm	001 – Partition 8 Auto-Arming Times: (4-digit HH:MM) Default: 9999	24-Hour: Sunday: Thursday: Monday: Friday: Tuesday: Saturday: Wednesday:
Descriptions on 42		

(3-digit decimal) (000-255 minutes)	002 – Partition 8 Auto-Disarm Times: (4-digit HH:MM) Default: 9999	24-Hour: Sunday: Thursday: Monday: Friday: Tuesday: Saturday: Wednesday:
	003 – Partition 8 Auto-Disarming Holiday Schedule:	Holiday 1: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off Holiday 2: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off Holiday 3: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off Holiday 4: <input type="checkbox"/> On <input checked="" type="checkbox"/> Off
	004 – Partition 8 Auto-Arming Pre-Alert (Default: 004):	
	005 – Partition 8 Auto-Arming Postpone Timer (Default: 000):	
	006 – Partition 8 No Activity Arming Timer (Default: 000):	
	007 – Partition 8 No Activity Arming Pre-Alert Timer (Default: 001):	

[200] Partition Mask Descriptions on 42	001 – Partition 1 to 8 Enable Mask	<input checked="" type="checkbox"/> – Partition 1 <input type="checkbox"/> – Partition 2 <input type="checkbox"/> – Partition 3 <input type="checkbox"/> – Partition 4 <input type="checkbox"/> – Partition 5 <input type="checkbox"/> – Partition 6 <input type="checkbox"/> – Partition 7 <input type="checkbox"/> – Partition 8
---	------------------------------------	---

[201]-[208] Partition Zone Assignment									(Description on page 43)																	
[201] Partition 1 Zone Assignment									[202] Partition 2 Zone Assignment									[203] Partition 3 Zone Assignment								
Bit	1	2	3	4	5	6	7	8	Bit	1	2	3	4	5	6	7	8	Bit	1	2	3	4	5	6	7	8
001 – 01-08	<input checked="" type="checkbox"/>	001 – 01-08	<input type="checkbox"/>	001 – 01-08	<input type="checkbox"/>																					
002 – 09-16	<input type="checkbox"/>	002 – 09-16	<input type="checkbox"/>	002 – 09-16	<input type="checkbox"/>																					
003 – 17-24	<input type="checkbox"/>	003 – 17-24	<input type="checkbox"/>	003 – 17-24	<input type="checkbox"/>																					
004 – 25-32	<input type="checkbox"/>	004 – 25-32	<input type="checkbox"/>	004 – 25-32	<input type="checkbox"/>																					
005 – 33-40	<input type="checkbox"/>	005 – 33-40	<input type="checkbox"/>	005 – 33-40	<input type="checkbox"/>																					
006 – 41-48	<input type="checkbox"/>	006 – 41-48	<input type="checkbox"/>	006 – 41-48	<input type="checkbox"/>																					
007 – 49-56	<input type="checkbox"/>	007 – 49-56	<input type="checkbox"/>	007 – 49-56	<input type="checkbox"/>																					
008 – 57-64	<input type="checkbox"/>	008 – 57-64	<input type="checkbox"/>	008 – 57-64	<input type="checkbox"/>																					
009 – 65-72	<input type="checkbox"/>	009 – 65-72	<input type="checkbox"/>	009 – 65-72	<input type="checkbox"/>																					
010 – 73-80	<input type="checkbox"/>	010 – 73-80	<input type="checkbox"/>	010 – 73-80	<input type="checkbox"/>																					
011 – 81-88	<input type="checkbox"/>	011 – 81-88	<input type="checkbox"/>	011 – 81-88	<input type="checkbox"/>																					
012 – 89-96	<input type="checkbox"/>	012 – 89-96	<input type="checkbox"/>	012 – 89-96	<input type="checkbox"/>																					
013 – 97-104	<input type="checkbox"/>	013 – 97-104	<input type="checkbox"/>	013 – 97-104	<input type="checkbox"/>																					
014 – 105-112	<input type="checkbox"/>	014 – 105-112	<input type="checkbox"/>	014 – 105-112	<input type="checkbox"/>																					
015 – 113-120	<input type="checkbox"/>	015 – 113-120	<input type="checkbox"/>	015 – 113-120	<input type="checkbox"/>																					
016 – 121-128	<input type="checkbox"/>	016 – 121-128	<input type="checkbox"/>	016 – 121-128	<input type="checkbox"/>																					

Section 6: Programming Worksheets

[204] Partition 4 Zone Assignment									[205] Partition 5 Zone Assignment									[206] Partition 6 Zone Assignment								
Bit	1	2	3	4	5	6	7	8	Bit	1	2	3	4	5	6	7	8	Bit	1	2	3	4	5	6	7	8
001 – 01-08	<input type="checkbox"/>	001 – 01-08	<input type="checkbox"/>	001 – 01-08	<input type="checkbox"/>																					
002 – 09-16	<input type="checkbox"/>	002 – 09-16	<input type="checkbox"/>	002 – 09-16	<input type="checkbox"/>																					
003 – 17-24	<input type="checkbox"/>	003 – 17-24	<input type="checkbox"/>	003 – 17-24	<input type="checkbox"/>																					
004 – 25-32	<input type="checkbox"/>	004 – 25-32	<input type="checkbox"/>	004 – 25-32	<input type="checkbox"/>																					
005 – 33-40	<input type="checkbox"/>	005 – 33-40	<input type="checkbox"/>	005 – 33-40	<input type="checkbox"/>																					
006 – 41-48	<input type="checkbox"/>	006 – 41-48	<input type="checkbox"/>	006 – 41-48	<input type="checkbox"/>																					
007 – 49-56	<input type="checkbox"/>	007 – 49-56	<input type="checkbox"/>	007 – 49-56	<input type="checkbox"/>																					
008 – 57-64	<input type="checkbox"/>	008 – 57-64	<input type="checkbox"/>	008 – 57-64	<input type="checkbox"/>																					
009 – 65-72	<input type="checkbox"/>	009 – 65-72	<input type="checkbox"/>	009 – 65-72	<input type="checkbox"/>																					
010 – 73-80	<input type="checkbox"/>	010 – 73-80	<input type="checkbox"/>	010 – 73-80	<input type="checkbox"/>																					
011 – 81-88	<input type="checkbox"/>	011 – 81-88	<input type="checkbox"/>	011 – 81-88	<input type="checkbox"/>																					
012 – 89-96	<input type="checkbox"/>	012 – 89-96	<input type="checkbox"/>	012 – 89-96	<input type="checkbox"/>																					
013 – 97-104	<input type="checkbox"/>	013 – 97-104	<input type="checkbox"/>	013 – 97-104	<input type="checkbox"/>																					
014 – 105-112	<input type="checkbox"/>	014 – 105-112	<input type="checkbox"/>	014 – 105-112	<input type="checkbox"/>																					
015 – 113-120	<input type="checkbox"/>	015 – 113-120	<input type="checkbox"/>	015 – 113-120	<input type="checkbox"/>																					
016 – 121-128	<input type="checkbox"/>	016 – 121-128	<input type="checkbox"/>	016 – 121-128	<input type="checkbox"/>																					
[207] Partition 7 Zone Assignment									[208] Partition 8 Zone Assignment																	
Bit	1	2	3	4	5	6	7	8	Bit	1	2	3	4	5	6	7	8									
001 – 01-08	<input type="checkbox"/>	001 – 01-08	<input type="checkbox"/>																							
002 – 09-16	<input type="checkbox"/>	002 – 09-16	<input type="checkbox"/>																							
003 – 17-24	<input type="checkbox"/>	003 – 17-24	<input type="checkbox"/>																							
004 – 25-32	<input type="checkbox"/>	004 – 25-32	<input type="checkbox"/>																							
005 – 33-40	<input type="checkbox"/>	005 – 33-40	<input type="checkbox"/>																							
006 – 41-48	<input type="checkbox"/>	006 – 41-48	<input type="checkbox"/>																							
007 – 49-56	<input type="checkbox"/>	007 – 49-56	<input type="checkbox"/>																							
008 – 57-64	<input type="checkbox"/>	008 – 57-64	<input type="checkbox"/>																							
009 – 65-72	<input type="checkbox"/>	009 – 65-72	<input type="checkbox"/>																							
010 – 73-80	<input type="checkbox"/>	010 – 73-80	<input type="checkbox"/>																							
011 – 81-88	<input type="checkbox"/>	011 – 81-88	<input type="checkbox"/>																							
012 – 89-96	<input type="checkbox"/>	012 – 89-96	<input type="checkbox"/>																							
013 – 97-104	<input type="checkbox"/>	013 – 97-104	<input type="checkbox"/>																							
014 – 105-112	<input type="checkbox"/>	014 – 105-112	<input type="checkbox"/>																							
015 – 113-120	<input type="checkbox"/>	015 – 113-120	<input type="checkbox"/>																							
016 – 121-128	<input type="checkbox"/>	016 – 121-128	<input type="checkbox"/>																							

[300] Panel/Receiver Communications Path			
	Description on page 43	001 – Receiver 1:	<input checked="" type="checkbox"/> PSTN-Phone Line <input type="checkbox"/> Alt Comm Auto Routing <input type="checkbox"/> Alt Comm Rec 1 <input type="checkbox"/> Alt Comm Rec 2 <input type="checkbox"/> Alt Comm Rec 3 <input type="checkbox"/> Alt Comm Rec 4
		002 – Receiver 2:	<input checked="" type="checkbox"/> PSTN-Phone Line <input type="checkbox"/> Alt Comm Auto Routing <input type="checkbox"/> Alt Comm Rec 1 <input type="checkbox"/> Alt Comm Rec 2 <input type="checkbox"/> Alt Comm Rec 3 <input type="checkbox"/> Alt Comm Rec 4
		003 – Receiver 3:	<input checked="" type="checkbox"/> PSTN-Phone Line <input type="checkbox"/> Alt Comm Auto Routing <input type="checkbox"/> Alt Comm Rec 1 <input type="checkbox"/> Alt Comm Rec 2 <input type="checkbox"/> Alt Comm Rec 3 <input type="checkbox"/> Alt Comm Rec 4
		004 – Receiver 4:	<input checked="" type="checkbox"/> PSTN-Phone Line <input type="checkbox"/> Alt Comm Auto Routing <input type="checkbox"/> Alt Comm Rec 1 <input type="checkbox"/> Alt Comm Rec 2 <input type="checkbox"/> Alt Comm Rec 3 <input type="checkbox"/> Alt Comm Rec 4
[301] Phone Number Programming (Default: DFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF)			
	(32-Digit HEX) Description on page 43	001 – Phone Number 1 Programming:	
		002 – Phone Number 2 Programming:	
		003 – Phone Number 3 Programming:	
		004 – Phone Number 4 Programming:	
[304] Call Waiting Cancel String (Description on page 43)			
	Call Waiting Cancel String (6-digit Hex; Default: DB70EF):		

[307] Zone Reporting Description on page 43 (001-128 = zones 1-128)											
<input checked="" type="checkbox"/> 1 – Alarm <input checked="" type="checkbox"/> 2 – Alarm Restore <input checked="" type="checkbox"/> 3 – Tamper <input checked="" type="checkbox"/> 4 – Tamper Restore <input checked="" type="checkbox"/> 5 – Fault <input checked="" type="checkbox"/> 6 – Fault Restore											
001	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	002	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	003	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	004	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	005	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
006	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	007	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	008	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	009	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	010	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
011	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	012	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	013	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	014	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	015	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
016	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	017	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	018	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	019	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	020	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
021	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	022	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	023	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	024	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	025	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
026	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	027	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	028	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	029	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	030	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
031	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	032	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	033	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	034	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	035	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
036	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	037	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	038	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	039	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	040	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
041	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	042	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	043	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	044	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	045	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
046	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	047	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	048	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	049	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	050	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
051	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	052	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	053	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	054	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	055	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
056	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	057	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	058	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	059	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	060	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
061	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	062	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	063	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	064	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	065	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
066	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	067	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	068	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	069	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	070	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
071	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	072	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	073	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	074	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	075	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
076	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	077	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	078	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	079	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	080	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
081	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	082	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	083	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	084	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	085	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
086	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	087	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	088	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	089	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	090	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
091	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	092	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	093	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	094	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	095	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
096	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	097	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	098	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	099	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	100	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
101	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	102	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	103	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	104	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	105	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
106	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	107	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	108	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	109	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	110	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
111	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	112	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	113	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	114	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	115	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
116	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	117	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	118	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	119	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	120	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
121	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	122	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	123	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	124	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	125	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		
126	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	127	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	128	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>						

[308] Event Reporting	Description on page 43		
001 – Miscellaneous Alarm 1	<input checked="" type="checkbox"/> 1 – Duress Alarm <input checked="" type="checkbox"/> 2 – Opening After Alarm <input checked="" type="checkbox"/> 3 – Recent Closing Alarm <input checked="" type="checkbox"/> 4 – Zone Expander Supervisory Alarm <input checked="" type="checkbox"/> 5 – Zone Expander Supervisory Alarm Restore <input checked="" type="checkbox"/> 6 – Burglary Verified <input checked="" type="checkbox"/> 7 – Burglary Not Verified Alarm <input checked="" type="checkbox"/> 8 – Alarm Cancel	002 – Miscellaneous Alarm 2	<input checked="" type="checkbox"/> 1 – Holdup Verified Alarm
011 – Priority Alarms 1	<input checked="" type="checkbox"/> 1 – Keypad Fire Alarm-F Key <input checked="" type="checkbox"/> 2 – Keypad Fire Restore <input checked="" type="checkbox"/> 3 – Keypad Medical Alarm-M Key <input checked="" type="checkbox"/> 4 – Keypad Medical Restore <input checked="" type="checkbox"/> 5 – Keypad Panic Alarm-P Key Alarm <input checked="" type="checkbox"/> 6 – Keypad Panic Restore <input checked="" type="checkbox"/> 7 – Auxiliary Input Alarm <input checked="" type="checkbox"/> 8 – Auxiliary Input Alarm Restore	021 – Fire Alarms 1	<input checked="" type="checkbox"/> 3 – PGM 2 2-Wire Alarm <input checked="" type="checkbox"/> 4 – PGM 2 2-Wire Alarm Restore
101 – Tamper Events	<input checked="" type="checkbox"/> 3 – Module Tamper <input checked="" type="checkbox"/> 4 – Module Tamper Restore <input checked="" type="checkbox"/> 5 – Keypad Lockout <input checked="" type="checkbox"/> 7 – Remote Lockout	201 – Open/Close Events 1	<input checked="" type="checkbox"/> 1 – User Closing <input checked="" type="checkbox"/> 2 – User Opening <input checked="" type="checkbox"/> 5 – Special Closing <input checked="" type="checkbox"/> 6 – Special Opening
202 – Open/Close Events 2	<input checked="" type="checkbox"/> 1 – Automatic Closing <input checked="" type="checkbox"/> 3 – Auto Arm Cancellation/Postpone	211 – Miscellaneous Open/Close Events	<input checked="" type="checkbox"/> 1 – Late to Close <input checked="" type="checkbox"/> 2 – Late to Open <input checked="" type="checkbox"/> 5 – Exit Fault
221 – Bypass Events	<input checked="" type="checkbox"/> 1 – Automatic Zone Bypass <input checked="" type="checkbox"/> 2 – Automatic Zone Unbypass <input checked="" type="checkbox"/> 3 – Partial Closing	301 – Panel Events 1	<input checked="" type="checkbox"/> 1 – Panel AC Fail Trouble <input checked="" type="checkbox"/> 2 – Panel AC Fail Restore <input checked="" type="checkbox"/> 3 – Panel Low Battery Trouble <input checked="" type="checkbox"/> 4 – Panel Low Battery Trouble Restore <input checked="" type="checkbox"/> 5 – Panel Battery Absent Trouble <input checked="" type="checkbox"/> 6 – Panel Battery Absent Trouble Restore
302 – Panel Events 2	<input checked="" type="checkbox"/> 1 – Bell Circuit Trouble <input checked="" type="checkbox"/> 2 – Bell Circuit Trouble Restore <input checked="" type="checkbox"/> 3 – Telephone Line Trouble <input checked="" type="checkbox"/> 4 – Telephone Line Trouble Restore <input checked="" type="checkbox"/> 5 – Auxiliary Trouble <input checked="" type="checkbox"/> 6 – Auxiliary Trouble Restore	305 – Panel Events 5	<input checked="" type="checkbox"/> 3 – PGM 2 2-Wire Trouble <input checked="" type="checkbox"/> 4 – PGM 2 2-Wire Trouble Restore
311 – Maintenance Events 1	<input checked="" type="checkbox"/> 1 – RF Jam Trouble <input checked="" type="checkbox"/> 2 – RF Jam Trouble Restore <input checked="" type="checkbox"/> 3 – Fire Trouble <input checked="" type="checkbox"/> 4 – Fire Trouble Restore <input checked="" type="checkbox"/> 5 – Cold Start <input checked="" type="checkbox"/> 6 – Delinquency	312 – Maintenance Events 2	<input checked="" type="checkbox"/> 1 – Installer Lead IN <input checked="" type="checkbox"/> 2 – Installer Lead OUT <input checked="" type="checkbox"/> 3 – DLS Lead IN <input checked="" type="checkbox"/> 4 – DLS Lead OUT <input checked="" type="checkbox"/> 5 – SA Lead IN <input checked="" type="checkbox"/> 6 – SA Lead OUT <input checked="" type="checkbox"/> 7 – Event Buffer 75% Full
313 – Maintenance Events 3	<input checked="" type="checkbox"/> 1 – Firmware Update Begin <input checked="" type="checkbox"/> 2 – Firmware Update Successful <input checked="" type="checkbox"/> 3 – Firmware Update Fail	314 – Maintenance Events 4	<input checked="" type="checkbox"/> 1 – Gas Trouble <input checked="" type="checkbox"/> 2 – Gas Trouble Restore <input checked="" type="checkbox"/> 3 – Heat Trouble <input checked="" type="checkbox"/> 4 – Heat Trouble Restore <input checked="" type="checkbox"/> 5 – Freeze Trouble <input checked="" type="checkbox"/> 6 – Freeze Trouble Restore <input checked="" type="checkbox"/> 7 – Probe Disconnected Trouble <input checked="" type="checkbox"/> 8 – Probe Disconnected Restore
321 – Receiver Events	<input checked="" type="checkbox"/> 2 – Receiver 1 FTC Restore <input checked="" type="checkbox"/> 4 – Receiver 2 FTC Restore <input checked="" type="checkbox"/> 6 – Receiver 3 FTC Restore <input checked="" type="checkbox"/> 8 – Receiver 4 FTC Restore	331 – Module Events 1	<input checked="" type="checkbox"/> 1 – Module AC Trouble <input checked="" type="checkbox"/> 2 – Module AC Trouble Restore <input checked="" type="checkbox"/> 3 – Module Battery Trouble <input checked="" type="checkbox"/> 4 – Module Battery Trouble Restore <input checked="" type="checkbox"/> 5 – Module Battery Absent <input checked="" type="checkbox"/> 6 – Module Battery Absent Restore
332 – Module Events 2	<input checked="" type="checkbox"/> 1 – Module Low Voltage Trouble <input checked="" type="checkbox"/> 2 – Module Low Voltage Restore <input checked="" type="checkbox"/> 3 – Module Supervisory <input checked="" type="checkbox"/> 4 – Module Supervisory Restore <input checked="" type="checkbox"/> 5 – Module Aux Trouble <input checked="" type="checkbox"/> 6 – Module Aux Trouble Restore	335 – Module Events 5	<input checked="" type="checkbox"/> 1 – Output 1 Fault <input checked="" type="checkbox"/> 2 – Output 1 Fault Restore

351 – Alternate Communicator 1	<input checked="" type="checkbox"/> 1 – Alt. Comm. Module Comm Fault <input checked="" type="checkbox"/> 2 – Alt. Comm. Module Comm Fault Restore <input checked="" type="checkbox"/> 7 – Alt. Comm. Radio/SIM Failure <input checked="" type="checkbox"/> 8 – Alt. Comm. Radio/SIM Failure Restore	352 – Alternate Communicator 2	<input checked="" type="checkbox"/> 1 – Alt. Comm. Network Fault <input checked="" type="checkbox"/> 2 – Alt. Comm. Network Fault Restore <input checked="" type="checkbox"/> 3 – Alt. Comm. Low Signal Trouble <input checked="" type="checkbox"/> 4 – Alt. Comm. Low Signal Trouble Restore <input checked="" type="checkbox"/> 5 – Alt. Comm. Ethernet Trouble <input checked="" type="checkbox"/> 6 – Alt. Comm. Ethernet Trouble Restore <input checked="" type="checkbox"/> 7 – Alt. Comm. Lockout Trouble <input checked="" type="checkbox"/> 8 – Alt. Comm. Lockout Trouble Restore
354 – Alternate Communicator 4	<input checked="" type="checkbox"/> 1 – Alt. Comm Receiver 1 Trouble <input checked="" type="checkbox"/> 2 – Alt. Comm Receiver 1 Restore <input checked="" type="checkbox"/> 3 – Alt. Comm Receiver 2 Trouble <input checked="" type="checkbox"/> 4 – Alt. Comm Receiver 2 Restore <input checked="" type="checkbox"/> 5 – Alt. Comm Receiver 3 Trouble <input checked="" type="checkbox"/> 6 – Alt. Comm Receiver 3 Restore <input checked="" type="checkbox"/> 7 – Alt. Comm Receiver 4 Trouble <input checked="" type="checkbox"/> 8 – Alt. Comm Receiver 4 Restore	355 – Alternate Communicator 5	<input checked="" type="checkbox"/> 1 – Alt. Comm Receiver 1 Supervision Failure <input checked="" type="checkbox"/> 2 – Alt. Comm Receiver 1 Supervision Restore <input checked="" type="checkbox"/> 3 – Alt. Comm Receiver 2 Supervision Failure <input checked="" type="checkbox"/> 4 – Alt. Comm Receiver 2 Supervision Restore <input checked="" type="checkbox"/> 5 – Alt. Comm Receiver 3 Supervision Failure <input checked="" type="checkbox"/> 6 – Alt. Comm Receiver 3 Supervision Restore <input checked="" type="checkbox"/> 7 – Alt. Comm Receiver 4 Supervision Failure <input checked="" type="checkbox"/> 8 – Alt. Comm Receiver 4 Supervision Restore
361 – Wireless Device Events	<input checked="" type="checkbox"/> 1 – Device AC Fail <input checked="" type="checkbox"/> 2 – Device AC Restore <input checked="" type="checkbox"/> 3 – Device Low Battery <input checked="" type="checkbox"/> 4 – Device Low Battery Restore <input checked="" type="checkbox"/> 5 – Device Fault <input checked="" type="checkbox"/> 6 – Device Fault Restore	401 – System Test Events	<input checked="" type="checkbox"/> 1 – Walk Test Start <input checked="" type="checkbox"/> 2 – Walk Test End <input checked="" type="checkbox"/> 3 – Periodic Test Transmission <input checked="" type="checkbox"/> 4 – Periodic Test Transmission with Trouble <input checked="" type="checkbox"/> 5 – System Test

Communications

[309] System Call Direction			
Description on page 47	001 – Maintenance Events:	<input checked="" type="checkbox"/> Receiver #1	
		<input type="checkbox"/> Receiver #2	
		<input type="checkbox"/> Receiver #3	
		<input type="checkbox"/> Receiver #4	
	002 – Test Transmission Events:	<input checked="" type="checkbox"/> Receiver #1	
		<input type="checkbox"/> Receiver #2	
		<input type="checkbox"/> Receiver #3	
		<input type="checkbox"/> Receiver #4	
[310] Account Codes			
(4-Digit HEX; Default FFFF) Description on page 47	000 – System Account Code (6-digit Hex; Default: FFFFFFFF):		
	001 – Partition 1 Account Code:		
	002 – Partition 2 Account Code:		
	003 – Partition 3 Account Code:		
	004 – Partition 4 Account Code:		
	005 – Partition 5 Account Code:		
	006 – Partition 6 Account Code:		
	007 – Partition 7 Account Code:		
	008 – Partition 8 Account Code:		
[311] Partition 1 Call Directions			
Description on page 47	001 – Partition 1 Alarm/ Restore:	<input checked="" type="checkbox"/> Receiver #1	<input type="checkbox"/> Receiver #3
		<input type="checkbox"/> Receiver #2	<input type="checkbox"/> Receiver #4
	002 – Partition 1 Tamper/ Restore:	<input checked="" type="checkbox"/> Receiver #1	<input type="checkbox"/> Receiver #3
		<input type="checkbox"/> Receiver #2	<input type="checkbox"/> Receiver #4
	003 – Partition 1 Opening/ Closing:	<input type="checkbox"/> Receiver #1	<input type="checkbox"/> Receiver #3
		<input type="checkbox"/> Receiver #2	<input type="checkbox"/> Receiver #4

[312] Partition 2 Call Directions				
		001 – Partition 2 Alarm/ Restore:	<input checked="" type="checkbox"/> Receiver #1 <input type="checkbox"/> Receiver #2	<input type="checkbox"/> Receiver #3 <input type="checkbox"/> Receiver #4
		002 – Partition 2 Tamper/ Restore:	<input checked="" type="checkbox"/> Receiver #1 <input type="checkbox"/> Receiver #2	<input type="checkbox"/> Receiver #3 <input type="checkbox"/> Receiver #4
		003 – Partition 2 Opening/ Closing:	<input type="checkbox"/> Receiver #1 <input type="checkbox"/> Receiver #2	<input type="checkbox"/> Receiver #3 <input type="checkbox"/> Receiver #4
[313] Partition 3 Call Directions				
		001 – Partition 3 Alarm/ Restore:	<input checked="" type="checkbox"/> Receiver #1 <input type="checkbox"/> Receiver #2	<input type="checkbox"/> Receiver #3 <input type="checkbox"/> Receiver #4
		002 – Partition 3 Tamper/ Restore:	<input checked="" type="checkbox"/> Receiver #1 <input type="checkbox"/> Receiver #2	<input type="checkbox"/> Receiver #3 <input type="checkbox"/> Receiver #4
		003 – Partition 3 Opening/ Closing:	<input type="checkbox"/> Receiver #1 <input type="checkbox"/> Receiver #2	<input type="checkbox"/> Receiver #3 <input type="checkbox"/> Receiver #4
[314] Partition 4 Call Directions				
		001 – Partition 4 Alarm/ Restore:	<input checked="" type="checkbox"/> Receiver #1 <input type="checkbox"/> Receiver #2	<input type="checkbox"/> Receiver #3 <input type="checkbox"/> Receiver #4
		002 – Partition 4 Tamper/ Restore:	<input checked="" type="checkbox"/> Receiver #1 <input type="checkbox"/> Receiver #2	<input type="checkbox"/> Receiver #3 <input type="checkbox"/> Receiver #4
		003 – Partition 4 Opening/ Closing:	<input type="checkbox"/> Receiver #1 <input type="checkbox"/> Receiver #2	<input type="checkbox"/> Receiver #3 <input type="checkbox"/> Receiver #4
[315] Partition 5 Call Directions				
		001 – Partition 5 Alarm/ Restore:	<input checked="" type="checkbox"/> Receiver #1 <input type="checkbox"/> Receiver #2	<input type="checkbox"/> Receiver #3 <input type="checkbox"/> Receiver #4
		002 – Partition 5 Tamper/ Restore:	<input checked="" type="checkbox"/> Receiver #1 <input type="checkbox"/> Receiver #2	<input type="checkbox"/> Receiver #3 <input type="checkbox"/> Receiver #4
		003 – Partition 5 Opening/ Closing:	<input type="checkbox"/> Receiver #1 <input type="checkbox"/> Receiver #2	<input type="checkbox"/> Receiver #3 <input type="checkbox"/> Receiver #4
[316] Partition 6 Call Directions				
		001 – Partition 6 Alarm/ Restore:	<input checked="" type="checkbox"/> Receiver #1 <input type="checkbox"/> Receiver #2	<input type="checkbox"/> Receiver #3 <input type="checkbox"/> Receiver #4
		002 – Partition 6 Tamper/ Restore:	<input checked="" type="checkbox"/> Receiver #1 <input type="checkbox"/> Receiver #2	<input type="checkbox"/> Receiver #3 <input type="checkbox"/> Receiver #4
		003 – Partition 6 Opening/ Closing:	<input type="checkbox"/> Receiver #1 <input type="checkbox"/> Receiver #2	<input type="checkbox"/> Receiver #3 <input type="checkbox"/> Receiver #4
[317] Partition 7 Call Directions				
		001 – Partition 7 Alarm/ Restore:	<input checked="" type="checkbox"/> Receiver #1 <input type="checkbox"/> Receiver #2	<input type="checkbox"/> Receiver #3 <input type="checkbox"/> Receiver #4
		002 – Partition 7 Tamper/ Restore:	<input checked="" type="checkbox"/> Receiver #1 <input type="checkbox"/> Receiver #2	<input type="checkbox"/> Receiver #3 <input type="checkbox"/> Receiver #4
		003 – Partition 7 Opening/ Closing:	<input type="checkbox"/> Receiver #1 <input type="checkbox"/> Receiver #2	<input type="checkbox"/> Receiver #3 <input type="checkbox"/> Receiver #4
[318] Partition 8 Call Directions				
		001 – Partition 8 Alarm/ Restore:	<input checked="" type="checkbox"/> Receiver #1 <input type="checkbox"/> Receiver #2	<input type="checkbox"/> Receiver #3 <input type="checkbox"/> Receiver #4
		002 – Partition 8 Tamper/ Restore:	<input checked="" type="checkbox"/> Receiver #1 <input type="checkbox"/> Receiver #2	<input type="checkbox"/> Receiver #3 <input type="checkbox"/> Receiver #4
		003 – Partition 8 Opening/ Closing:	<input type="checkbox"/> Receiver #1 <input type="checkbox"/> Receiver #2	<input type="checkbox"/> Receiver #3 <input type="checkbox"/> Receiver #4

[350] Communicator Formats		Description on page 47	
(2-Digit decimal) Range: 03= Contact ID, 04= SIA (Default)	001 – Receiver 1:	003 – Receiver 3:	
	002 – Receiver 2:	004 – Receiver 4:	
[377] Communication Variables			
(3-digit decimal) Range: 000-255 attempts unless otherwise noted Description on page 47	001 – Swinger Shutdown Attempts: Default: 003	Alarms and Restore (000-014): Tampers and Restore: Maintenance and Restore:	
	002 – Communication Delays:	Zone Delay (Default: 000):	
		AC Failure Communication Delay (Default:030 minutes/Hours):	
		TLM Trouble Delay (Default:010 seconds x 3):	
		Wireless Zone Low Bat. Transmission Delay (Default: 007 days):	
		Delinquency Transmission Delay (Default: 030 days/hours):	
		Communications Cancel Window (Default: 000 minutes):	
	003 – Periodic Test Transmission Cycle (Default: 030 hours/days):		
	004 – Periodic Test Transmission Time of Day (Default: 9999):		
	011 – Maximum Dialing Attempts: (Default: 005):		
	012 – Delay Between PSTN Attempts: (Default: 003 seconds):		
	013 – Delay Between Force Attempts: (Default: 020 seconds):		
	014 – Post Dial Wait for Handshake: (Range: 001-255; Default: 040 Seconds; UL=45):		
	015 – IP/GS Wait for Ack: (Range: 001-255; Default: 060 seconds):		
016 – IP/Cellular Fault Check Timer: (Range: 003-255; Default: 010):			
[380] Communicator Option 1			
Description on page 48	1 – <input checked="" type="checkbox"/> Communications Enabled		
	2 – <input type="checkbox"/> Restore on Bell Time-out		
	3 – <input type="checkbox"/> Pulse Dialing		
	4 – <input type="checkbox"/> Pulse Dial after 5th Attempt		
	5 – <input type="checkbox"/> Parallel Communications		
	6 – <input type="checkbox"/> Alternate Dial		
	7 – <input type="checkbox"/> Reduced Dialing Attempts		
	8 – <input type="checkbox"/> Activity Delinquency		
[381] Communicator Option 2			
Description on page 49	1 – <input type="checkbox"/> Keypad Ringback		
	2 – <input type="checkbox"/> Bell Ringback		
	4 – <input type="checkbox"/> Closing Confirmation		
	8 – <input type="checkbox"/> Communications Priority Options		
[382] Communicator Option 3			
Description on page 49	1 – <input type="checkbox"/> Test Transmission Receiver		
	2 – <input type="checkbox"/> Walk Test Communication		
	4 – <input type="checkbox"/> Call Waiting Cancel		
	5 – <input type="checkbox"/> Alternate Communicator Enable/Disable		
	6 – <input type="checkbox"/> AC Failure Communication Delay in Hours		
[383] Communicator Option 4			
Description on page 50	1 – <input type="checkbox"/> Phone Number Account Code		
	2 – <input type="checkbox"/> 6-Digit Account Code		
	5 – <input type="checkbox"/> Communicate FTC Events		
[384] Communicator Backup Options			
Description on page 50	2 – <input checked="" type="checkbox"/> Backup Options - Receiver 2		
	3 – <input type="checkbox"/> Backup Options - Receiver 3		
	4 – <input type="checkbox"/> Backup Options - Receiver 4		

DLS Programming

[401] DLS/SA Options			
Description on page 50	1 – <input type="checkbox"/> Double Call	4 – <input type="checkbox"/> User Call up	
	2 – <input checked="" type="checkbox"/> User Enables DLS	6 – <input type="checkbox"/> Panel Call up and Baud Rate	
	3 – <input type="checkbox"/> DLS Callback	7 – <input checked="" type="checkbox"/> Alt. Comm. DLS	
[402] PSTN DLS Phone Number Programming (31-digit phone number): Description on page 50			
[403] DLS Access Code (6-digit hex; 000000-FFFFFF; Default: 212800): Description on page 51			
[404] DLS/SA Panel ID (10-digit hex; 0000000000-FFFFFFFF; Default 2128000000): Description on page 51			
[405] PSTN Double Call Timer (3-decimal; 000-255; Default: 060): Description on page 51			
[406] PSTN Number of Rings to Answer On (3-decimal; 000-255; Default 000): Description on page 51			
[407] SA Access Code (6-digit hex; 000000-FFFFFF; Default: FFFFFFFF): Description on page 51			
[410] Automatic DLS Options			
Description on page 51	001 – Auto DLS Options	1 – <input type="checkbox"/> Periodic DLS	
		3 – <input type="checkbox"/> DLS / Event Buffer 75% Full	
		5 – <input type="checkbox"/> SA on Event Buffer 75% Full	
	002 – Periodic DLS Days (3-digit decimal; 000-255; Default: 000 days):		
	003 – Periodic DLS Time (4-digit decimal; HH:MM; 0000-2359; Default: 0000):		
	007 – Delay Call Window (4-digit decimal; 0000-2359; HH:MM Default: 0000)	1 – <input type="checkbox"/> Delay Call Window Start	
	2 – <input type="checkbox"/> Delay Call Window End		

Schedule Programming

[601] Programming Schedule 1			
Description on page 52	Interval 1	101 – Start Time:	102 – End Time:
	(8- digit decimal) HH:MM to HH:MM Default: 0000	103 – Days Assignment:	104 – Holiday Assignment:
		01 – <input type="checkbox"/> Sunday	09 – <input type="checkbox"/> Holiday 1
		02 – <input type="checkbox"/> Monday	10 – <input type="checkbox"/> Holiday 2
		03 – <input type="checkbox"/> Tuesday	11 – <input type="checkbox"/> Holiday 3
		04 – <input type="checkbox"/> Wednesday	12 – <input type="checkbox"/> Holiday 4
	05 – <input type="checkbox"/> Thursday		
	06 – <input type="checkbox"/> Friday		
	07 – <input type="checkbox"/> Saturday		
	Interval 2	201 – Start Time:	202 – End Time:
(8- digit decimal) HH:MM to HH:MM Default: 0000	203 – Days Assignment:	204 – Holiday Assignment:	
	01 – <input type="checkbox"/> Sunday	09 – <input type="checkbox"/> Holiday 1	
	02 – <input type="checkbox"/> Monday	10 – <input type="checkbox"/> Holiday 2	
	03 – <input type="checkbox"/> Tuesday	11 – <input type="checkbox"/> Holiday 3	
	04 – <input type="checkbox"/> Wednesday	12 – <input type="checkbox"/> Holiday 4	
	05 – <input type="checkbox"/> Thursday		
	06 – <input type="checkbox"/> Friday		
	07 – <input type="checkbox"/> Saturday		

	Description on page 52	Interval 3	301 – Start Time:	302 – End Time:
		(8- digit decimal) HH:MM to HH:MM Default: 0000	303 – Days Assignment: 01 – <input type="checkbox"/> Sunday 02 – <input type="checkbox"/> Monday 03 – <input type="checkbox"/> Tuesday 04 – <input type="checkbox"/> Wednesday 05 – <input type="checkbox"/> Thursday 06 – <input type="checkbox"/> Friday 07 – <input type="checkbox"/> Saturday	304 – Holiday Assignment: 09 – <input type="checkbox"/> Holiday 1 10 – <input type="checkbox"/> Holiday 2 11 – <input type="checkbox"/> Holiday 3 12 – <input type="checkbox"/> Holiday 4
		Interval 4	401 – Start Time:	402 – End Time:
		(8- digit decimal) HH:MM to HH:MM Default: 0000	403 – Days Assignment: 01 – <input type="checkbox"/> Sunday 02 – <input type="checkbox"/> Monday 03 – <input type="checkbox"/> Tuesday 04 – <input type="checkbox"/> Wednesday 05 – <input type="checkbox"/> Thursday 06 – <input type="checkbox"/> Friday	404 – Holiday Assignment: 09 – <input type="checkbox"/> Holiday 1 10 – <input type="checkbox"/> Holiday 2 11 – <input type="checkbox"/> Holiday 3 12 – <input type="checkbox"/> Holiday 4

[602] Programming Schedule 2

	Description on page 52	Interval 1	101 – Start Time:	102 – End Time:
		(8- digit decimal) HH:MM to HH:MM Default: 0000	103 – Days Assignment: 01 – <input type="checkbox"/> Sunday 02 – <input type="checkbox"/> Monday 03 – <input type="checkbox"/> Tuesday 04 – <input type="checkbox"/> Wednesday 05 – <input type="checkbox"/> Thursday 06 – <input type="checkbox"/> Friday 07 – <input type="checkbox"/> Saturday	104 – Holiday Assignment: 09 – <input type="checkbox"/> Holiday 1 10 – <input type="checkbox"/> Holiday 2 11 – <input type="checkbox"/> Holiday 3 12 – <input type="checkbox"/> Holiday 4
		Interval 2	201 – Start Time:	202 – End Time:
		(8- digit decimal) HH:MM to HH:MM Default: 0000	203 – Days Assignment: 01 – <input type="checkbox"/> Sunday 02 – <input type="checkbox"/> Monday 03 – <input type="checkbox"/> Tuesday 04 – <input type="checkbox"/> Wednesday 05 – <input type="checkbox"/> Thursday 06 – <input type="checkbox"/> Friday 07 – <input type="checkbox"/> Saturday	204 – Holiday Assignment: 09 – <input type="checkbox"/> Holiday 1 10 – <input type="checkbox"/> Holiday 2 11 – <input type="checkbox"/> Holiday 3 12 – <input type="checkbox"/> Holiday 4
	Description on page 52	Interval 3	301 – Start Time:	302 – End Time:
		(8- digit decimal) HH:MM to HH:MM Default: 0000	303 – Days Assignment: 01 – <input type="checkbox"/> Sunday 02 – <input type="checkbox"/> Monday 03 – <input type="checkbox"/> Tuesday 04 – <input type="checkbox"/> Wednesday 05 – <input type="checkbox"/> Thursday 06 – <input type="checkbox"/> Friday 07 – <input type="checkbox"/> Saturday	304 – Holiday Assignment: 09 – <input type="checkbox"/> Holiday 1 10 – <input type="checkbox"/> Holiday 2 11 – <input type="checkbox"/> Holiday 3 12 – <input type="checkbox"/> Holiday 4
		Interval 4	401 – Start Time:	402 – End Time:
		(8- digit decimal) HH:MM to HH:MM Default: 0000	403 – Days Assignment: 01 – <input type="checkbox"/> Sunday 02 – <input type="checkbox"/> Monday 03 – <input type="checkbox"/> Tuesday 04 – <input type="checkbox"/> Wednesday 05 – <input type="checkbox"/> Thursday 06 – <input type="checkbox"/> Friday 07 – <input type="checkbox"/> Saturday	404 – Holiday Assignment: 09 – <input type="checkbox"/> Holiday 1 10 – <input type="checkbox"/> Holiday 2 11 – <input type="checkbox"/> Holiday 3 12 – <input type="checkbox"/> Holiday 4

[603] Programming Schedule 3				
Description on page 52	Interval 1	(8- digit decimal) HH:MM to HH:MM Default: 0000	101 – Start Time:	102 – End Time:
			103 – Days Assignment: 01 – <input type="checkbox"/> Sunday 02 – <input type="checkbox"/> Monday 03 – <input type="checkbox"/> Tuesday 04 – <input type="checkbox"/> Wednesday 05 – <input type="checkbox"/> Thursday 06 – <input type="checkbox"/> Friday 07 – <input type="checkbox"/> Saturday	104 – Holiday Assignment: 09 – <input type="checkbox"/> Holiday 1 10 – <input type="checkbox"/> Holiday 2 11 – <input type="checkbox"/> Holiday 3 12 – <input type="checkbox"/> Holiday 4
	Interval 2	(8- digit decimal) HH:MM to HH:MM Default: 0000	201 – Start Time:	202 – End Time:
			203 – Days Assignment: 01 – <input type="checkbox"/> Sunday 02 – <input type="checkbox"/> Monday 03 – <input type="checkbox"/> Tuesday 04 – <input type="checkbox"/> Wednesday 05 – <input type="checkbox"/> Thursday 06 – <input type="checkbox"/> Friday 07 – <input type="checkbox"/> Saturday	204 – Holiday Assignment: 09 – <input type="checkbox"/> Holiday 1 10 – <input type="checkbox"/> Holiday 2 11 – <input type="checkbox"/> Holiday 3 12 – <input type="checkbox"/> Holiday 4
	Interval 3	(8- digit decimal) HH:MM to HH:MM Default: 0000	301 – Start Time:	302 – End Time:
			303 – Days Assignment: 01 – <input type="checkbox"/> Sunday 02 – <input type="checkbox"/> Monday 03 – <input type="checkbox"/> Tuesday 04 – <input type="checkbox"/> Wednesday 05 – <input type="checkbox"/> Thursday 06 – <input type="checkbox"/> Friday 07 – <input type="checkbox"/> Saturday	304 – Holiday Assignment: 09 – <input type="checkbox"/> Holiday 1 10 – <input type="checkbox"/> Holiday 2 11 – <input type="checkbox"/> Holiday 3 12 – <input type="checkbox"/> Holiday 4
	Interval 4	(8- digit decimal) HH:MM to HH:MM Default: 0000	401 – Start Time:	402 – End Time:
			403 – Days Assignment: 01 – <input type="checkbox"/> Sunday 02 – <input type="checkbox"/> Monday 03 – <input type="checkbox"/> Tuesday 04 – <input type="checkbox"/> Wednesday 05 – <input type="checkbox"/> Thursday 06 – <input type="checkbox"/> Friday 07 – <input type="checkbox"/> Saturday	404 – Holiday Assignment: 09 – <input type="checkbox"/> Holiday 1 10 – <input type="checkbox"/> Holiday 2 11 – <input type="checkbox"/> Holiday 3 12 – <input type="checkbox"/> Holiday 4
[604] Programming Schedule 4				
Description on page 52	Interval 1	(8- digit decimal) HH:MM to HH:MM Default: 0000	101 – Start Time:	102 – End Time:
			103 – Days Assignment: 01 – <input type="checkbox"/> Sunday 02 – <input type="checkbox"/> Monday 03 – <input type="checkbox"/> Tuesday 04 – <input type="checkbox"/> Wednesday 05 – <input type="checkbox"/> Thursday 06 – <input type="checkbox"/> Friday 07 – <input type="checkbox"/> Saturday	104 – Holiday Assignment: 09 – <input type="checkbox"/> Holiday 1 10 – <input type="checkbox"/> Holiday 2 11 – <input type="checkbox"/> Holiday 3 12 – <input type="checkbox"/> Holiday 4

Description on page 52	Interval 2	201 – Start Time:	202 – End Time:	
	(8- digit decimal) HH:MM to HH:MM Default: 0000	203 – Days Assignment: 01 – <input type="checkbox"/> Sunday 02 – <input type="checkbox"/> Monday 03 – <input type="checkbox"/> Tuesday 04 – <input type="checkbox"/> Wednesday 05 – <input type="checkbox"/> Thursday 06 – <input type="checkbox"/> Friday 07 – <input type="checkbox"/> Saturday	204 – Holiday Assignment: 09 – <input type="checkbox"/> Holiday 1 10 – <input type="checkbox"/> Holiday 2 11 – <input type="checkbox"/> Holiday 3 12 – <input type="checkbox"/> Holiday 4	
	Interval 3	301 – Start Time:	302 – End Time:	
	(8- digit decimal) HH:MM to HH:MM Default: 0000	303 – Days Assignment: 01 – <input type="checkbox"/> Sunday 02 – <input type="checkbox"/> Monday 03 – <input type="checkbox"/> Tuesday 04 – <input type="checkbox"/> Wednesday 05 – <input type="checkbox"/> Thursday 06 – <input type="checkbox"/> Friday 07 – <input type="checkbox"/> Saturday	304 – Holiday Assignment: 09 – <input type="checkbox"/> Holiday 1 10 – <input type="checkbox"/> Holiday 2 11 – <input type="checkbox"/> Holiday 3 12 – <input type="checkbox"/> Holiday 4	
	Interval 4	401 – Start Time:	402 – End Time:	
	(8- digit decimal) HH:MM to HH:MM Default: 0000	403 – Days Assignment: 01 – <input type="checkbox"/> Sunday 02 – <input type="checkbox"/> Monday 03 – <input type="checkbox"/> Tuesday 04 – <input type="checkbox"/> Wednesday 05 – <input type="checkbox"/> Thursday 06 – <input type="checkbox"/> Friday 07 – <input type="checkbox"/> Saturday	404 – Holiday Assignment: 09 – <input type="checkbox"/> Holiday 1 10 – <input type="checkbox"/> Holiday 2 11 – <input type="checkbox"/> Holiday 3 12 – <input type="checkbox"/> Holiday 4	
	[711] Holiday Group 1			
	(6-Digit Decimal) MMDDYY Default: 000000	001 – Holiday Group 1 Date 1:		
	Description on page 52	002 – Holiday Group 1 Date 2:		
003 – Holiday Group 1 Date 3:				
004 – Holiday Group 1 Date 4:				
005 – Holiday Group 1 Date 5:				
006 – Holiday Group 1 Date 6:				
007 – Holiday Group 1 Date 7:				
008 – Holiday Group 1 Date 8:				
	009-099 – Holiday Group 1 Date 9-99:			
[712] Holiday Group 2				
(6-Digit Decimal) MMDDYY Default: 000000	001 – Holiday Group 1 Date 1:			
Description on page 52	002 – Holiday Group 1 Date 2:			
	003 – Holiday Group 1 Date 3:			
	004 – Holiday Group 1 Date 4:			
	005 – Holiday Group 1 Date 5:			
	006 – Holiday Group 1 Date 6:			
	007 – Holiday Group 1 Date 7:			
	008 – Holiday Group 1 Date 8:			
	009-099 – Holiday Group 1 Date 9-99:			

[713] Holiday Group 3		
(6-Digit Decimal) MMDDYY Default: 000000 Description on page 52	001 – Holiday Group 1 Date 1:	
	002 – Holiday Group 1 Date 2:	
	003 – Holiday Group 1 Date 3:	
	004 – Holiday Group 1 Date 4:	
	005 – Holiday Group 1 Date 5:	
	006 – Holiday Group 1 Date 6:	
	007 – Holiday Group 1 Date 7:	
	008 – Holiday Group 1 Date 8:	
	009-099 – Holiday Group 1 Date 9-99:	
[714] Holiday Group 4		
(6-Digit Decimal) MMDDYY Default: 000000 Description on page 52	001 – Holiday Group 1 Date 1:	
	002 – Holiday Group 1 Date 2:	
	003 – Holiday Group 1 Date 3:	
	004 – Holiday Group 1 Date 4:	
	005 – Holiday Group 1 Date 5:	
	006 – Holiday Group 1 Date 6:	
	007 – Holiday Group 1 Date 7:	
	008 – Holiday Group 1 Date 8:	
	009-099 – Holiday Group 1 Date 9-99:	

Wireless Programming

[804] Wireless Programming See the HSM2HOSTx installation manual and wireless device installation sheets for detailed information.				
This section is an overview of wireless device programming. See the associated device installation sheets and the HSM2HOST/RFK keypad installation instructions for detailed worksheets	000 – WLS Device Enrollment	Zones:	(Selection) Zone #:	
			(Selection) Zone Definition:	
		(2-digit decimal)	(14 x 2)	Partition Assignment:
				Zone Label:
		WLS Keys	(Selection)	WLS Key #:
			(2-digit decimal)	Partition Assignment:
			(Selection)	Select User:
			(14 x 1)	WLS Key Label:
		Sirens	(Selection)	Siren #:
			(2-digit decimal)	Partition Assignment:
			(14 x 1)	Siren Label:
		Keypads	(2-digit decimal)	Keypad #:
			(2-digit decimal)	Partition Assignment:
			(14 x 1)	Keypad Label:
		Repeaters	(Selection)	Repeater #:
		(14 x 1)	Repeater Label:	
	001- 128 Configure Wireless Zones 1 to 128			
	551-556 Configure Wireless Sirens 1-16			
	601-632 Configure Wireless Keys 1-32			
	701-716 Configure Wireless Keypads			
	801-810 Wireless Options			
	841 Visual Verification Programming			
	901-905 Delete Wireless Devices			
	921-925 Replace Wireless Devices			
	990 Show All Devices			
	999 Reset Devices to Factory Default			
[850] Cellular Signal Strength (Description on page 52)				
[851] Alternate Communicator Programming Refer to the installation instructions provided with the alternate communicator for details.				
[860] Display Keypad Slot Number (Description on page 52)				

[861]-[876] Keypad Programming Refer to the installation instructions provided with the keypad for details.																																									
	000 – Keypad Partition Mask	<table border="1"> <tr> <td colspan="2">00 – Global</td> </tr> <tr> <td>01 – <input checked="" type="checkbox"/> Partition 1</td> <td>05 – <input type="checkbox"/> Partition 5</td> </tr> <tr> <td>02 – <input type="checkbox"/> Partition 2</td> <td>06 – <input type="checkbox"/> Partition 6</td> </tr> <tr> <td>03 – <input type="checkbox"/> Partition 3</td> <td>07 – <input type="checkbox"/> Partition 7</td> </tr> <tr> <td>04 – <input type="checkbox"/> Partition 4</td> <td>08 – <input type="checkbox"/> Partition 8</td> </tr> </table>	00 – Global		01 – <input checked="" type="checkbox"/> Partition 1	05 – <input type="checkbox"/> Partition 5	02 – <input type="checkbox"/> Partition 2	06 – <input type="checkbox"/> Partition 6	03 – <input type="checkbox"/> Partition 3	07 – <input type="checkbox"/> Partition 7	04 – <input type="checkbox"/> Partition 4	08 – <input type="checkbox"/> Partition 8																													
00 – Global																																									
01 – <input checked="" type="checkbox"/> Partition 1	05 – <input type="checkbox"/> Partition 5																																								
02 – <input type="checkbox"/> Partition 2	06 – <input type="checkbox"/> Partition 6																																								
03 – <input type="checkbox"/> Partition 3	07 – <input type="checkbox"/> Partition 7																																								
04 – <input type="checkbox"/> Partition 4	08 – <input type="checkbox"/> Partition 8																																								
	001 – Function Key 1 (Default: 03):																																								
	002 – Function Key 2 (Default: 04):																																								
	003 – Function Key 3 (Default: 06):																																								
	004 – Function Key 4 (Default: 22):																																								
	005 – Function Key 5 (Default: 16):																																								
	Function Key Programming Options:																																								
	<table border="0"> <tr> <td>00 - Null Key</td> <td>17 - Arm Interior</td> <td>37 - Time/Date Programming</td> </tr> <tr> <td>02 - Instant Stay Arm</td> <td>21 - Command Output 1</td> <td>39 - Trouble Display</td> </tr> <tr> <td>03 - Stay Arm</td> <td>22 - Command Output 2</td> <td>40 - Alarm Memory</td> </tr> <tr> <td>04 - Away Arm</td> <td>23 - Command Output 3</td> <td>51 - [M] Key Alarm</td> </tr> <tr> <td>05 - [*][9]No Entry Arm</td> <td>24 - Command Output 4</td> <td>52 - [P] Key Alarm</td> </tr> <tr> <td>06 - Chime On/Off</td> <td>29 - Bypass Group Recall</td> <td>61 - Partition Select 1</td> </tr> <tr> <td>07 - System Test</td> <td>31 - Local PGM Active</td> <td>62 - Partition Select 2</td> </tr> <tr> <td>09 - Night Arm</td> <td>32 - Bypass Mode</td> <td>63 - Partition Select 3</td> </tr> <tr> <td>12 - Global Stay Arm</td> <td>33 - Bypass Recall</td> <td>64 - Partition Select 4</td> </tr> <tr> <td>13 - Global Away Arm</td> <td>34 - User Programming</td> <td>65 - Partition Select 5</td> </tr> <tr> <td>14 - Global Disarming</td> <td>35 - User Functions</td> <td>66 - Partition Select 6</td> </tr> <tr> <td>16 - Quick Exit</td> <td></td> <td>67 - Partition Select 7</td> </tr> <tr> <td></td> <td></td> <td>68 - Partition Select 8</td> </tr> </table>	00 - Null Key	17 - Arm Interior	37 - Time/Date Programming	02 - Instant Stay Arm	21 - Command Output 1	39 - Trouble Display	03 - Stay Arm	22 - Command Output 2	40 - Alarm Memory	04 - Away Arm	23 - Command Output 3	51 - [M] Key Alarm	05 - [*][9]No Entry Arm	24 - Command Output 4	52 - [P] Key Alarm	06 - Chime On/Off	29 - Bypass Group Recall	61 - Partition Select 1	07 - System Test	31 - Local PGM Active	62 - Partition Select 2	09 - Night Arm	32 - Bypass Mode	63 - Partition Select 3	12 - Global Stay Arm	33 - Bypass Recall	64 - Partition Select 4	13 - Global Away Arm	34 - User Programming	65 - Partition Select 5	14 - Global Disarming	35 - User Functions	66 - Partition Select 6	16 - Quick Exit		67 - Partition Select 7			68 - Partition Select 8	
00 - Null Key	17 - Arm Interior	37 - Time/Date Programming																																							
02 - Instant Stay Arm	21 - Command Output 1	39 - Trouble Display																																							
03 - Stay Arm	22 - Command Output 2	40 - Alarm Memory																																							
04 - Away Arm	23 - Command Output 3	51 - [M] Key Alarm																																							
05 - [*][9]No Entry Arm	24 - Command Output 4	52 - [P] Key Alarm																																							
06 - Chime On/Off	29 - Bypass Group Recall	61 - Partition Select 1																																							
07 - System Test	31 - Local PGM Active	62 - Partition Select 2																																							
09 - Night Arm	32 - Bypass Mode	63 - Partition Select 3																																							
12 - Global Stay Arm	33 - Bypass Recall	64 - Partition Select 4																																							
13 - Global Away Arm	34 - User Programming	65 - Partition Select 5																																							
14 - Global Disarming	35 - User Functions	66 - Partition Select 6																																							
16 - Quick Exit		67 - Partition Select 7																																							
		68 - Partition Select 8																																							
	011 – Keypad I/O (Zone number or output number; 3-digit decimal; Default: 000):																																								
	012 – Local PGM Output Timer	<table border="1"> <tr> <td>Pulse Time Minutes (Default: 00 minutes)</td> </tr> <tr> <td>Pulse Time Seconds (Default: 05 seconds)</td> </tr> </table>	Pulse Time Minutes (Default: 00 minutes)	Pulse Time Seconds (Default: 05 seconds)																																					
Pulse Time Minutes (Default: 00 minutes)																																									
Pulse Time Seconds (Default: 05 seconds)																																									
	021 – Keypad Option 1 2-digit decimal	<table border="1"> <tr> <td>1 – <input checked="" type="checkbox"/> [F] Key Enabled</td> </tr> <tr> <td>2 – <input checked="" type="checkbox"/> [M] Key Enabled</td> </tr> <tr> <td>3 – <input checked="" type="checkbox"/> [P] Key Enabled</td> </tr> <tr> <td>4 – <input checked="" type="checkbox"/> Display Code or X's</td> </tr> </table>	1 – <input checked="" type="checkbox"/> [F] Key Enabled	2 – <input checked="" type="checkbox"/> [M] Key Enabled	3 – <input checked="" type="checkbox"/> [P] Key Enabled	4 – <input checked="" type="checkbox"/> Display Code or X's																																			
1 – <input checked="" type="checkbox"/> [F] Key Enabled																																									
2 – <input checked="" type="checkbox"/> [M] Key Enabled																																									
3 – <input checked="" type="checkbox"/> [P] Key Enabled																																									
4 – <input checked="" type="checkbox"/> Display Code or X's																																									
	022 – Keypad Option 2	<table border="1"> <tr> <td>1 – <input checked="" type="checkbox"/> Local Clock Display</td> </tr> <tr> <td>2 – <input type="checkbox"/> Local Clock 24-Hour</td> </tr> <tr> <td>3 – <input checked="" type="checkbox"/> Auto Alarm Scroll</td> </tr> <tr> <td>5 – <input type="checkbox"/> Power LED</td> </tr> <tr> <td>6 – <input checked="" type="checkbox"/> Power LED AC Present</td> </tr> <tr> <td>7 – <input checked="" type="checkbox"/> Alarms Displayed While Armed</td> </tr> <tr> <td>8 – <input type="checkbox"/> Auto Scroll Open Zones</td> </tr> </table>	1 – <input checked="" type="checkbox"/> Local Clock Display	2 – <input type="checkbox"/> Local Clock 24-Hour	3 – <input checked="" type="checkbox"/> Auto Alarm Scroll	5 – <input type="checkbox"/> Power LED	6 – <input checked="" type="checkbox"/> Power LED AC Present	7 – <input checked="" type="checkbox"/> Alarms Displayed While Armed	8 – <input type="checkbox"/> Auto Scroll Open Zones																																
1 – <input checked="" type="checkbox"/> Local Clock Display																																									
2 – <input type="checkbox"/> Local Clock 24-Hour																																									
3 – <input checked="" type="checkbox"/> Auto Alarm Scroll																																									
5 – <input type="checkbox"/> Power LED																																									
6 – <input checked="" type="checkbox"/> Power LED AC Present																																									
7 – <input checked="" type="checkbox"/> Alarms Displayed While Armed																																									
8 – <input type="checkbox"/> Auto Scroll Open Zones																																									
	023 – Keypad Option 3	<table border="1"> <tr> <td>1 – <input type="checkbox"/> Armed LED Power Save</td> </tr> <tr> <td>2 – <input checked="" type="checkbox"/> Keypad Status Shows Arm Mode</td> </tr> <tr> <td>3 – <input type="checkbox"/> 5th Terminal is PGM Output/Zone Input</td> </tr> <tr> <td>7 – <input type="checkbox"/> Local Display of Temperature</td> </tr> <tr> <td>8 – <input type="checkbox"/> Low Temperature Warning</td> </tr> </table>	1 – <input type="checkbox"/> Armed LED Power Save	2 – <input checked="" type="checkbox"/> Keypad Status Shows Arm Mode	3 – <input type="checkbox"/> 5th Terminal is PGM Output/Zone Input	7 – <input type="checkbox"/> Local Display of Temperature	8 – <input type="checkbox"/> Low Temperature Warning																																		
1 – <input type="checkbox"/> Armed LED Power Save																																									
2 – <input checked="" type="checkbox"/> Keypad Status Shows Arm Mode																																									
3 – <input type="checkbox"/> 5th Terminal is PGM Output/Zone Input																																									
7 – <input type="checkbox"/> Local Display of Temperature																																									
8 – <input type="checkbox"/> Low Temperature Warning																																									
	030 – LCD Message:																																								
	031 – Downloaded LCD Message Duration (3-digit decimal; 000-255; Default: 000):																																								
	041 – Indoor Temperature Zone Entry (3-digit decimal; 000-128; Default: 000):																																								
	042 – Outdoor Temperature Zone Entry (3-digit decimal; 000-128; Default: 000):																																								
	101-228 – Door Chime Sound:	<table border="1"> <tr> <td>00 – <input type="checkbox"/> Disabled</td> </tr> <tr> <td>01 – <input checked="" type="checkbox"/> 6 Beeps</td> </tr> <tr> <td>02 – <input type="checkbox"/> Bing Bong</td> </tr> <tr> <td>03 – <input type="checkbox"/> Ding Dong</td> </tr> <tr> <td>04 – <input type="checkbox"/> Alarm Tone</td> </tr> <tr> <td>05 – <input type="checkbox"/> Zone Name</td> </tr> </table>	00 – <input type="checkbox"/> Disabled	01 – <input checked="" type="checkbox"/> 6 Beeps	02 – <input type="checkbox"/> Bing Bong	03 – <input type="checkbox"/> Ding Dong	04 – <input type="checkbox"/> Alarm Tone	05 – <input type="checkbox"/> Zone Name																																	
00 – <input type="checkbox"/> Disabled																																									
01 – <input checked="" type="checkbox"/> 6 Beeps																																									
02 – <input type="checkbox"/> Bing Bong																																									
03 – <input type="checkbox"/> Ding Dong																																									
04 – <input type="checkbox"/> Alarm Tone																																									
05 – <input type="checkbox"/> Zone Name																																									

		Door Chime Zone Assignment:
		1 ___ 13 ___ 25 ___ 37 ___ 49 ___ 61 ___ 73 ___ 85 ___ 97 ___ 109 ___ 121 ___
		2 ___ 14 ___ 26 ___ 38 ___ 50 ___ 62 ___ 74 ___ 86 ___ 98 ___ 110 ___ 122 ___
		3 ___ 15 ___ 27 ___ 39 ___ 51 ___ 63 ___ 75 ___ 87 ___ 99 ___ 111 ___ 123 ___
		4 ___ 16 ___ 28 ___ 40 ___ 52 ___ 64 ___ 76 ___ 88 ___ 100 ___ 112 ___ 124 ___
		5 ___ 17 ___ 29 ___ 41 ___ 53 ___ 65 ___ 77 ___ 89 ___ 101 ___ 113 ___ 125 ___
		6 ___ 18 ___ 30 ___ 42 ___ 54 ___ 66 ___ 78 ___ 90 ___ 102 ___ 114 ___ 126 ___
		7 ___ 19 ___ 31 ___ 43 ___ 55 ___ 67 ___ 79 ___ 91 ___ 103 ___ 115 ___ 127 ___
		8 ___ 20 ___ 32 ___ 44 ___ 56 ___ 68 ___ 80 ___ 92 ___ 104 ___ 116 ___ 128 ___
		9 ___ 21 ___ 33 ___ 45 ___ 57 ___ 69 ___ 81 ___ 93 ___ 105 ___ 117 ___
		10 ___ 22 ___ 34 ___ 46 ___ 58 ___ 70 ___ 82 ___ 94 ___ 106 ___ 118 ___
		11 ___ 23 ___ 35 ___ 47 ___ 59 ___ 71 ___ 83 ___ 95 ___ 107 ___ 119 ___
		12 ___ 24 ___ 36 ___ 48 ___ 60 ___ 72 ___ 84 ___ 96 ___ 108 ___ 120 ___

[899] Template Programming		
Description on page 52		5 Digit Template Code:
		Central Station Phone Number:
		Central Station Account Code:
		Partition Account Code:
		DLS Access Code:
		Partition 1 Entry Delay 1:
		Partition 1 Exit Delay:
		Installer Code:

System Information and Testing

[900] System Information		
Description on page 53		000 – Control Panel Version
		001- 016 – View Keypad 1-16 Version
		101-116 – HSM2108 8 Zone Module 1-16 Version
		201-216 – HSM2208 8 Output Module 1 Version
		460 – Alternate Communicator
		461 – HSM2Host Module
		501 – HSM2300 Power Supply 1A Module 1
		502 – HSM2300 Power Supply 1A Module 2
		503 – HSM2300 Power Supply 1A Module 3
		504 – HSM2300 Power Supply 1A Module 4
		521 – HSM2204 High-Current O/P Module 1
		522 – HSM2204 High-Current O/P Module 2
		523 – HSM2204 High-Current O/P Module 3
	524 – HSM2204 High-Current O/P Module 4	

[901] Installer Walk Test Mode Enable/Disable	Description on page 53
--	------------------------

Module Programming

[902] Add/Remove Modules		
Description on page 53		000 – Auto Enroll Modules
		001 – Enroll Modules
		002 – Slot Assignment
		003 – Edit Module Slot Assignment
		101 – Delete Keypads
		102 – Delete HSM2108 8 Zone Module
		103 – Delete HSM2208 8 Output Module or High Current O/P
		106 – Delete HSM2Host
		109 – Delete HSM2300 Power Supply 1A
		110 – Delete HSM2204 4 High Current Output

[903] Confirm Modules		
Description on page 54	*LED and ICON keypads	000 – View All Modules
		001 – View Keypads*
		002 – View HSM2108 8 Zone Module*
		003 – View HSM2208 8 Output Module O/P*
		006 – View HSM2Host*
		009 – View HSM2300 Power Supply 1A*
		010 – View HSM2204 4 High Current Output*
Description on page 54		101 – Confirm Keypads
		102 – Confirm HSM2108 8 Zone Module
		103 – Confirm HSM2208 8 Output Module or High Current O/P
		106 – Confirm HSM2Host
		109 – Confirm HSM2300 Power Supply 1A
		110 – Confirm HSM2204 4 High Current Output

Testing

[904] Wireless Placement Test		
Description on page 54		001-128 – Placement Test - Zone 1-128
		521-528 – Placement Test Repeaters 1-28
		551-566 – Placement Test Sirens 1-16
		601-632 – Placement Test Wireless Keys 1-32
		701-716 – Placement Test Wireless Keypads 1-16

Battery Settings

[982] Battery Settings		
Description on page 54	000 – Panel Battery Settings	01 – <input type="checkbox"/> Panel High Charge Current
		010 – HSM2204 High Current Output Battery
		01 – <input type="checkbox"/> HSM2204 1 High Charge Current
		02 – <input type="checkbox"/> HSM2204 2 High Charge Current
	020 – HSM2300 1A Power Supply Battery	03 – <input type="checkbox"/> HSM2204 3 High Charge Current
		04 – <input type="checkbox"/> HSM2204 4 High Charge Current
		01 – <input type="checkbox"/> HSM2300 1 High Charge Current
		02 – <input type="checkbox"/> HSM2300 2 High Charge Current
		03 – <input type="checkbox"/> HSM2300 3 High Charge Current
		04 – <input type="checkbox"/> HSM2300 4 High Charge Current

Defaults

[989] Default Master Code		
[990] Installer Lockout Enable/Disable		
[991] Default Keypads	999 – Default All Keypads	
	901-916 – Default Keypad 1-16	
[993] Default Alt Comm		
[996] Default HSM2HOST Wireless Receiver		
[999] Default System	(Descriptions on page 54)	

Section 7: Troubleshooting

7.1 Testing

- Power up system
- Program options as required (See “Programming Descriptions” on page 26).
- Trip, then restore zones
- Verify correct reporting codes are sent to the central station

7.2 Troubleshooting

LCD programmable-message keypad:

- Press [*][2] followed by access code if required to view a trouble condition
- The trouble light flashes and the LCD displays the first trouble condition
- Use the arrow keys to scroll through all trouble conditions present on the system

NOTE: When additional information is available for a specific trouble condition, a [*] is displayed. Press the [*] key to view the additional information.

LED and ICON keypads:

- Press [*][2] to view a trouble condition
- The trouble light flashes
- Refer to the trouble summary list below to determine the trouble condition(s) present on the system

[*][2] Trouble Summary

The list below describes the trouble indications displayed on keypads.

Trouble	Detailed Trouble	
01 – Service Required	01 – Bell circuit 02 – RF jam detected 03 – Aux supply trouble	04 – Time and date 05 – Output 1 fault
02 – Module Low Battery	01 – Panel low battery 02 – Panel no battery 04 – HSM2204 1-4 low battery	05 – HSM2204 1-4 no battery 07 – HSM2300 1-4 low battery 08 – HSM2300 1-4 no battery
03 – Bus Voltage	01 – HSM2HOSTx voltage 02 – Keypad 1-16 voltage 04 – HS2108 1-15 voltage 05 – HSM2300 1-4 voltage	06 – HSM2204 1-4 voltage 11 – HSM2208 1-4 voltage
04 – AC Troubles	01 – Zone 1-128 AC 03 – Siren 1-16 AC 04 – Repeater 1-8 AC	05 – HSM2300 1-4 AC 06 – HSM2204 1-4 AC 07 – Alarm Controller AC
05 – Device Faults	01 – Zone 1-128 02 – Keypad 1-16	03 – Siren 1-16 04 – Repeater 1-8
06 – Device Low Battery	01 – Zone 1-128 02 – Keypad 1-16 03 – Siren 1-16	04 – Repeater 1-8 05 – User 1-32
07 – Device Tamper	01 – Zone 1-128 02 – Keypad 1-16	03 – Siren 1-16 04 – Repeater 1-8
08 – RF Delinquency	01 – Zone 1-128 02 – Keypad 1-16	03 – Siren 1-16 04 – Repeater 1-8
09 – Module Supervisory	01 – HSM2HOSTx 02 – Keypad 1-16 04 – HS2108 1-15	05 – HSM2300 1-4 06 – HSM2204 08 – HSM2208 1-4
10 – Module Tamper	01 – HSM2HOSTx 02 – Keypad 1-16 04 – HS2108 1-15	05 – HSM2300 1-4 06 – HSM2204 08 – HSM2208 1-4
11 – Communications	01 – TLM 02 – Phone number 01-04 03 – Alt. comm SIM lock 04 – Alt. comm cellular 05 – Alt. comm Ethernet	06 – Receiver 1-4 absent 07 – Receiver 1-4 supervision 09 – Alt. comm fault
12 – Not Networked	01 – Zone 1-128 02 – Keypad 1-16 03 – Siren 1-16	04 – Repeater 1-8 05 – User 1-32

Trouble [1] Service Required		Press [01] to determine specific trouble	
Trouble	Troubleshooting		
[01] Bell Circuit Bell+, Bell-...open circuit.	<ul style="list-style-type: none"> • Disconnect Bell-/+ leads and measure resistance: <ul style="list-style-type: none"> • Open circuit indicates break in wiring or defective siren/bell. • Jumper Bell+/- with 1K resistor (Brown, Black, Red): 		
[02] RF Jam Detected Wireless receiver - excessive noise detected.	<ul style="list-style-type: none"> • Check event buffer to determine specific trouble. • If buffer logs RF jam, check for RF interference. • Disable RF Jam: section [804] sub-section [801]. 		
[03] Aux Supply An auxiliary power supply trouble is present.	<ul style="list-style-type: none"> • Check for a short between Aux+ and Aux- or other system ground. • Ensure the aux current draw has not exceeded the documented limits. 		
[04] Time and Date The alarm controller internal clock is not set.	<p>To program the time and date:</p> <ul style="list-style-type: none"> • Enter [*][6][Master Code] then press [01]. • Enter the time and date (24-hour clock) using the following format: HH:MM MM/DD/YY e.g., For 6:00 pm, June 29, 2010: Enter: [18] [00] [06] [29] [10] 		
[05] Output 1 Fault HSM2204 output#1 open circuit.	<ul style="list-style-type: none"> • If output #1 is unused: ensure terminals O1, AUX are jumpered with 1K resistor (brown, black, red). • If output #1 is used: disconnect wire leads from O1, AUX terminals, measure resistance of leads: <ul style="list-style-type: none"> • Open circuit indicates a break in wiring. 		
Trouble [2] Module Battery		Press [02] to determine specific trouble	
Trouble	Troubleshooting		
[01] Panel Low Battery The panel detects that the battery is below the low battery threshold (less than 11.5VDC). NOTE: This trouble condition will not clear until the battery voltage is 12.5VDC min., under load.	<ul style="list-style-type: none"> • NOTE: If battery is new allow 1 hour to charge. • Verify voltage measured across AC terminals is 16-18 VAC. Replace transformer if required. • Disconnect battery wire leads: <ul style="list-style-type: none"> • Verify battery charging voltage measured across battery leads = 13.70 - 13.80 VDC. • Connect battery, remove AC power. • Verify measured voltage across Aux terminals is 12.5VDC min. 		
[02] Panel No Battery The panel detects that no battery is present or that the battery is shorted.	<ul style="list-style-type: none"> • Verify battery is connected. • Refer to troubleshooting steps for panel low battery. 		
[04] 4 High Current output 1-4 Low Battery (HSM2204) HSM2204 battery less than 11.5VDC. NOTE: This trouble condition will not clear until the battery voltage is 12.5VDC min., under load.	<ul style="list-style-type: none"> • Charge battery. It may be low due to a long period without AC. • Replace battery if it is no longer able to hold a charge due to age. 		
[05] 4 High Current output 1-4 No Battery (HSM2204) Enter 05 to view which HSM2204 does not have a battery connected.	<ul style="list-style-type: none"> • Verify battery is connected. • Refer to troubleshooting steps for panel low battery. 		
[7] Power Supply 1-4 Low Battery (HSM2300) Enter 07 to view which HSM2300 has a battery voltage less than 11.5V.	<ul style="list-style-type: none"> • Charge battery. It may be low due to a long period without AC. • Replace battery if it is no longer able to hold a charge due to age. 		
[8] Power Supply 1-4 No Battery (HSM2300) Enter 08 to view which HSM2300 does not have a battery connected.	<ul style="list-style-type: none"> • Verify battery is connected. • Refer to troubleshooting steps for panel low battery. 		

Trouble [3] Bus Voltage Trouble		Press [03] to determine specific trouble
Trouble	Troubleshooting	
[01] HSM2HOST Bus Low Voltage The 2-way wireless integration module has detected a voltage less than 6.3V on its aux input.	<ul style="list-style-type: none"> • Ensure voltage at module is higher than the documented limits. • Ensure wire run is not too long. • Check voltage of panel battery. • Trouble should clear when AC is re-applied and the battery has had time to charge. • Disconnect AC and allow the panel to run on battery power. Ensure voltage at module is higher than the documented limits. 	
[02] Keypad 1-16 Bus Low Voltage Enter 02 to view hardwired keypads with a bus voltage of less than 6.9V for ICON/LCD models that include a wireless transceiver, 7.7V for the ICON/LCD/LED models that do not.		
[04] HSM2108 Bus Low Voltage Enter 04 to view zone expanders with a bus voltage of less than 5.9V.		
[05] HSM2300 Bus Low Voltage Enter 05 to view power supplies with a bus voltage of less than 6.9V.		
[06] HSM2204 Bus Low Voltage Enter 06 to view high current output modules that have detected a bus voltage of less than 6.9V.		
[11] HSM2208 Bus Low Voltage The low current output module has detected a voltage less than 5.9V on its aux input.		
Trouble [4] AC Failure		Press [04] to determine specific trouble
Trouble	Troubleshooting	
[01] Zone 1-128 AC [05] HSM2300 AC 1-4 [06] HSM2204 1-4 AC [07] Alarm Controller An AC trouble has been detected on a device or module.	<ul style="list-style-type: none"> • Verify voltage measured across AC terminals is 16-18VAC. Replace transformer if required. 	
Trouble [05] Device Faults		Press [05] to determine specific trouble
Trouble	Troubleshooting	
[01] Zone 1-128 faults Wireless zones: Enter [01] to view zones in fault. This trouble is generated by a zone wireless supervisory trouble.	<ul style="list-style-type: none"> • Ensure fire zones have a 5.6K resistor (green, blue, red) connected. • Remove wire leads from Z and COM terminals and measure resistance of the wire leads: <ul style="list-style-type: none"> • Check for a short on DEOL zones or an open condition on SEOL fire zones. • Connect a 5.6K resistor across the Z and COM terminals. Verify the trouble condition clears. • Placement test a wireless device and re-locate it if bad results are received. 	
Hardwired zones: Enter [01] to view zones in fault. “Fire Zone” is displayed in the [*][2] menu if an open circuit is present on PGM2 being used as a 2-wire smoke detector input. This trouble is generated by a short on hardwired zones when DEOL is used.	<ul style="list-style-type: none"> • Ensure a 2.2K EOL resistor is connected (red, red, red). • Remove wire leads from PGM2 and AUX+ terminals and measure resistance of the wire leads: <ul style="list-style-type: none"> • An open circuit indicates a break in the wiring or no resistor connected. • Connect a 2.2K resistor across PGM2 and AUX+ terminals. Verify that trouble clears. 	
[02] Keypad 1-16 faults Enter [02] to view keypads in fault. This trouble is caused by a wireless supervisory fault if the keypad is wireless.	<ul style="list-style-type: none"> • Placement test the wireless keypad and re-locate if needed. 	
[03] Siren 1-16 faults This trouble is caused by a wireless supervisory fault on a wireless siren.	<ul style="list-style-type: none"> • See [02] Keypad 1-16 faults above. 	
[04] Repeater 1-8 faults This trouble is caused by a wireless supervisory fault on a wireless repeater, or by the repeater shutting down due to a loss of AC/DC power.	<ul style="list-style-type: none"> • See [02] Keypad 1-16 faults above. 	
Additional trouble conditions: <ul style="list-style-type: none"> • Fire (2-W Smoke, PGX916, PGX926, PGX936) • Gas (PGX923) • Heat (PGX946) 	<ul style="list-style-type: none"> • Freeze (PGX905) • CO (PGX913) • Probe Disconnected (PGX905, PGX985) 	

Trouble [6] Device Low Battery		Press [06] to toggle through specific devices with low battery trouble
Trouble	Troubleshooting	
[01] Zones 1-128 [02] Keypad 1-16 [03] Siren 1-16 [04] Repeater 1-8 [05] User 1-32 One or more wireless devices has a low battery. NOTE: The event is not logged to the event buffer until the wireless device low battery delay time expires. Programming section [377], Opt 002.	<ul style="list-style-type: none"> • Verify zone operation. • Verify that tamper and low battery condition is cleared and reported. • View which device is in low battery through the [*][2] menu. 	
Trouble [7] Device Tamper		Press [07] to determine specific trouble
Trouble	Troubleshooting	
[01] Zone 1-128 tampers [02] Keypad 1-16 tampers [03] Siren 1-16 tampers [04] Repeater 1-8 tampers An open circuit is present on one or more zones with DEOL resistors enabled.	<ul style="list-style-type: none"> • Check that the tamper switch is securely attached to the wall. • Remove the wire leads from I/O and COM and measure the resistance of the wire leads. • Connect a 5.6K resistor (Green, Blue, Red) across the I/O and COM terminals. • Verify the trouble condition clears. 	
A tamper condition is present on one or more wireless devices.	<ul style="list-style-type: none"> • Ensure device cover is secure. • Ensure device is correctly mounted for wall tamper operation. • Trip, then restore the tamper. If tamper condition persists, replace wireless device. 	
Trouble [8] RF Delinquency		Press [08] to determine specific trouble
Trouble	Troubleshooting	
[01] Zone 1-128 faults [02] Keypad 1-16 faults [03] Siren 1-16 faults [04] Repeater 1-8 faults HSM2HOST has not received a supervisory signal from a wireless device for 20 minutes.	<ul style="list-style-type: none"> • Open/close the device, press a key on the keypad or tamper/restore. • Ensure the device is physically present. • Check for device faults (e.g., low battery). • Check the current signal strength and during the last 24 hours. • Replace the battery. • Replace the device. 	
Trouble [9] Module Supervisory		Press [09] to determine specific zones with a tamper trouble
Trouble	Troubleshooting	
[01] HSM2HOST [02] Keypad 1-16 [04] HSM2108 1-15 [05] HSM2300 1-4 [06] HSM2204 [08] HSM2208 1-4 No supervisory response from enrolled module.	<ul style="list-style-type: none"> • Modules are immediately enrolled and supervised. If a module is removed, or if the keypad slot is changed, module supervision must be reset. • View the event buffer to identify the specific module(s) in trouble. • To reset module supervision: <ul style="list-style-type: none"> • Enter programming section [902]. • Select auto or manual enrollment. • Enter programming section [903] to identify modules connected to the Corbus. 	
Trouble [10] Module Tamper		Press [10] to determine specific trouble
Trouble	Troubleshooting	
[01] HSM2HOST [02] Keypad 1-16 [04] HSM2108 1-15 [05] HSM2300 1-4 [06] HSM2204 [08] HSM2208 1-4 A tamper condition is present on one or more modules.	<ul style="list-style-type: none"> • Ensure the TAM terminal on HSM2108, HSM2300, HSM2204 and HSM2208 modules is shorted to ground if tamper support is not used. • Ensure module cover is secure. • Ensure module is correctly mounted for wall tamper operation. • Trip, then restore the tamper. If tamper condition persists, replace the module. 	

Trouble [11] Communications		Press [11] to determine specific trouble
Trouble	Troubleshooting	
[01] Phone Line Trouble Phone line voltage at TIP, RING on main panel less than 3VDC.	<ul style="list-style-type: none"> • Measure the voltage across TIP and RING on the panel: <ul style="list-style-type: none"> • No phone off-hook – 50VDC (approx). • Any phone off-hook – 5VDC (approx). • Wire incoming line directly to TIP and RING. • If trouble clears, check wiring or the RJ-31 phone jack. 	
[02] Phone Number 1-4 The system failed to communicate with a receiver using one of the enabled phone numbers. Enter [02] to view phone numbers with failure to communicate troubles.	<ul style="list-style-type: none"> • Ensure adequate line voltage at the panel Tip and Ring (On hook ~41VDC, Off hook ~7VDC). • Ensure panel phone number is programmed correctly when using . If using IP or cellular, ensure alternate communicator has the correct IP addresses and programming. 	
[03] Alternate Comm SIM Lock SIM lock is enabled and the unit does not have the correct SIM PIN.	<ul style="list-style-type: none"> • See the communicator installation manual for details. 	
[04] Alternate Comm Cellular The alternate communicator has detected a radio or SIM failure, a cellular network trouble, or insufficient signal strength.	<ul style="list-style-type: none"> • See the communicator installation manual for details. 	
[05] Alternate Comm Ethernet The alternate communicator has detected a network absent condition.	<ul style="list-style-type: none"> • See the communicator installation manual for details. 	
[06] Receiver 1-4 Absent Alternate communicator supervision loss or failure to initialize a receiver.	<ul style="list-style-type: none"> • See the communicator installation manual for details. 	
[07] Receiver 1-4 Supervision The alarm system loses communication with an Ethernet or cellular receiver on the system.	<ul style="list-style-type: none"> • See the communicator installation manual for details. 	
[08] Alt. Comm Configuration The SIM is active but the unit has not received programming from Connect 24.	<ul style="list-style-type: none"> • See the communicator installation manual for details. 	
[09] Alternate Comm Fault The alternate communicator has not responded to any poll commands. Alt Comm Fault is displayed in [*][2] and the event buffer.	<ul style="list-style-type: none"> • See the communicator installation manual for details. 	
[10] Alternate Comm FTC Fault	<ul style="list-style-type: none"> • Refer to the communicator installation manual for more details. 	
Trouble [12] Not Networked		Press [12] to toggle through troubles
Trouble	Troubleshooting	
[01] Zones 1-128 [02] keypad 1-16 [03] Siren 1-16 [04] Repeater 1-8 [05] User 1-16 A device is out of sync with the wireless network or was not synchronized with the network after enrollment.	<ul style="list-style-type: none"> • Ensure the device is physically present. • Check the current signal strength and during the last 24 hours. • Replace the battery or press the tamper switch. • Enroll the device again. 	

IMPORTANT!

Ensure you have the following information available before contacting Customer Support:

- Alarm controller type and version, (e.g., HSM2064 1.0):
Note: Version number can be accessed by entering [*][Installer Code][900] on any LCD keypad. This information is also located on a sticker on the printed circuit board.
- List of modules connected to control panel, (e.g., HSM2108, HSM2HOSTx etc.).

Appendix A: Event Codes

The following tables contain Contact ID and Automatic SIA format reporting codes. See Programming Sections [308] for event reporting codes.

Contact ID

Each of the digits indicate specific information about the signal. For example, if zone 1 is an entry/exit point, the event code contains [34]. The central station would receive the following:

*BURG - ENTRY/EXIT - 1 where the "1" indicates which zone went into alarm.

See Table A-1 "Contact ID Event Codes" for code definitions.

SIA Format - Level 2 (Hard Coded)

The SIA communication format used in this product follows the level 2 specifications of the SIA Digital Communication Standard - October 1997. This format sends the account code along with its data transmission. The transmission appears similar to the following at the receiver:

```
N ri1    BA 01
N      = New Event
ri1    = Partition /Area Identifier
BA     = Burglary Alarm
01     = Zone 1
```

A system event uses the Area Identifier ri00.

Contact ID Zone Alarm/Restore Event Codes

Section #	Definition	Dialer Direction*	Automatic Contact ID Codes	SIA Auto Rep Codes**
Zone Events				
[307]	Zone alarms	A/R	See tables on page 103 for details	
[307]	Zone restores	A/R		
[307]	Zone tamper/restore	MA/R	383-ZZZ	TA-ZZZ/ TR-ZZZZ
[307]	Zone fault/restore	MA/R	38A-ZZZ	UT-ZZZZ/UJ-ZZZZ
Tamper Events				
[308]-[101]	Keypad 1 tamper/restore alarm	T/R	(3)83-601	TA-0601/TR-0601
[308]-[101]	Keypad 2 tamper/restore alarm	T/R	(3)83-602	TA-0602/TR-0602
[308]-[101]	Keypad 3 tamper/restore alarm	T/R	(3)83-603	TA-0603/TR-0603
[308]-[101]	Keypad 4 tamper/restore alarm	T/R	(3)83-604	TA-0604/TR-0604
[308]-[101]	Keypad 5 tamper/restore alarm	T/R	(3)83-605	TA-0605/TR-0605
[308]-[101]	Keypad 6 tamper/restore alarm	T/R	(3)83-606	TA-0606/TR-0606
[308]-[101]	Keypad 7 tamper/restore alarm	T/R	(3)83-607	TA-0607/TR-0607
[308]-[101]	Keypad 8 tamper/restore alarm	T/R	(3)83-608	TA-0608/TR-0608
[308]-[101]	Keypad 9 tamper/restore alarm	T/R	(3)83-609	TA-0609/TR-0609
[308]-[101]	Keypad 10 tamper/restore alarm	T/R	(3)83-610	TA-0610/TR-0610
[308]-[101]	Keypad 11 tamper/restore alarm	T/R	(3)83-611	TA-0611/TR-0611
[308]-[101]	Keypad 12 tamper/restore alarm	T/R	(3)83-612	TA-0612/TR-0612
[308]-[101]	Keypad 13 tamper/restore alarm	T/R	(3)83-613	TA-0613/TR-0613
[308]-[101]	Keypad 14 tamper/restore alarm	T/R	(3)83-614	TA-0614/TR-0614
[308]-[101]	Keypad 15 tamper/restore alarm	T/R	(3)83-615	TA-0615/TR-0615
[308]-[101]	Keypad 16 tamper/restore alarm	T/R	(3)83-616	TA-0616/TR-0616
[308]-[101]	Siren 1 tamper/restore alarm	T/R	(3)83-801	TA-0801/TR-0801
[308]-[101]	Siren 2 tamper/restore alarm	T/R	(3)83-802	TA-0802/TR-0802
[308]-[101]	Siren 3 tamper/restore alarm	T/R	(3)83-803	TA-0803/TR-0803
[308]-[101]	Siren 4 tamper/restore alarm	T/R	(3)83-804	TA-0804/TR-0804
[308]-[101]	Siren 5 tamper/restore alarm	T/R	(3)83-805	TA-0805/TR-0805
[308]-[101]	Siren 6 tamper/restore alarm	T/R	(3)83-806	TA-0806/TR-0806
[308]-[101]	Siren 7 tamper/restore alarm	T/R	(3)83-807	TA-0807/TR-0807
[308]-[101]	Siren 8 tamper/restore alarm	T/R	(3)83-808	TA-0808/TR-0808
[308]-[101]	Siren 9 tamper/restore alarm	T/R	(3)83-809	TA-0809/TR-0809
[308]-[101]	Siren 10 tamper/restore alarm	T/R	(3)83-810	TA-0810/TR-0810
[308]-[101]	Siren 11 tamper/restore alarm	T/R	(3)83-811	TA-0811/TR-0811
[308]-[101]	Siren 12 tamper/restore alarm	T/R	(3)83-812	TA-0812/TR-0812
[308]-[101]	Siren 13 tamper/restore alarm	T/R	(3)83-813	TA-0813/TR-0813

Section #	Definition	Dialer Direction*	Automatic Contact ID Codes	SIA Auto Rep Codes**
[308]-[101]	Siren 14 tamper/restore alarm	T/R	(3)83-814	TA-0814/TR-0814
[308]-[101]	Siren 15 tamper/restore alarm	T/R	(3)83-815	TA-0815/TR-0815
[308]-[101]	Siren 16 tamper/restore alarm	T/R	(3)83-816	TA-0816/TR-0816
[308]-[101]	Repeater 1 tamper/restore alarm	T/R	(3)83-901	TA-0901/TR-0901
[308]-[101]	Repeater 2 tamper/restore alarm	T/R	(3)83-902	TA-0902/TR-0902
[308]-[101]	Repeater 3 tamper/restore alarm	T/R	(3)83-903	TA-0903/TR-0903
[308]-[101]	Repeater 4 tamper/restore alarm	T/R	(3)83-904	TA-0904/TR-0904
[308]-[101]	Repeater 5 tamper/restore alarm	T/R	(3)83-905	TA-0905/TR-0905
[308]-[101]	Repeater 6 tamper/restore alarm	T/R	(3)83-906	TA-0906/TR-0906
[308]-[101]	Repeater 7 tamper/restore alarm	T/R	(3)83-907	TA-0907/TR-0907
[308]-[101]	Repeater 8 tamper/restore alarm	T/R	(3)83-908	TA-0908/TR-0908
[308]-[101]	HSM2108: 8-Zone Expander module #1 tamper/restored	T/R	(3)41-101	ES-0101/EJ-0101
[308]-[101]	HSM2108: 8-Zone Expander module #2 tamper/restored	T/R	(3)41-102	ES-0102/EJ-0102
[308]-[101]	HSM2108: 8-Zone Expander module #3 tamper/restored	T/R	(3)41-103	ES-0103/EJ-0103
[308]-[101]	HSM2108: 8-Zone Expander module #4 tamper/restored	T/R	(3)41-104	ES-0104/EJ-0104
[308]-[101]	HSM2108: 8-Zone Expander module #5 tamper/restored	T/R	(3)41-105	ES-0105/EJ-0105
[308]-[101]	HSM2108: 8-Zone Expander module #6 tamper/restored	T/R	(3)41-106	ES-0106/EJ-0106
[308]-[101]	HSM2108: 8-Zone Expander module #7 tamper/restored	T/R	(3)41-107	ES-0107/EJ-0107
[308]-[101]	HSM2108: 8-Zone Expander module #8 tamper/restored	T/R	(3)41-108	ES-0108/EJ-0108
[308]-[101]	HSM2108: 8-Zone Expander module #9 tamper/restored	T/R	(3)41-109	ES-0109/EJ-0109
[308]-[101]	HSM2108: 8-Zone Expander module #10 tamper/restored	T/R	(3)41-110	ES-0110/EJ-0110
[308]-[101]	HSM2108: 8-Zone Expander module #11 tamper/restored	T/R	(3)41-111	ES-0111/EJ-0111
[308]-[101]	HSM2108: 8-Zone Expander module #12 tamper/restored	T/R	(3)41-112	ES-0112/EJ-0112
[308]-[101]	HSM2108: 8-Zone Expander module #13 tamper/restored	T/R	(3)41-113	ES-0113/EJ-0113
[308]-[101]	HSM2108: 8-Zone Expander module #14 tamper/restored	T/R	(3)41-114	ES-0114/EJ-0114
[308]-[101]	HSM2108: 8-Zone Expander module #15 tamper/restored	T/R	(3)41-115	ES-0115/EJ-0115
[308]-[101]	HSM2108: 8-Zone Expander module #16 tamper/restored	T/R	(3)41-116	ES-0116/EJ-0116
[308]-[101]	HSM2208: 8-Output Expander module #1 tamper/restored	T/R	(3)41-201	ES-0201/EJ-0201
[308]-[101]	HSM2208: 8-Output Expander module #2 tamper/restored	T/R	(3)41-202	ES-0202/EJ-0202
[308]-[101]	HSM2208: 8-Output Expander module #3 tamper/restored	T/R	(3)41-203	ES-0203/EJ-0203
[308]-[101]	HSM2208: 8-Output Expander module #4 tamper/restored	T/R	(3)41-204	ES-0204/EJ-0204
[308]-[101]	HSM2208: 8-Output Expander module #5 tamper/restored	T/R	(3)41-205	ES-0205/EJ-0205
[308]-[101]	HSM2208: 8-Output Expander module #5 tamper/restored	T/R	(3)41-206	ES-0206/EJ-0206
[308]-[101]	HSM2208: 8-Output Expander module #7 tamper/restored	T/R	(3)41-207	ES-0207/EJ-0207
[308]-[101]	HSM2208: 8-Output Expander module #8 tamper/restored	T/R	(3)41-208	ES-0208/EJ-0208
[308]-[101]	HSM2208: 8-Output Expander module #9 tamper/restored	T/R	(3)41-209	ES-0209/EJ-0209
[308]-[101]	HSM2208: 8-Output Expander module #10 tamper/restored	T/R	(3)41-210	ES-0210/EJ-0210
[308]-[101]	HSM2208: 8-Output Expander module #11 tamper/restored	T/R	(3)41-211	ES-0211/EJ-0211
[308]-[101]	HSM2208: 8-Output Expander module #12 tamper/restored	T/R	(3)41-212	ES-0212/EJ-0212
[308]-[101]	HSM2208: 8-Output Expander module #13 tamper/restored	T/R	(3)41-213	ES-0213/EJ-0213
[308]-[101]	HSM2208: 8-Output Expander module #14 tamper/restored	T/R	(3)41-214	ES-0214/EJ-0214
[308]-[101]	HSM2208: 8-Output Expander module #15 tamper/restored	T/R	(3)41-215	ES-0215/EJ-0215
[308]-[101]	HSM2208: 8-Output Expander module #16 tamper/restored	T/R	(3)41-216	ES-0216/EJ-0216
[308]-[101]	HSM2204: Power Supply-1A (4 high-current outputs) #1 tamper/restored	T/R	(3)41-601	ES-0601/EJ-0601
[308]-[101]	HSM2204: Power Supply-1A (4 high-current outputs) #2 tamper/restored	T/R	(3)41-602	ES-0602/EJ-0602
[308]-[101]	HSM2204: Power Supply-1A (4 high-current outputs) #3 tamper/restored	T/R	(3)41-603	ES-0603/EJ-0603
[308]-[101]	HSM2204: Power Supply-1A (4 high-current outputs) #4 tamper/restored	T/R	(3)41-604	ES-0604/EJ-0604
[308]-[101]	HSM2300: Power Supply module #1 tamper/restored	T/R	(3)41-620	ES-0620/EJ-0620
[308]-[101]	HSM2300: Power Supply module #2 tamper/restored	T/R	(3)41-621	ES-0621/EJ-0621
[308]-[101]	HSM2300: Power Supply module #3 tamper/restored	T/R	(3)41-622	ES-0622/EJ-0622
[308]-[101]	HSM2300: Power Supply module #4 tamper/restored	T/R	(3)41-623	ES-0623/EJ-0623
[308]-[101]	Keypad Lockout - Incorrect access code entry	T/R	(4)61-000	JA-0000

Section #	Definition	Dialer Direction*	Automatic Contact ID Codes	SIA Auto Rep Codes**
Opening Events				
[308]-[201]	User Openings - Disarmed by user	O/C	(4)A1-UUU	OP-UUUU
[308]-[202]	Automatic Arming Canceled	O/C	(4)55-000	CI-0000
[308]-[201]	Special Opening - System disarmed using: keyswitch, maintenance code, DLS software, wireless key	O/C	(4)AA-000	OP-0000
[308]-[211]	Late to Open - System not disarmed before late to open time expired	O/C	E(4)53-000	CT-0000
[308]-[202]	Automatic (Schedule) Opening	O/C	(4)A3-000	OA-0000
Closing Events				
[308]-[201]	User Closings - System armed by user	O/C	E(4)A1-UUU	CL-UUUU
[308]-[221]	Partial Closing - 1 or more zones bypassed when armed	O/C	(4)56-000	CG-0000
[308]-[201]	Special Closing - System armed via: quick arm, keyswitch, function key, maintenance code, DLS software, wireless key	O/C	(4)AA-000	CL-0000
[308]-[211]	Late to Close - Auto-arm prealert sounded	O/C	(4)A3-000	CA-0000
[308]-[211]	Exit Fault	O/C	(3)74-ZZZ	EA-ZZZZ
System Trouble Events				
[308]-[301]	Battery trouble/restore - Main panel	MA/R	(3)A2-000	YT-0000/YR-0000
[308]-[301]	Battery absent trouble/restore - Main panel	MA/R	(3)11-000	YM-0000/YR-0000
[308]-[301]	Battery charging trouble/restore - Main panel	MA/R	(3)AA-000	YP-0000/YQ-0000
[308]-[301]	Panel AC trouble/restore - Main panel	MA/R	(3)A1-000	AT-0000/AR-0000
[308]-[302]	Bell Circuit trouble/restore	MA/R	(3)21-000	YA-0999/YH-0999
[308]-[302]	TLM (telephone line) fail/restore	MA/R	(3) 51-000	LT-0001/LR-0001
[308]-[302]	Auxiliary Power trouble/restore	MA/R	(3) 12-000	YP-0000/YQ-0000
[308]-[305]	PGM 2, 2-Wire Smoke trouble/restore	MA/R	(3)73-992	FT-0992/FJ-0992
Module Troubles				
[308]-[332]	Hardwired Module Low Voltage trouble/restore - System	MA/R	(3)AA-000	EM-0000/EN-0000
[308]-[332]	Hardwired Module Low Voltage trouble/restore - Keypads	MA/R	(3)AA-001-032	EM-0001-0032 EN-0001-0032
[308]-[332]	Hardwired Module Low Voltage trouble/restore - HSM2108	MA/R	(3)AA-101-162	EM-0101-0162 EN-0101-0162
[308]-[332]	Hardwired Module Low Voltage trouble/restore - HSM2208	MA/R	(3)AA-201-262	EM-0201-0262 EN-0201-0262
[308]-[332]	Hardwired Module Low Voltage trouble/restore - HSM2HOST	MA/R	(3)AA-551	EM-0551 EN-0551
[308]-[332]	Hardwired Module Low Voltage trouble/restore - HSM2204	MA/R	(3)AA-601-604	EM-0601-0601 EN-0601-0604
[308]-[332]	Hardwired Module Low Voltage trouble/restore - HSM2300	MA/R	(3)AA-621-624	EM-0621-0624 EN-0621-0624
[308]-[332]	Hardwired Module Supervisory trouble/restore - System	MA/R	(3)A-000	ET-0000/ER-0000
[308]-[332]	Hardwired Module Supervisory trouble/restore - Keypads	MA/R	(3)A-001-032	ET-0001-0032 ER-0001-0032
[308]-[332]	Hardwired Module Supervisory trouble/restore - HSM2108	MA/R	(3)A-101-162	ET-0101-0162 ER-0101-0162
[308]-[332]	Hardwired Module Supervisory trouble/restore - HSM2208	MA/R	(3)A-201-262	ET-0201-0262 ER-0201-0262
[308]-[332]	Hardwired Module Supervisory trouble/restore - HSM2HOST	MA/R	(3)A-551	ET-0551 ER-0551
[308]-[332]	Hardwired Module Supervisory trouble/restore - HSM2204	MA/R	(3)A-601-604	ET-0601-0601 ER-0601-0604
[308]-[332]	Hardwired Module Supervisory trouble/restore - HSM2300	MA/R	(3)A-621-624	ET-0621-0624 ER-0621-0624
[308]-[332]	Hardwired Module Supervisory trouble/restore	MA/R	(3)3A-MMM	ET-MMMM/ER-MMMM
[308]-[332]	HSM2204 Aux Supply 1 trouble/restore	MA/R	(3)12-601	YI-0601/YJ-0601
[308]-[332]	HSM2204 Aux Supply 2 trouble/restore	MA/R	(3)12-602	YI-0602/YJ-0602
[308]-[332]	HSM2204 Aux Supply 3 trouble/restore	MA/R	(3)12-603	YI-0603/YJ-0603
[308]-[332]	HSM2204 Aux Supply 4 trouble/restore	MA/R	(3)12-604	YI-0604/YJ-0604

Section #	Definition	Dialer Direction*	Automatic Contact ID Codes	SIA Auto Rep Codes**
[308]-[332]	HSM2300 Aux Supply 1 trouble/restore	MA/R	(3)12-621	YI-0621/YJ-0621
[308]-[332]	HSM2300 Aux Supply 2 trouble/restore	MA/R	(3)12-622	YI-0622/YJ-0622
[308]-[332]	HSM2300 Aux Supply 3 trouble/restore	MA/R	(3)12-623	YI-0623/YJ-0623
[308]-[332]	HSM2300 Aux Supply 4 trouble/restore	MA/R	(3)12-624	YI-0624/YJ-0624
[308]-[332]	HSM2204 Aux Supply 1 Low Battery trouble/restore	MA/R	(3)A2-601	YT-0601/YR-0601
[308]-[332]	HSM2204 Aux Supply 2 Low Battery trouble/restore	MA/R	(3)A2-602	YT-0602/YR-0602
[308]-[332]	HSM2204 Aux Supply 3 Low Battery trouble/restore	MA/R	(3)A2-603	YT-0603/YR-0603
[308]-[332]	HSM2204 Aux Supply 4 Low Battery trouble/restore	MA/R	(3)A2-604	YT-0604/YR-0604
[308]-[332]	HSM2300 Aux Supply 1 Low Battery trouble/restore	MA/R	(3)A2-621	YT-0621/YR-0621
[308]-[332]	HSM2300 Aux Supply 2 Low Battery trouble/restore	MA/R	(3)A2-622	YT-0622/YR-0622
[308]-[332]	HSM2300 Aux Supply 3 Low Battery trouble/restore	MA/R	(3)A2-623	YT-0623/YR-0623
[308]-[332]	HSM2300 Aux Supply 4 Low Battery trouble/restore	MA/R	(3)A2-624	YT-0624/YR-0624
[308]-[332]	HSM2204 Aux Supply 1 Battery absent trouble/restore	MA/R	(3)11-601	YM-0601/YR-0601
[308]-[332]	HSM2204 Aux Supply 2 Battery absent trouble/restore	MA/R	(3)11-602	YM-0602/YR-0602
[308]-[332]	HSM2204 Aux Supply 3 Battery absent trouble/restore	MA/R	(3)11-603	YM-0603/YR-0603
[308]-[332]	HSM2204 Aux Supply 4 Battery absent trouble/restore	MA/R	(3)11-604	YM-0604/YR-0604
[308]-[332]	HSM2300 Aux Supply 1 Battery absent trouble/restore	MA/R	(3)11-621	YM-0621/YJ-0621
[308]-[332]	HSM2300 Aux Supply 2 Battery absent trouble/restore	MA/R	(3)11-622	YM-0622/YJ-0622
[308]-[332]	HSM2300 Aux Supply 3 Battery absent trouble/restore	MA/R	(3)11-623	YM-0623/YJ-0623
[308]-[332]	HSM2300 Aux Supply 4 Battery absent trouble/restore	MA/R	(3)11-624	YM-0624/YJ-0624
[308]-[332]	HSM2204 Aux Supply 1 Charger trouble/restore	MA/R	(3)AA-601	YP-0601/YQ-0601
[308]-[332]	HSM2204 Aux Supply 2 Charger trouble/restore	MA/R	(3)AA-601	YP-0602/YQ-0602
[308]-[332]	HSM2204 Aux Supply 3 Charger trouble/restore	MA/R	(3)AA-601	YP-0603/YQ-0603
[308]-[332]	HSM2204 Aux Supply 4 Charger trouble/restore	MA/R	(3)AA-601	YP-0604/YQ-0604
[308]-[332]	HSM2300 Aux Supply 1 Charger trouble/restore	MA/R	(3)AA-621	YP-0621/YQ-0621
[308]-[332]	HSM2300 Aux Supply 2 Charger trouble/restore	MA/R	(3)AA-621	YP-0622/YQ-0622
[308]-[332]	HSM2300 Aux Supply 3 Charger trouble/restore	MA/R	(3)AA-621	YP-0623/YQ-0623
[308]-[332]	HSM2300 Aux Supply 4 Charger trouble/restore	MA/R	(3)AA-621	YP-0624/YQ-0624
Alternate Communicator				
[308]-[351]	Alternate Communicator fault/restore	MA/R	(3)3A-000	ET-0000/ER-0000
[308]-[351]	Alternate Communicator Radio/Sim failure/restore	MA/R	(3)AA-001	YX-0001/YZ-0001
[308]-[351]	Alternate Communicator cellular trouble/restore	MA/R	(3)AA-001	YX-0001/YZ-0001
[308]-[352]	Alternate Communicator Ethernet trouble/restore	MA/R	(3)AA-001	YX-0001/YZ-0001
[308]-[354]	Alternate Communicator Receiver 1 absent/restore	MA/R	(3)5A-001	YS-0001/YZ-0001
[308]-[354]	Alternate Communicator Receiver 2 absent/restore	MA/R	(3)5A-002	YS-0002/YZ-0002
[308]-[354]	Alternate Communicator Receiver 3 absent/restore	MA/R	(3)5A-003	YS-0003/YZ-0003
[308]-[354]	Alternate Communicator Receiver 4 absent/restore	MA/R	(3)5A-004	YS-0004/YZ-0004
[308]-[355]	Alternate Communicator Receiver 1 Supervisory trouble/restore	MA/R	(3)5A-001	YS-0001/YK-0001
[308]-[355]	Alternate Communicator Receiver 2 Supervisory trouble/restore	MA/R	(3)5A-001	YS-0001/YK-0001
[308]-[355]	Alternate Communicator Receiver 3 Supervisory trouble/restore	MA/R	(3)5A-001	YS-0001/YK-0001
[308]-[355]	Alternate Communicator Receiver 4 Supervisory trouble/restore	MA/R	(3)5A-001	YS-0001/YK-0001
[308]-[353]	Alternate Communicator SMS Config trouble/restore	MA/R	(3)AA-001	YX-0001/YZ-0001
[308]-[351]	Remote Programming Begin/End	MA/R	(6)27-001	LB-0000/LS-0000
[308]-[351]	General Alternate Communicator trouble/restore	MA/R	(3)AA-001	YX-0001/YR-0001
Wireless Events				
[308]-[361]	Wireless Zone Low Battery trouble/restore. ZZZ= Wireless zones 001-128.	MA/R	(3) 84-ZZZ	XT-ZZZZ/XR-ZZZZ
[308]-[361]	Wireless Device Low Battery trouble/restore. ZZZ= 601-616: wireless keypads, 701-764: wireless keys, 801-864: wireless Sirens, 901-908: wireless repeaters	MA/R	(3) 84-ZZZ	XT-ZZZZ/XR-ZZZZ
[308]-[361]	Wireless Zone AC trouble/restore	MA/R	(3)A1-ZZZ	AT-ZZZZ/AR-ZZZZ
[308]-[361]	Wireless Device Fault/restore	MA/R	(3)8A-ZZZ	UT-ZZZZ/UJ-ZZZZ
[308]-[361]	Wireless Temperature Probe trouble/restore	MA/R	(3)8A-ZZZ	KT-ZZZZ/KJ-ZZZZ
[308]-[361]	Repeater 1 AC fail/restore	MA/R	(3)A1-901	AT-0901/AR-0901
[308]-[361]	Repeater 2 AC fail/restore	MA/R	(3)A1-902	AT-0902/AR-0902
[308]-[361]	Repeater 3 AC fail/restore	MA/R	(3)A1-903	AT-0903/AR-0903
[308]-[361]	Repeater 4 AC fail/restore	MA/R	(3)A1-904	AT-0904/AR-0904

Section #	Definition	Dialer Direction*	Automatic Contact ID Codes	SIA Auto Rep Codes**
[308]-[361]	Repeater 5 AC fail/restore	MA/R	(3)A1-905	AT-0905/AR-0905
[308]-[361]	Repeater 6 AC fail/restore	MA/R	(3)A1-906	AT-0906/AR-0906
[308]-[361]	Repeater 7 AC fail/restore	MA/R	(3)A1-907	AT-0907/AR-0907
[308]-[361]	Repeater 8 AC fail/restore	MA/R	(3)A1-908	AT-0908/AR-0908
Miscellaneous Alarms				
[308]-[001]	Duress Alarm - Code entered at keypad	A/R	(1)21-000	HA-0000
[308]-[001]	Opening After Alarm - Disarmed with alarm in memory	A/R	(4)58-000	OR-0000
[308]-[001]	Recent Closing - Alarm occurs within two minutes of system arming	A/R	(4)59-UUU	CR-UUUU
[308]-[001]	Burglary Verified - a second cross zone alarm occurs within the cross zoning time	A/R	(1)39-000	BV-0000
[308]-[001]	Burglary Not Verified - a second cross zone alarm does not occur within the cross zoning time	A/R	(3)78-000	BG-0000
[308]-[001]	HSM2108 Zone Expander Supervisory Alarm/restore	A/R	(1)43-000	UA-0000/UH-0000
[308]-[011]	Alarm Canceled before expiry of alarm cancellation timer	A/R	(4)A6-UUU	BC-UUUU
[308]-[011]	PGM2 (Silent 24 Hour Input) -Aux Input Alarm/restore	A/R	(1)4A-992	UA-9992/UH-9992
[308]-[011]	PGM2 (Audible 24 Hour Input) -Aux Input Alarm/restore	A/R	(1)4A-992	UA-0992/UH-0992
Priority Alarm and Restoral Events				
	[F] Key alarm/restore	A/R	(1)1A-000	FA-0000/FH-0000
	[M] Key alarm/restore	A/R	(1)AA-000	MA-0000/MH-0000
	[P] Key alarm/restore	A/R	(1)2A-000	PA-0000/PH-0000
Miscellaneous Closing				
[308]-[221]	Zone Bypass at time of arming	O/C	(5)7A-ZZZ	UB-ZZZZ
Testing				
[308]-[401]	Walk Test Begin/End	T	(6)A7-UUU	TS-UUUU/TE-UUUU
[308]-[401]	Periodic Test	T	(6)A2-000	RP-0000/RY-0000
[308]-[401]	System Test - [*][6] bell/communications test	T	(6)A1-000	RX-0000
Maintenance				
[308]-[311]	General System trouble/restore - An RF jam trouble occurred/was restored	MA/R	(3) AA-000	YX-0000/YZ/0000
[308]-[311]	Fire trouble/restore	MA/R	(3)73-000	FT-0000/FJ-000
[308]-[314]	Gas trouble/restore	MA/R	(3)8A-ZZZ	GT-ZZZ/GJ-ZZZ
[308]-[314]	Heat trouble/restore	MA/R	E38A-ZZZ	KT-ZZZ/KJ-ZZZ
[308]-[311]	Cold Start - System has restarted after total power loss	MA/R	(3) A5-000	RR-0000
[308]-[312]	Event Buffer 75% Full	MA/R	(6)22-000	JL-0000
[308]-[312]	DLS Lead In - Download session start	MA/R	(4)11-000	RB-0000
[308]-[312]	DLS Lead Out - Download session stop	MA/R	(4)12-000	RS-0000
[308]-[312]	SA Lead In - Download session start	MA/R	(4)11-000	RB-0000
[308]-[312]	SA Lead Out - Download session stop	MA/R	(4)12-000	RS-0000
[308]-[312]	Installer Lead In - Installer Programming has been entered	MA/R	(6)27-000	LB-0000
[308]-[312]	Installer Lead out - Installer Programming has been exited	MA/R	(6)28-000	LS-0000
[308]-[313]	Panel firmware update begin/ successful	MA/R	(9)01-900	LB-0900/LS-0900
[308]-[313]	Panel firmware update fail	MA/R	(9)02-900	LU-0900
[308]-[401]	Periodic test with trouble	T	(6)A2-RRR	RP-0000
*	A/R = alarms/restores; T/R = tampers/restores; O/C = openings/closings; MA/R = maintenance alarms/restores; T = test transmissions			
**	UUU = user number (user 001-095); ZZZ/ZZZZ = zone number (001-128).			

Contact ID SIA Zone Alarm/Restore Event Codes

(as per SIA DCS: 'Contact ID' 01-1999):

The table below defines the meaning of all contact ID alarm/restore event codes.

Table A-1 Contact ID Event Codes

Zone Definition	SIA Auto Rep Codes	Contact ID Auto Rep Codes
Delay 1	BA-ZZZZ/BH-ZZZZ	(1) 3A
Delay 2	BA-ZZZZ/BH-ZZZZ	(1) 3A
Instant	BA-ZZZZ/BH-ZZZZ	(1) 3A
Interior	BA-ZZZZ/BH-ZZZZ	(1) 3A
Interior Stay/Away	BA-ZZZZ/BH-ZZZZ	(1) 3A
Delay Stay/Away	BA-ZZZZ/BH-ZZZZ	(1) 3A
Instant Stay/Away	BA-ZZZZ/BH-ZZZZ	(1) 3A
Interior Delay	BA-ZZZZ/BH-ZZZZ	(1) 3A
Day Zone	BA-ZZZZ/BH-ZZZZ	(1) 3A
Night Zone	BA-ZZZZ/BH-ZZZZ	(1) 3A
24-Hr. Burglary	BA-ZZZZ/BH-ZZZZ	(1) 3A
Delayed 24-Hr. Fire (Wireless)	FA-ZZZZ/FH-ZZZZ	(1) 1A
Standard 24-Hr. Fire (Wireless)	FA-ZZZZ/FH-ZZZZ	(1) 1A
24-Hr. Sprinkler	SA-ZZZZ/SH-ZZZZ	(1) 13
24-Hr. Low Temperature	ZA-ZZZZ/ZH-ZZZZ	(1) 59
24-Hr High Temperature	KA-ZZZZ/KH-ZZZZ	(1) 58
24-Hr. Latching Tamper	BA-ZZZZ/BH-ZZZZ	(1) 3A
24-Hr. Non Alarm	BA-ZZZZ/BH-ZZZZ	(1) 3A
24-Hr. Non-latching Tamper	TA-ZZZZ/TR-ZZZZ	(3) 83
Momentary Keyswitch Arm	BA-ZZZZ/BH-ZZZZ	(1) 3A
Maintained Keyswitch Arm	BA-ZZZZ/BH-ZZZZ	(1) 3A
Momentary Keyswitch Disarm	BA-ZZZZ/BH-ZZZZ	(1) 3A
Maintained Keyswitch Disarm	BA-ZZZZ/BH-ZZZZ	(1) 3A
24-Hr. Supervisory	US-ZZZZ/UR-ZZZZ	(1) 5A
24-Hr. Supervisory Buzzer	UA-ZZZZ/UH-ZZZZ	(1) 5A
24-Hr. Auto Verified Fire (Wireless)	FA-ZZZZ/FH-ZZZZ	(1) 1A
Fire Supervisory	FS-ZZZZ/FV-ZZZZ	(2) AA
24-Hr. Gas	GA-ZZZZ/GH-ZZZZ	(1) 51
24-Hr. CO Alarm	GA-ZZZZ/GH-ZZZZ	(1) 62
24-Hr. Holdup	HA-ZZZZ/HH-ZZZZ	(1) 22
24-Hr. Panic	PA-ZZZZ/PH-ZZZZ	(1) 2A
24-Hr. Flood	WA-ZZZZ/WH-ZZZZ	(1) 54
24-Hr Heat	KA-ZZZZ/KH-ZZZZ	(1) 58
24-Hr. Medical	MA-ZZZZ/MH-ZZZZ	(1) AA
24-Hr. Emergency	QA-ZZZZ/QH-ZZZZ	(1) A1
Doorbell Zone/Restore	BH-ZZZZ/BH-ZZZZ	(1) 3A
ZZZ/ZZZZ = zones 001-128		

Appendix B: Word Library

Item #	Text	Item #	Text	Item #	Text	Item #	Text	Item #	Text	Item #	Text
001	Aborted	042	Control	083	Garage	124	Motion	165	Shop	206	E
002	AC	043	Date	084	Gas	125	No	166	Side	207	F
003	Access	044	Daughter's	085	Glass	126	North	167	Siren	208	G
004	Active	045	Degrees	086	Goodbye	127	Not	168	Sliding	209	H
005	Activity	046	Delay	087	Gym	128	Now	169	Smoke	210	I
006	Alarm	047	Den	088	Hallway	129	Number	170	Son's	211	J
007	All	048	Desk	089	Heat	130	Off	171	Sound	212	K
008	AM	049	Detector	090	Hello	131	Office	172	South	213	L
009	Area	050	Dining	091	Help	132	OK	173	Special	214	M
010	Arm	051	Disarmed	092	High	133	On	174	Stairs	215	N
011	Armed	052	Door	093	Home	134	Open	175	Stay	216	O
012	Arming	053	Down	094	House	135	Opening	176	Sun	217	P
013	Attic	054	Download	095	In	136	Panic	177	Supervisory	218	Q
014	Auxiliary	055	Downstairs	096	Install	137	Partition	178	System	219	R
015	Away	056	Drawer	097	Interior	138	Patio	179	Tamper	220	S
016	Baby	057	Driveway	098	Intrusion	139	Pet	180	Temperature	221	T
017	Back	058	Duct	099	Invalid	140	Phone	181	Test	222	U
018	Bar	059	Duress	100	Is	141	Please	182	Time	223	V
019	Basement	060	East	101	Key	142	PM	183	To	224	W
020	Bathroom	061	Energy Saver	102	Kids	143	Police	184	Touchpad	225	X
021	Battery	062	Enter	103	Kitchen	144	Pool	185	Trouble	226	Y
022	Bedroom	063	Entry	104	Latchkey	145	Porch	186	Unbypass	227	Z
023	Bonus	064	Error	105	Laundry	146	Power	187	Unit	228	(Space)
024	Bottom	065	Exercise	106	Left	147	Press	188	Up	229	' (Apostrophe)
025	Breezeway	066	Exit	107	Level	148	Program	189	West	230	- (Dash)
026	Building	067	Exterior	108	Library	149	Progress	190	Window	231	_ (Underscore)
027	Bus	068	Factory	109	Light	150	Quiet	191	Zone	232	*
028	Bypass	069	Failure	110	Lights	151	Rear	192	0	233	#
029	Bypassed	070	Family	111	Living	152	Receiver	193	1	234	:
030	Enclosure	071	Father's	112	Load	153	Report	194	2	235	/
031	Cancelled	072	Feature	113	Loading	154	RF	195	3	236	?

Appendix C: Template Programming Tables

The following tables show the programming options for template programming digits 1-5.

- Digit 1 – Zones 1-8 Definition Options**

A “0” in the digit 1 location indicates that the default settings for the first 8 zones are in place unless overridden.

Option	Zn1	Zn2	Zn3	Zn4	Zn5	Zn6	Zn7	Zn8	Zone Definitions (Options 1- 6)
1	001	003	003	003	004	004	004	004	001 Delay 1 003 Instant 004 Interior 005 Interior Stay/Away 006 Delayed Stay/Away 007 Delayed 24Hr. Fire (Wireless) 008 Standard 24Hr. Fire (Wireless)
2	001	003	003	005	005	005	005	008	
3	001	003	003	005	005	005	005	007	
4	001	001	003	003	003	003	003	003	
5	001	003	003	006	005	005	005	005	
6	001	003	003	006	005	005	005	008	
Refer to "[001] Zone Type" on page 27 for details.									

- Digit 2 – System EOL Configuration Options**

Option	Zn1	[13] bit 1	[13] bit 2
1	NC Loops	ON	OFF
2	SEOL	OFF	OFF
3	DEOL	OFF	ON

- Digit 3 – Reporting Code Communication Options**

Entry	Template	Programming
1	Disabled	[380] Comm Toggles 1 - Bit 1 Communications Enabled - Off
2	Receiver 1 and 2 SIA with Backup	[380] Comm Toggles 1 - Bit 1 Communications Enabled - On [350] Communicator Formats - [001] Receiver 1 - 04 SIA [350] Communicator Formats - [002] Receiver 2 - 04 SIA [350] Communicator Formats - [003] Receiver 3 - 04 SIA [350] Communicator Formats - [004] Receiver 4 - 04 SIA [381] Comm Toggles 2 - Bit 2 Bell Ringback - Off [384] Comm Backup - Bit 2 Receiver 2 Backup - On [384] Comm Backup - Bit 2 Receiver 2 Backup - Off [384] Comm Backup - Bit 2 Receiver 2 Backup - Off [300] Comm Path - [001] Receiver 1 - 01 PSTN [300] Comm Path - [002] Receiver 2 - 01 PSTN [300] Comm Path - [003] Receiver 3 - 01 PSTN [300] Comm Path - [004] Receiver 4 - 01 PSTN
3	Receiver 1 SIA, Receiver 2 CID with backup	[380] Comm Toggles 1 - Bit 1 Communications Enabled - On [350] Communicator Formats - [001] Receiver 1 - 03 CID [350] Communicator Formats - [002] Receiver 2 - 04 SIA [350] Communicator Formats - [003] Receiver 3 - 04 SIA [350] Communicator Formats - [004] Receiver 4 - 04 SIA [384] Comm Backup - Bit 2 Receiver 2 Backup - On [384] Comm Backup - Bit 2 Receiver 2 Backup - Off [384] Comm Backup - Bit 2 Receiver 2 Backup - Off [300] Comm Path - [001] Receiver 1 - 01 PSTN [300] Comm Path - [002] Receiver 2 - 01 PSTN [300] Comm Path - [003] Receiver 3 - 01 PSTN [300] Comm Path - [004] Receiver 4 - 01 PSTN

4	Receiver 1 SIA	[380] Comm Toggles 1 - Bit 1 Communications Enabled - On [350] Communicator Formats - [001] Receiver 1 - 04 SIA [350] Communicator Formats - [002] Receiver 2 - 04 SIA [350] Communicator Formats - [003] Receiver 3 - 04 SIA [350] Communicator Formats - [004] Receiver 4 - 04 SIA [381] Comm Toggles 2 - Bit 2 Bell Ringback - Off [384] Comm Backup - Bit 2 Receiver 2 Backup - Off [384] Comm Backup - Bit 2 Receiver 2 Backup - Off [384] Comm Backup - Bit 2 Receiver 2 Backup - Off [300] Comm Path - [001] Receiver 1 - 01 PSTN [300] Comm Path - [002] Receiver 2 - 01 PSTN [300] Comm Path - [003] Receiver 3 - 01 PSTN [300] Comm Path - [004] Receiver 4 - 01 PSTN
5	Receiver 1 CID	[380] Comm Toggles 1 - Bit 1 Communications Enabled - On [350] Communicator Formats - [001] Receiver 1 - 03 CID [350] Communicator Formats - [002] Receiver 2 - 03 CID [350] Communicator Formats - [003] Receiver 3 - 03 CID [350] Communicator Formats - [004] Receiver 4 - 03 CID [384] Comm Backup - Bit 2 Receiver 2 Backup - Off [384] Comm Backup - Bit 2 Receiver 2 Backup - Off [384] Comm Backup - Bit 2 Receiver 2 Backup - Off [300] Comm Path - [001] Receiver 1 - 01 PSTN [300] Comm Path - [002] Receiver 2 - 01 PSTN [300] Comm Path - [003] Receiver 3 - 01 PSTN [300] Comm Path - [004] Receiver 4 - 01 PSTN
6	Receiver 1 and 2 CIA with backup	[380] Comm Toggles 1 - Bit 1 Communications Enabled - On [350] Communicator Formats - [001] Receiver 1 - 03 CID [350] Communicator Formats - [002] Receiver 2 - 03 CID [350] Communicator Formats - [003] Receiver 3 - 03 CID [350] Communicator Formats - [004] Receiver 4 - 03 CID [384] Comm Backup - Bit 2 Receiver 2 Backup - On [384] Comm Backup - Bit 2 Receiver 2 Backup - Off [384] Comm Backup - Bit 2 Receiver 2 Backup - Off [300] Comm Path - [001] Receiver 1 - 01 PSTN [300] Comm Path - [002] Receiver 2 - 01 PSTN [300] Comm Path - [003] Receiver 3 - 01 PSTN [300] Comm Path - [004] Receiver 4 - 01 PSTN

• **Digit 4 – Reporting Code Configuration Options**

Option	Common Group	Selected Troubles	Openings/ Closings	DLS/Installer Lead In/Out
1	✓			✗
2	✓	✓		✗
3	✓		✓	✗
4	✓	✓	✓	✗
5	✓	✓		✗
6	✓		✓	✗
7	✓	✓	✓	✗
8	✓			

✓ indicates included, blank indicates default setting, ✗ indicates disabled

• **Common Group – Enables/Disables all Reporting Codes**

Common Group	Common Group Programming
Set all reporting codes to automatic	[308] Event Reporting - All Events On
Alarm/restore call directions enabled	[311][001] Partition 1 Alarm/Restore - Bit 1 Receiver 1 - On [311][001] Partition 1 Alarm/Restore - Bit 2 Receiver 2 - Off [311][001] Partition 1 Alarm/Restore - Bit 3 Receiver 3 - Off [311][001] Partition 1 Alarm/Restore - Bit 4 Receiver 4 - Off
Tamper/restore call directions disabled	[311][002] Partition 1 Tamper/Restore - Bit 1 Receiver 1 - Off [311][002] Partition 1 Tamper/Restore - Bit 2 Receiver 2 - Off [311][002] Partition 1 Tamper/Restore - Bit 3 Receiver 3 - Off [311][002] Partition 1 Tamper/Restore - Bit 4 Receiver 4 - Off
Opening/closing call directions disabled	[311][003] Partition 1 Open/Close - Bit 1 Receiver 1 - Off [311][003] Partition 1 Open/Close - Bit 2 Receiver 2 - Off [311][003] Partition 1 Open/Close - Bit 3 Receiver 3 - Off [311][003] Partition 1 Open/Close - Bit 4 Receiver 4 - Off
Maintenance call directions enabled	[309][001] Maintenance - Bit 1 Receiver 1 - On [309][001] Maintenance - Bit 2 Receiver 2 - Off [309][001] Maintenance - Bit 3 Receiver 3 - Off [309][001] Maintenance - Bit 4 Receiver 4 - Off
Test transmission call directions disabled	[309][002] Test Transmission - Bit 1 Receiver 1 - Off [309][002] Test Transmission - Bit 2 Receiver 2 - Off [309][002] Test Transmission - Bit 3 Receiver 3 - Off [309][002] Test Transmission - Bit 4 Receiver 4 - Off

• **Selected Troubles - Enables the following Troubles**

Selected Troubles Group	Selected Troubles Programming
Battery	[308][301] - Bit 3 Panel Low Battery - On [308][301] - Bit 4 Panel Low Battery Restore - On [308][301] - Bit 5 Panel Battery Absent - On [308][301] - Bit 6 Panel Battery Absent Restore - On [308][331] - Bit 3 Module Low Battery - On [308][331] - Bit 4 Module Low Battery Restore - On [308][331] - Bit 5 Module Battery Absent - On [308][331] - Bit 6 Module Battery Absent Restore - On
AC Failure	[308][301] - Bit 1 Panel AC Trouble - Off [308][301] - Bit 2 Panel AC Trouble Restore - Off [308][331] - Bit 1 Module AC Trouble - Off [308][331] - Bit 2 Module AC Trouble Restore - Off
Bell Circuit Trouble	[308][302] - Bit 1 Panel Bell Trouble - On [308][302] - Bit 2 Panel Bell Trouble Restore - On
Fire, Alarm	[308][311] - Bit 3 Fire Trouble - On [308][311] - Bit 4 Fire Trouble Restore - On [308][305] - Bit 3 2W Smoke Trouble - On [308][305] - Bit 4 2W Smoke Trouble Restore - On
Aux Power Supply Trouble	[308][302] - Bit 5 Panel AUX Trouble - On [308][302] - Bit 6 Panel AUX Trouble Restore - On [308][332] - Bit 5 Module AUX Trouble - On [308][332] - Bit 6 Module AUX Trouble Restore - On
TLM Trouble	[308][302] - Bit 3 Panel TLM Trouble - Off [308][302] - Bit 4 Panel TLM Trouble Restore - On
General System Tamper	[308][101] - Bit 3 Module Tamper Trouble - Off [308][101] - Bit 4 Module Tamper Restore - Off
General System Supervisory	[308][332] - Bit 3 Module Supervisory Trouble - On [308][332] - Bit 4 Module Supervisory Restore - On

- **Openings & Closings** - Sets Residential Dial Reporting Codes for all openings and closings

Openings/Closings Group	Openings/Closings Programming
Enable All User Open/Close Reports	[308][201] - Bit 1 User Closing - On [308][201] - Bit 2 User Opening - On [308][201] - Bit 3 Partition Closing - Off [308][201] - Bit 4 Partition Opening - Off [308][201] - Bit 5 Special Closing - On [308][201] - Bit 6 Special Opening - On [308][202] - Bit 1 Automatic Closing - On [308][202] - Bit 3 Automatic Cancel - On

- **Zone Alarm Restore Group** - Disables all zone alarm restore reporting codes

Zone Alarm Restore Group	DLS/Installer Lead In/Out Programming
Restore zone alarm reporting codes	[307][001] - Bit 2 Alarm Restore - Off [307][002] - Bit 2 Alarm Restore - Off [307][003] - Bit 2 Alarm Restore - Off [307][004] - Bit 2 Alarm Restore - Off [307][005] - Bit 2 Alarm Restore - Off [307][006] - Bit 2 Alarm Restore - Off [307][007] - Bit 2 Alarm Restore - Off [307][008] - Bit 2 Alarm Restore - Off [307][009] - [128] Bit 2 Alarm Restore - Off

- **Installer Lead-in/Lead-out and DLS Lead-in/Lead-out**

DLS/Installer Lead In/Out Group	DLS/Installer Lead In/Out Programming
DLS/Installer Disabled	[308][312] - Bit 1 Installer Lead In - Off [308][312] - Bit 2 Installer Lead Out - Off [308][312] - Bit 3 DLS Lead In - Off [308][312] - Bit 4 DLS Lead Out - Off [308][312] - Bit 5 SA Lead In - Off [308][312] - Bit 6 SA Lead Out - Off

- **Digit 5 DLS Connection Options**

Option	Programming Section	DLS Connection/Call Back Setting
1	[401] Option 1 OFF Option 3 OFF Option 4 OFF [406] 000	Double Call Disabled Call Back Disabled User Initiated Call Up Disabled Number of Rings to Answer On Disabled
2	[401] Option 1 ON Option 3 OFF Option 4 OFF [406] 008	Double Call Enabled Call Back Disabled User Initiated Call Up Disabled Number of Rings to Answer On is 8
3	[401] Option 1 ON Option 3 ON Option 4 OFF [406] 008	Double Call Enabled Call Back Enabled User Initiated Call Up Disabled Number of Rings to Answer On is 8
4	[401] Option 1 ON Option 3 OFF Option 4 ON [406] 008	Double Call Enabled Call Back Disabled User Initiated Call Up Enabled Number of Rings to Answer On is 8

After entering a valid 5-digit template programming code, the system prompts for the following data in the sequence listed:

- 1. Central Station Telephone Number**
Program the required central station phone number. Press [#] to complete your entry.
This phone number is entered into programming section [301][001].
- 2. Central Station Account Code (6-digit code)**
Program the system account code. All 6 digits must be entered in order to complete your entry.
This account code is entered into programming section [310][000].
- 3. DLS Access Code (6-digit code)**

Program the required DLS access code. All 6 digits must be entered in order to complete your entry.

This access code is entered into programming section [453].

4. Entry Delay 1 and Exit Delay

Enter the 3-digit entry delay 1 (in seconds) followed by the desired 3-digit exit delay (in seconds). These entries affect all partitions.

All 3 digits must be entered in order to complete each section entry.

These values are entered in programming sections [005][001]-[008] entry 1 and 3 respectively.

5. Installer's Code

Enter the 4 or 6-digit installer access code (dependent on section [041]). All digits must be entered in order to complete the section entry.

This code is entered into programming section [006][001].

After the installer code has been programmed the system returns to the base installer programming menu.

All template programming information defaults after performing a hardware or software panel default. The 5-digit template programming code is defaulted to 01111.

NOTE: Pressing the pound key (#) advances through template programming, accepting what is displayed in these locations, potentially overwriting desired programming. Depending on the option programmed, restoring the defaults using template programming may not be possible.

Appendix D: Regulatory Approvals

FCC COMPLIANCE STATEMENT

CAUTION: Changes or modifications not expressly approved by Digital Security Controls could void your authority to use this equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-orient the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help. The user may find the following booklet prepared by the FCC useful: "How to Identify and Resolve Radio/Television Interference Problems". This booklet is available from the U.S. Government Printing Office, Washington D.C. 20402, Stock # 004-000-00345-4.

IMPORTANT INFORMATION

This equipment complies with Part 68 of the FCC Rules. On the side of this equipment is a label that contains, among other information, the FCC registration number and ringer equivalence number (REN) for this equipment. If requested, this number must be provided to the Telephone Company. HS2128 Product Identifier US: F53AL01BHS2128
REN:0.1B
USOC Jack:RJ-31X

Telephone Connection Requirements

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

Ringer Equivalence Number (REN)

The REN is used to determine the number of devices that may be connected to a telephone line. Excessive RENs on a telephone line may result in the devices not ringing in response to an incoming call.

In most but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the local Telephone Company. For products approved after July 23, 2001, the REN for this product is part of the product identifier that has the format.

US: AAAEQ##TXXXX. The digits represented by ## are the REN without a decimal point (e.g., 03 is a REN of 0.3). For earlier products, the REN is separately shown on the label.

Incidence of Harm

If this equipment HS2016/HS2032/HS2064/HAS2128 causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice is not practical, the Telephone Company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.

Changes in Telephone Company Equipment or Facilities

The Telephone Company may make changes in its facilities, equipment, operations or procedures that could affect the operation of the equipment. If this happens the Telephone Company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.


Equipment Maintenance Facility

If trouble is experienced with this equipment HS2016/HS2032/HS2064/HAS21284 for repair or warranty information, please contact the facility indicated below. If the equipment is causing harm to the telephone network, the Telephone Company may request that you disconnect the equipment until the problem is solved. This equipment is of a type that is not intended to be repaired by the end user.
DSC c/o APL Logistics, 757 Douglas Hill Rd., Lithia Springs, GA 30122

Additional Information

Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission or corporation commission for information.

Alarm dialling equipment must be able to seize the telephone line and place a call in an emergency situation. It must be able to do this even if other equipment (telephone, answering system, computer modem, etc.) already has the telephone line in use. To do so, alarm dialling equipment must be connected to a properly installed RJ-31X jack that is electrically in series with and ahead of all other equipment attached to the same telephone line. Proper installation is depicted in the figure below. If you have any questions concerning these instructions, you should consult your telephone company or a qualified installer about installing the RJ-31X jack and alarm dialling equipment for you.



INDUSTRY CANADA STATEMENT

NOTICE: This Equipment, HS2016/HS2032/HS2064/HAS2128, meets the applicable Industry Canada Terminal Equipment Technical Specifications. This is confirmed by the registration number. The abbreviation, IC, before the registration number signifies that registration was performed based on a Declaration of Conformity indicating that Industry Canada technical specifications were met. It does not imply that Industry Canada approved the equipment

NOTICE: The Ringer Equivalence Number (REN) for this terminal equipment is 0.1. The REN assigned to each terminal equipment provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Numbers of all devices does not exceed five.

L'indice d'équivalence de la sonnerie

(IES) sert à indiquer le nombre maximal de terminaux qui peuvent être raccordés à une interface téléphonique. La terminaison d'une interface peut consister en une combinaison quelconque de dispositifs, à la seule condition que la somme d'indices d'équivalence de la sonnerie de tous les dispositifs n'excède pas 5.

Certification Number:

IC: 160A-HS2128

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

4.0.1 UL/ULC Installations

This product has been tested and found in compliance with the following standards:

UL1610 Central-Station Burglar-Alarm Units
UL365 Police Station Connected Burglar Alarm Units and Systems
UL1023 Household Burglar-Alarm System Units
UL985 Household Fire Warning System Units
UL1635 Digital Alarm Communicator System Units
UL1637 Home Health Care Signaling Equipment
ULC-S304-06 Signal Receiving Centre & Premise Burglar Alarm Control Units
ULC-S559-04 Equipment for Fire Signal Receiving Centers and Systems
ULC-S545-02 Residential Fire Warning System Control Units
ORD-C1023-1974 Household Burglar-Alarm System Units

This product has also been tested and found in compliance with the ANSI/SIA CP-01-2010 Control Panel Standard – Features for False Alarm Reduction.

This product is UL/ULC listed under the following categories:

AMCX/AMCXC Central Stations Alarm Units
APAW Police-station-connected Alarm Units
DAYRCC Central Station Fire Alarm System Units
UTOU/UTOC Control Units and Accessories, Household System Type
NBSX/NBSXC Household Burglar Alarm System Units
AMTB Control Panels, SIA False Alarm Reduction

The product is labeled with the UL and ULC listing marks along with the SIA CP-01 compliance statement (Also Classified in accordance with SIA-CP-01 Standard) as proof of compliance with the above mentioned standards. For further information on this product's listings please also refer to the official listing guides published at the UL web site (www.ul.com) under Online Directions Section.

UL/ULC Residential Fire and Burglary Installations:

For ULC Installations refer to the Standard for the Installation of Residential Fire Warning Systems, CAN/ULC-S540.

- All burglary-type zones shall be configured with SEOL or DEOL configuration (refer to section [002], bit 10 or 11 shall be ON)
- Use at least one PG9926 or PG9916 Smoke Detector for Fire Installations (section [001], fire zone shall be programmed as type 025)
- The entry delay shall not exceed 45 seconds (refer to section [005])
- The exit delay shall not exceed 60 seconds (refer to section [005])
- The minimum Bell Time-out is 4 minutes (refer to section [005])

Note: For ULC Residential Fire Installations the minimum Bell Time-out is 5 minutes

For UL Home Health Care Installations the minimum Bell Time-out is 5 min.
For UL Commercial Burglary Installations minimum Bell Time-out is 15 min.

- Temporal Three Fire Signal shall be enabled (section [013], opt.8 ON)
- Arm/Disarm Bell Squawk shall be enabled when using wireless key PG4939, PG4929, PG4949 (section [014], option 1 shall be ON)
- A code shall be required for bypassing (section [023], option 4 shall be ON)
- Trouble beeps shall be enabled (section [022], option 7 shall be ON)
- AC trouble indication LED shall be enabled (Keypad Programming, section [022], options 5 and 6 shall be ON)
- DACT Communicator shall be enabled for Supervising Station Monitoring (section [380], option 1 shall be ON)

Note: The DACT communicator for this product has no line security.

- Telephone Line Monitoring (TLM) shall be enabled (section [015], option 7 shall be ON)

Note: This product is programmed to perform 5 (min.) to 10 (max.) attempts for communication of an event to the supervising station. If unsuccessful, a Fail To Communicate (FTC) trouble is generated.

- Test transmission cycle shall be set for monthly transmission (refer to section [351])

Note: For ULC Residential/Commercial installations set for daily test transmission

- Wireless Supervision window shall be set to 4 hours for Fire Installations (Wireless Programming, section [804]>[802] shall be programmed with the value 16)
- Wireless Supervision window shall be set to 4 hours for Burglary Installations only (Wireless Programming, section [804]>[802] shall be programmed with the value 96)
- RF Jam detection shall be enabled (refer to Wireless Programming (section [804][801], option 00 shall be OFF)
- New Alarms will Disconnect 2-way Audio (section [022], opt 6 OFF)

UL Central Station and Police Connect with Standard or Encrypted Line Security Service

- The installation must use the Models TL2803G(R) IP/3G Interface, 3G2080(R) 3G Interface or TL280(R) IP Interface, which communicates over Cellular Data Network or an Ethernet network 10/100BaseT to the compatible Sur-Gard System I/II/III/IV receiver.
- Polling time shall be 200 seconds and compromise detection time shall be 6 min.
- For Encrypted line security applications, the Models TL2803G(R) IP/3G Interface, 3G2080(R) 3G Interface or TL280(R) IP Interface shall have the Encryption Key enabled (AES128 bit encryption algorithm is validated under NIST Certificate No.xxx)
- Wireless Supervision window shall be enabled (refer to Wireless Programming, sections [804]>[802])

UL Local, Central Station and Police Connect with No Line Security Service

- The installation shall use a Bell which is UL Listed for Mercantile local alarms. An example of a UL Listed bell that can be used is Amseco Model MBL10B bell with Model AB-12 bell housing. Connections from the control unit to the bell shall be made in conduit. (Optional for central Station)

- The bell timeout shall be programmed for 15 minutes minimum
- At least one system remote keypad with tamper switch shall be employed
- The integral DACT shall be enabled and shall be programmed to provide a low battery transmission
- The control panel shall be in the attack resistant enclosure. The separately listed CMC-1 or PC4050CA attack resistant enclosure shall be employed
- The maximum entry delay time shall not exceed 45s as a result of the attack test. The maximum exit delay time shall not exceed 60 s.
- A tamper switch shall be used to protect the enclosure cover of the control unit. A tamper switch shall also be used on the keypad rear to detect removal from the wall.
- 24 h check in transmission shall be enabled
- Open/Closing acknowledgement enabled.(Not Police Station)
- The Installation shall use the internal dialer (DACT) alone or in conjunction with Models TL2803G(R) IP/3G Interface, 3G2080(R) 3G Interface or TL280(R) IP Interface, which communicates over Cellular Data Network or an Ethernet network 10/100BaseT to the compatible Sur-Gard System I/II/III/IV receiver.

UL Home Health Care Signaling Equipment

- There must be at least two keypads, one of either one of the compatible keypads models HS2LED, HS2LCD(P), HS2ICN(P), HS2LCDRF(P)9, HS2IC-NRF(P)9
- Each system shall be programmed to activate an audible Trouble signal within 90 seconds upon loss of microprocessor memory

ULC Central Station Fire and Burglary Monitoring Installations

- For installation requirements, levels of security, communication modules and configurations (Refer to the ULC Installation Information Sheet, DSC #29002157)
- Use a CSA/cUL approved transformer (hardwired connections required for Fire Monitoring)
- All tamper circuits may be connected to the same zone

Programming

The notes in the programming sections of the PowerSeries Neo Reference Manual describing the system configurations for UL/ULC listed installations shall be implemented.

Control of the Protected Premises

In order to have a UL certificated system, the protected area is to be under the responsibility of one ownership and management (i.e., one business under one name). This may be a group of buildings attached or unattached with different addresses but under the responsibility of someone having mutual interest. The person of mutual interest is not the alarm-installing company.

Note: This does not apply to strip mall applications where each independent business must have their own separate alarm system.

e.g.,1: a commercial partitioned system that has an office and a warehouse area in a building where each area can be armed or disarmed independently.

e.g.,2: a residential system partitioned so that the garage area is armed separately from the house.

Each of the above examples is under the sole responsibility of a single owner. The bell and DACT power supply must be in a protected area including partitioned systems. The bell and DACT power supply must be located where it can be heard by the person or persons responsible for maintaining the security system during the daily arming cycle.

Bell Location

The alarm sounding device (bell) shall be located where it can be heard by the person operating the security system during the daily arming and disarming cycle.

Protection of the Control Unit

The local control unit and the local power supply must be protected in one of the following ways:

- The control unit and audible alarm device must be in a protected area which is armed 24 hours a day.
- Each partition must arm the area protecting the control unit and the audible alarm device power supply. This may require duplicate protection armed by each partition. Access to this protected area, without causing an alarm, will require that all partitions be disarmed.
- In all cases described above, the protected area for the control unit must be programmed as not-bypassable.

Casual Users

The installer should caution the user(s) not to give system information (e.g., codes, bypass methods, etc.) to casual users (baby-sitters or service people). Only the One-Time Use codes shall be given to casual users.

User Information

The installer should advise the users and note in the User's Manual:

- Service organization name and telephone number
- The programmed exit time
- The programmed entry time
- Test system weekly
- The installer code cannot arm or disarm the system

Aux Loading and Battery Selection

HS2128/HS2064/HS2032/HS2016 Board current draw mA	UL Resi Burg ULC Resi Burg	UL Com Burg	UL Resi Fire UL Home Health Care ULC Resi Fire ULC Com Burg	ULC Fire Monitoring	EN50131 Grade 2/Class II
Max AUX (NSC) current loading	0.7A	0.7A	0.5A	0.5A	
Max BELL (Alarm) current loading	0.7A	0.7A	0.7A	0.7A (no local alarm notification allowed, only remote transmission to SRC)	0.7A
UL/ULC Listed enclosure	PC500C PC5003C	CMC-1 PC4050CAR	PC5003C	PC5003C PC4050CR (red/transformer mounted inside)	PC5003C Power UC1
Transformer requirements	16.5V/40VA (plug in type) PTC1640U (USA) PTC1640CG (CND)			FTC1637 (cUL listed) 16.5V/37VA (Hardwired type, mounted inside the enclosure or outside using electrical box)	16.5V/40VA (hardwired type, mounted inside the cabinet)
Battery Capacity requirements	7Ah	7Ah	14Ah (2 x 7Ah in parallel)	14Ah (2 x 7Ah in parallel)	7Ah
Standby Time	4 hours	4 hours	24 hours	24 hours	12 hours
Alarm time	4 minutes	15 minutes	4 min (UL resi fire) 5 min (Home Health Care and ULC Resi Fire)	5 minutes (Alarm Transmission only)	N/A
Recharging current setting	mA, 700mA	mA, 700mA	mA, 700mA	mA, 700mA	mA, 700mA

4.0.2 SIA False Alarm Reduction Installations: Quick Reference

Minimum required system consists of one Control unit model HS2128 or HS2064 or HS2032 or HS2016 and any one of the compatible listed keypads: HS2LCDRF9, HS2LC-DRFP9, HS2ICNRF9, HS2ICNRP9, HS2LCD, HS2LCDP, HS2ICN, HS2ICNP, HS2LED.

The following wireless keys can also be used in SIA compatible installations: PG9929, PG9939, PG9949.

NOTE: For models PG9929 and PG9939, the panic/emergency key shall be disabled for SIA compliant installations.

For a list of the default values programmed when the unit is shipped from the factory, and for any other programming information, refer to the table below.

The following optional subassembly modules also bear the SIA CP-01-2010 classification and may be used if desired: HSM2108 zone expander, HSM2208 PGM output module, HSM2300 auxiliary power supply, HSM2204 output module, HSM2HOST9 2-way wireless transceiver, PG9901 indoor siren, PG9911 outdoor siren, and 3G2080(R)/ TL2803G(R)/ TL280(R) cellular and PSDN communication module.

Caution

- For SIA FAR installations use only modules/devices that are listed on this page.
- Fire Alarm Verification feature (Auto Verified Fire Zone type [025]) is not supported on 2-wire smoke detectors zones, model FSA-210B(T)(S)(ST)(LST)(R)(RT)(RD)(RST)(LRST). This feature may be enabled for 4-wire smoke detectors only (FSA-410B(T)(S)(ST)(LST)(R)(RT)(RST)(LRST) and wireless detectors PG9916/PG9926). The fire alarm delay is 60s.
- Call Waiting Cancel (Section [382], Option 4) feature on a non-Call Waiting line will prevent successful communication to the supervising station.
- All smoke detectors on the system must be tested annually by conducting the Installer Walk Test. Prior to exiting walk test mode, a sensor reset must be done on the system, [*][7][2], to reset all latching 4-wire smoke detectors. Refer to the installation instructions supplied with the detector for details.

Notes

- Programming at installation may be subordinate to other UL requirements for the intended application.
- Cross zones have the ability to individually protect the intended area (e.g. motion detectors which overlap).
- Cross zoning is not recommended for line security Installations nor is it to be implemented on exit/entry zones.
- This control panel has a communication delay of 30 seconds. It can be removed or increased up to 45 seconds by the end user in consultation with the installer.
- The security system shall be installed with the sounding device activated and the communicator enabled for transmission using SIA or CID format.
- ULC commercial burglary installations require DEOL resistors.

SIA Feature Programming Section	Comments	Range/Default	Requirement
Exit Time [005]>[001], option 3	Access to Entry and Exit delays and Bell Time Out for the system.	Range: 45- 255 seconds Default: 60 sec.	Required (programmable)
Progress Annunciation/Disable - for Silent Exit [014], option 6 ON	Enables audible exit beeps from the keypad for the duration of exit delay.	Individual keypads may be disabled Default: Enabled	Allowed
Exit Delay Restart [018], option 7	Opening a Delay zone door after it has already been opened and closed during an exit delay restarts the exit delay timer.	Default: Enabled	Required
Auto Stay Arm on Un-vacated Premises [001]>[001]-[128] Zone type 05, 06,09	Function key: Forces the system to arm in Stay mode if the occupant does not exit the premises after pressing the Away function key.	If no exit after full arm Default: Enabled	Required
Exit Time and Progress Annunciation/Disable or Remote Arming [861]>[001]-[005], option 4	System times and audible exit beeps can be disabled when using the wireless key to stay arm the system. When away arming, audible exit beeps can not be disabled.	Default: Enabled	Allowed
Entry delay(s) [005]>[001]-[008], options 1 and 2	Access to entry and exit delays and bell time out for the system Note: Combined entry delay and communications delay (abort window) shall not exceed 60s.	Range: 30 sec. to 4 min. Default: 30 sec.	Required (programmable)
Abort Window for Non-Fire zones [002]>[001]-[128], option 7 ON	Access to zone attributes, i.e., swinger shutdown, transmission delay and cross zone. May be disabled by zone or zone type.	Default: Enabled	Required
Abort Window Time - for Non-Fire zones [377]>[002], option 1	Access to the programmable delay before communicating alarms Note: Combined entry delay and communications delay (abort window) shall not exceed 60 seconds.	Range: 00 - 45 sec. Default: 30 sees	Required (programmable)
Abort Annunciation	An audible tone is generated when an alarm is aborted during the abort window.	Hard-coded ON	Required
Duress Feature [*][5]> master code> user 2-95> 5> 2	When this feature is enabled, selected user codes send a duress reporting code to the central station when used to perform any function on the system. Section [019], option [6] must be enabled.	Default: N	Required
Cancel Window [377]>[002], option 6	Access to the communications cancel window. Minimum duration must be 5 minutes.	Range: 005-255 Default: 005	
Cancel Annunciation [308]>[001], option 8	Access to the reporting code for Alarm Canceled.	A Cancel was transmitted Default: Enabled	Required
Cross Zoning [042]>Selection 3, option 002	Enables cross zoning for entire system. Zones can be enabled for cross zoning via zone attribute option 8 in sections [002][101] - [128].	Programming required Default: Disabled	Required
Burglary Verification Timer [005]>[000], option 3	Access to the programmable Cross Zone timer.	Range: 000-255 sec. Default: 60 seconds	Allowed
Swinger Shutdown for Alarms [377]>[001], option 1	Access to the swinger shutdown limit for zone alarms For all non-fire zones, shut down at 1 to 6 trips.	Default: 2 trips	Required (programmable)
Swinger Shutdown Enable [002]>[001] - [128], option 6 ON	Access to swinger shutdown, transmission delay and cross zone attributes. Zone attribute option 6 (Swinger Shutdown enabled) is ON.	Non-police response zones Default: Enabled	Allowed
24-Hr. Auto-verified Fire [001]>[001]-[128], Zone type 025 ON	Access to 24-Hr. Auto-verified Fire Activates if Not restored within the specified time.	Must choose zone type for application	Required
Call Waiting Cancel [382], option 4 OFF	Access to the dialing sequence used to disable call waiting. Call waiting string can be programmed in [034]	Depends on user phone line Default: Disabled	Required
System Test: [*][6] Master Code, option 4	The system activates all keypad sounders, bells or sirens for 2 seconds and all keypad lights turn on. Refer to user manual (<i>part no. 29008365</i>).		
Walk Test Mode: [*][8][Installer code][901]	This mode is used to test each zone on the system for proper functionality.		
Walk Test Communications [382], option 2	Enables communication of zone alarms while walk test is active.	Default: Disabled	
Walk Test Start/ End Reporting Codes [308][401], options 1 and 2	Access to the reporting codes for walk test start and end times.		

Appendix F: Wiring Diagrams

HS2016, HS2032, HS2064, HS2128 UL/ULC Wiring Diagram

HS2016/2032/2064/2128 UL/ULC Wiring Diagram

APPLICABLE UL STANDARDS

UL FILE NO. S4019

- UL1610 Central-Station Burglar Alarm Units
- UL609 Local Burglar Alarm Units and Systems
- UL365 Police Station Connected Burglar Alarm Units & Systems
- UL985 Household Fire Warning System Units
- UL1023 Household Burglar Alarm System Units
- UL1635 Digital Alarm Communicator System Units
- UL1637 Home Health Care Signaling Equipment
- ANSI/SIA CP-01-2010


SIA-FAR Minimum System Requirements:
 1 HS2016/2032/2064/2128 Panel
 2 Local annunciation devices

Local annunciation devices may be any combination of these keypads:
 HS2LCD, HS2LCDP, HS2ICN, HS2ICNP, HS2LED








WARNING
 Incorrect connections may result in PTC failure or improper operation. Inspect wiring and ensure connections are correct before applying power.
 Do not route any wiring over circuit boards. Maintain at least 25.4mm (1") separation.

WARNING
 High voltage.
 Disconnect AC power and telephone lines prior to servicing.

*AUX Wiring
 Use No.14-22 AWG conductor
 AUX+ and Keybus (RED) are internally connected. Total current draw from keypads, PGM Outputs and AUX circuits must not exceed 700mA.



All circuits are classified for UL installations as power limited/Class II power limited, except for the battery leads which are not power limited. Do not route any wiring over circuit boards. Maintain at least 1" (25.4mm) separation. Please see Section 2. A minimum 1/4" (6.4mm) separation must be maintained at all points between power limited wiring and all other non-power limited wiring.



WARNING:

This equipment should be installed in accordance with the National Fire Code ANSI/NFPA 72 (National Fire Protection Association, Batterymarch Park, Quincy MA, 02269). Printed information describing proper installation, operation, testing, maintenance, evacuation planning, and repair service is to be provided with this equipment. For compliance with UL-985, at least one smoke detector is required.

Temperature Range: 0°C-49°C [32°F-120°F] / Maximum Humidity: 93% R.H.
 The HS2016/2032/2064/2128 is UL Listed for limited energy installations per NEC Article 760. Recognized limited energy cable should be used. Observe NEC wiring requirements and local codes defined by the authority having jurisdiction. Security detection devices that require power from the control panel must be UL Listed for the intended application and operate over the range of 11.6-12.6VDC (residential), 12.0VDC (commercial). PG9904(P), PG9934(P), and PG9974(P) are recommended UL Listed motion detectors. Compatible system keypads: HS2LCDRF(4)(8)(9), HS2LCDRFP(4)(8)(9), HS2ICNRF(4)(8)(9), HS2ICNRP(4)(8)(9), HS2LCD, HS2LCDP, HS2ICN, HS2ICNP, HS2LED

- ULC NOTES**
- For ULC Listed Fire Monitoring Installations & module requirements, please refer to the ULC Installation Information Sheet, part #29002157.
 - Use a CSA/UL transformer, hardwired.
 - All tamper circuits may be connected to the same zone.
 - Use ULC-LA for AC Power indication.


Circuit (zone)	Control Unit Delay - Sec.	Smoke Detector	
		Model	Delay - Sec. (a)

(a) The delay (power-up) time marked on the installation wiring diagram of the smoke detector or on the installed smoke detector(s) is to be used.

Control panel is suitable for the following UL installations: (1) Grade AA Central Station and Grade AA Police Connect with high line security (using T-LINK to communicate to the Sur-Gard MLR-IP Receiver). (2) Household Fire and Grade A Household Burglary and Home Health Care Signaling Equipment (3) Grade A Local 1 Grade B Central Station and Police Connect with basic line security (4) Grade C Central Station. Refer to Installation Manual

NOTE: For ULC installations, please refer to the ULC Installation Information Sheet part#29002157.

HS2016/032/064/128 Standard Wiring Diagram For NA



Zone Wiring

Zones can be wired for Normally Open, Normally Closed Contacts with Single-end-of-line (SEOL) resistors or Double End-of-Line (DEOL) resistors. Observe the following guidelines For UL Listed Installations use SEOL or DEOL only.

Minimum 22 AWG wire, maximum 18 AWG

Do **NOT** use shielded wire

Wire run resistance shall not exceed 100Ω, refer to the chart below:

Burglary Zone Wiring Chart

Wire Gauge	Maximum wire length to End of Line Resistor (feet/meters)
22	3000 / 914
20	4900 / 1493
19	6200 / 1889
18	7800 / 2377

Figures are based on maximum wiring resistance of 100 ohms.

Section [001-004] Selects Zone Definition

Section [013] Opt [1] Selects Normally Closed or EOL resistors

Section [013] Opt [2] Selects Single EOL or Double EOL resistors.

Zone Status


Loop Resistance

- 0Ω (shorted wire/loop)
- 5600Ω (contact closed)
- infinite (broken wire, open)
- 11,200Ω (contact open)


Loop Status

- Fault
- Secure
- Tamper
- Violated


Normally Closed Loops - Do NOT use for UL Installations



Single End-of-Line Resistor Wiring



Double End-of-Line Resistor Wiring




Bell Wiring

These terminals supply 700mA of current at 12VDC for commercial installations and 11.1-12.6 VDC for residential installations (e.g.DSC SD-15 WULF). To comply with NFPA 72 Temporal Three Pattern requirements:

Program **Section [013] Opt [8] ON**.

The Bell output is supervised and power limited. If unused, connect a 1000Ω resistor across Bell+ and Bell- to prevent the panel from displaying a trouble. See **[*][2]**.



NOTE: Bell output is current limited by 2A PTC

NOTE: Steady, Pulsed and Temporal Three Pattern alarms are supported.

PGM Wiring

PGMs switch to ground when activated by control panel.
 Connect the positive side of the device to be activated to the AUX+ Terminal. Connect the negative terminal to the PGM.
 current output is as follows

- PGM 1, 3, 4..... 50mA
- PGM 2..... 300mA

For currents levels greater than 300mA a UL listed RM-1 or RM-2 relay module is required.

PGM2 can also be used for 2-wire smoke detectors.

NOTE: Use SEOL resistors on FIRE ZONES ONLY.

2-wire Smoke Detectors Initiating Circuit

- Style B (Class B), Supervised, Power Limited
- Compatibility IdentifierPC18-1
- DC Output Voltage 9.8-13.8VDC
- Detector Load 2 mA (MAX)
- Single-end-of-line (SEOL) Resistor 2200Ω
- Loop Resistance 24Ω (MAX)
- Standby Impedance 1020Ω (NOM)
- Alarm Impedance..... 570Ω (MAX)
- Alarm Current 89 mA (MAX)
- Maximum number of 2-wire Smoke Detectors..... 18


2-wire Smoke Detectors

Compatibility ID For FSA-210 Series is: FS200

Compatible DSC 2-wire smoke detectors:


FSA-210A Series for ULC
 FSA-210B Series for UL
 FSA-210C Series for EU

FSA-210B
 FSA-210BT
 FSA-210BS
 FSA-210BST
 FSA-210BLST
 FSA-210BR
 FSA-210BRT
 FSA-210BRS
 FSA-210BRST
 FSA-210BLRST



NOTE: Do NOT combine models from different Manufacturers On the same circuit. Operation may be impaired.

PGM 1, LED Output with current limiting resistor and Optional Relay driver output




IMPORTANT: Minimum 6.4mm (1/4") separation must be maintained between RM-1 circuits and all other wiring

4-wire Smoke Detectors

Compatible DSC 4-wire smoke detectors:

FSA-410A Series for ULC
 FSA-410B Series for UL
 FSA-410C Series for EU



Smoke Detector must be latching type (e.g., DSC FSA 410B Series)
 To reset smoke detector, Enter [*] [7] [2]


Telephone Line Wiring

Wire the telephone connection terminals (TIP, Ring, T-1, R-1) to an RJ-31x Connector as indicated.

For connection of multiple devices to the phone line, wire in the sequence shown.

Telephone format is programmed in section [350].

Telephone Call Directions are programmed in section [351]-[376].



Appendix G: Specifications

Zone Configuration

- 16, 32, 64, or 128 wireless zones supported and 8 hardwired zones available on the controller
- 40 zone types and 14 programmable zone attributes
- Zone configurations available: normally closed, single EOL and DEOL supervised
- Hardwired zone expansion (fully supervised) available using the model HSM2108 (eight zone expander module)
- Wireless zone expansion (fully supervised) available using the HSM2Host 2-way wireless integration module (operating at 915MHz (North America), 433MHz (Europe) and 868MHz (international))

Access Codes

- Up to 97 access codes: 94 (level 2-EN), one system master code (level 3-EN), one installer code (level 3-EN), and one maintenance code
- Programmable attributes for each user code (see page 20)
- When using 6-digit access codes, the minimum number of variations of access codes are 10526 for HS2128/HS2064, 13888 for HS2032 and 20833 for HS2016

Warning Device Output

- Integral sounder capable of 85 dB @ 3m, self-powered type Z
- 2 remote, wireless indoor/outdoor warning devices supported: models PGX901 (indoor), PGX911 (outdoor) (X=4, 8, or 9)
- Programmable as steady, pulsed or temporal three (as per ISO8201) and temporal four (CO alarm) output
- Warning device sounds alarms in the following priority: fire, CO, medical, burg

Memory

- CMOS EEPROM memory
- Retains programming and system status on AC or battery failure for 20 years min. (not verified by UL)

Power Supply

Transformer: DSC PTD1640U

Primary: 120V, 60Hz Class II

Secondary: 16.5VAC, 40VA Max.

Regulated power supply:

- 700mA auxiliary supply, 12V DC
- Positive temperature coefficient (PTC) for Bell, Aux+ and Battery terminals
- Reverse battery detection/protection
- Supervision for AC power and low battery
- Normal and high current battery charge options
- Supervised battery charging circuit

Current draw (panel): 85mA (nominal) 2A(Max)

Bell Output:

- 12V, 700mA supervised (1k Ohm) bell output (current limited at 2 amps)
- Steady, Pulsed, Temporal 3 fire, CO alarm cadences
- Bell short detection (software + hardware)

Aux+:

- Voltage range = 9.6V - 13.8V DC
- Current = 700mA (shared with PGM outputs)

Output ripple voltage: 270mVp-p max.

Onboard programmable outputs:

- PGM 1 - 50mA switched programmable output
- PGM 2 - 300mA current-limited switched programmable output. 2-Wire smoke detectors (90mA current limited) are supported using this PGM
- PGM 3 - 50mA switched programmable output
- PGM 4 - 50mA switched programmable output
- Hardware PGM over current protection

Battery

- 12V sealed lead acid, rechargeable
- Battery capacity:

- 4Ah (PS4-12)
- 7Ah (BD7-12)
- 14Ah
- Maximum standby time: 24 hours (with 14Ah battery and Aux current limited to 470mA)
- Recharging time to 80% 72 hours
- Recharging rate: 240mA (12 hours max.), 480mA (24 hour backup)
- Backup time: 24 hours (UL)
- Battery lifespan: 3-5 years
- Low battery trouble indication threshold 11.5VDC
- Battery restore voltage 12.5V
- Main board current draw (battery only):
 - HS2016/32/64/128 (no alternate communicator) standby 80mA DC
 - HS2016/32/64/128, (including alternate communicator) standby 190mA DC
 - Transmit (alternate communicator module) 195mA DC
- Resettable fuses (PTC) used on circuit board
- Supervision for loss of primary power source (AC fail), battery loss or battery low voltage (battery trouble) with indication provided on the keypad
- Internal clock locked to AC power frequency

Operating Environmental Conditions

- Temperature range: UL = 0°C to +49°C (32°F-120°F),
- Relative humidity: <93% non condensing

Alarm Transmitter Equipment (ATE) Specification

- Digital dialer integral to the main control board
- Supports SIA and Contact ID
- Complies with TS203 021-1, -2, -3 Telecom equipment requirements and EN50136-1-1, EN50136-2-1, EN50136-2-3 ATS 2
- Optional Dual IP/Cellular communicators (3G2080(R)/ TL2803G(R)/ TL280(R)) can be installed in the same enclosure and configured as primary or back-up, with AES 128-bit encryption
- Compliant with EN50136-1-1, EN50136-2-1 ATS2 requirements

System Supervision Features

The PowerSeries Neo continuously monitors a number of possible trouble conditions and provides audible and visual indication at the keypad.

Trouble conditions include:

- AC power failure
- Zone trouble
- Fire trouble
- Telephone line trouble
- Communicator trouble
- Low battery condition
- RF jam
- AUX power supply fault
- Failure to communicate
- Module fault (supervisory or tamper)

Additional Features

- 2-way wireless device support
- Visual verification (images + audio)*
- Proximity tag support
- PGM scheduling
- Quick arming
- User, partition, module, zone and system labels
- Programmable system loop response
- Keypad and panel software versions viewable through keypad
- Doorbell zone type
- Low battery PGM type

*Feature not evaluated by UL/ULC.

Guidelines for Locating Smoke & CO Detectors

The following information is for general guidance only and it is recommended that local fire codes and regulations be consulted when locating and installing smoke and CO alarms.

Smoke Detectors

Research indicates that all hostile fires in homes generate smoke to a greater or lesser extent. Detectable quantities of smoke precede detectable levels of heat in most cases. Smoke alarms should be installed outside of each sleeping area and on each storey of the home. DSC recommends that additional smoke alarms beyond those required for minimum protection be installed. Additional areas that should be protected include: the basement; bedrooms, especially where smokers sleep; dining rooms; furnace and utility rooms; and any hallways not protected by the required units.

On smooth ceilings, detectors may be spaced 9.1m (30 feet) apart as a guide. Other spacing may be required depending on ceiling height, air movement, the presence of joists, uninsulated ceilings, etc. Consult National Fire Alarm Code NFPA 72, CAN/ULC-S553-02 or other appropriate national standards for installation recommendations.

- Do not locate smoke detectors at the top of peaked or gabled ceilings; dead air space in these locations may prevent smoke detection.
- Avoid areas with turbulent air flow, such as near doors, fans or windows. Rapid air movement around the detector may prevent smoke from entering the unit.
- Do not locate detectors in areas of high humidity.
- Do not locate detectors in areas where the temperature rises above 38°C (100°F) or falls below 5°C (41°F).

Smoke detectors should always be installed in USA in accordance with section 11 of NFPA 72, the National Fire Alarm Code: 11.5.1.1. Where required by applicable laws, codes, or standards for a specific type of occupancy, approved single- and multiple-station smoke alarms shall be installed as follows:

1. In all sleeping rooms and guest rooms.
2. Outside of each separate dwelling unit sleeping area, within 6.4 m (21 ft) of any door to a sleeping room, the distance measured along a path of travel.
3. On every level of a dwelling unit, including basements.
4. On every level of a residential board and care occupancy (small facility), including basements and excluding crawl spaces and unfinished attics.
5. In the living area(s) of a guest suite.
6. In the living area(s) of a residential board and care occupancy (small facility).




Figure 1




Figure 2




Figure 3




Figure 3a

- Smoke detectors for better protection
- Smoke detectors for minimum protection




Figure 4

CO Detectors

CO gas moves freely in the air. The human body is most vulnerable to the effects of CO gas during sleeping hours. For maximum protection, a CO alarm should be located outside primary sleeping areas or on each level of your home. Figure 5 indicates the suggested locations in the home. The electronic sensor detects carbon monoxide, measures the concentration and sounds a loud alarm before a potentially harmful level is reached.

Do **NOT** place the CO alarm in the following areas:

- Where the temperature may drop below -10°C or exceed 40 °C.
- Near paint thinner fumes.
- Within 5 feet (1.5 meters) of open flame appliances such as furnaces, stoves and fireplaces.
- In exhaust streams from gas engines, vents, flues or chimneys.
- Do not place in close proximity to an automobile exhaust pipe; this will damage the detector.




Figure 5

■ CARBON MONOXIDE DETECTOR

Limited Warranty

Digital Security Controls warrants the original purchaser that for a period of twelve months from the date of purchase, the product shall be free of defects in materials and workmanship under normal use. During the warranty period, Digital Security Controls shall, at its option, repair or replace any defective product upon return of the product to its factory, at no charge for labour and materials. Any replacement and/or repaired parts are warranted for the remainder of the original warranty or ninety (90) days, whichever is longer. The original purchaser must promptly notify Digital Security Controls in writing that there is a defect in material or workmanship, such written notice to be received in all events prior to expiration of the warranty period. There is absolutely no warranty on software and all software products are sold as a user license under the terms of the software license agreement included with the product. The Customer assumes all responsibility for the proper selection, installation, operation and maintenance of any products purchased from DSC. Custom products are only warranted to the extent that they do not function upon delivery. In such cases, DSC can replace or credit at its option.

International Warranty

The warranty for international customers is the same as for any customer within Canada and the United States, with the exception that Digital Security Controls shall not be responsible for any customs fees, taxes, or VAT that may be due.

Warranty Procedure

To obtain service under this warranty, please return the item(s) in question to the point of purchase. All authorized distributors and dealers have a warranty program. Anyone returning goods to Digital Security Controls must first obtain an authorization number. Digital Security Controls will not accept any shipment whatsoever for which prior authorization has not been obtained.

Conditions to Void Warranty

This warranty applies only to defects in parts and workmanship relating to normal use. It does not cover:

- damage incurred in shipping or handling;
- damage caused by disaster such as fire, flood, wind, earthquake or lightning;
- damage due to causes beyond the control of Digital Security Controls such as excessive voltage, mechanical shock or water damage;
- damage caused by unauthorized attachment, alterations, modifications or foreign objects;
- damage caused by peripherals (unless such peripherals were supplied by Digital Security Controls Ltd.);
- defects caused by failure to provide a suitable installation environment for the products;
- damage caused by use of the products for purposes other than those for which it was designed;
- damage from improper maintenance;
- damage arising out of any other abuse, mishandling or improper application of the products.

Note to Installers

This warning contains vital information. As the only individual in contact with system users, it is your responsibility to bring each item in this warning to the attention of the users of this system.

System Failures

This system has been carefully designed to be as effective as possible. There are circumstances, however, involving fire, burglary, or other types of emergencies where it may not provide protection. Any alarm system of any type may be compromised deliberately or may fail to operate as expected for a variety of reasons. Some but not all of these reasons may be:

- Inadequate Installation

A security system must be installed properly in order to provide adequate protection. Every installation should be evaluated by a security professional to ensure that all access points and areas are covered. Locks and latches on windows and doors must be secure and operate as intended. Windows, doors, walls, ceilings and other building materials must be of sufficient strength and construction to provide the level of protection expected. A reevaluation must be done during and after any construction activity. An evaluation by the fire and/or police department is highly recommended if this service is available.

Criminal Knowledge

This system contains security features which were known to be effective at the time of manufacture. It is possible for persons with criminal intent to develop techniques which reduce the effectiveness of these features. It is important that a security system be reviewed periodically to ensure that its features remain effective and that it be updated or replaced if it is found that it does not provide the protection expected.

- Access by Intruders

Intruders may enter through an unprotected access point, circumvent a sensing device, evade detection by moving through an area of insufficient coverage, disconnect a warning device, or interfere with or prevent the proper operation of the system.

- Power Failure

Control units, intrusion detectors, smoke detectors and many other security devices require an adequate power supply for proper operation. If a device operates from batteries, it is possible for the batteries to fail. Even if the batteries have not failed, they must be charged, in good condition and installed correctly. If a device operates only by AC power, any interruption, however brief, will render that device inoperative while it does not have power. Power interruptions of any length are often accompanied by voltage fluctuations which may damage electronic equipment such as a security system. After a power interruption has occurred, immediately conduct a complete system test to ensure that the system operates as intended.

- Failure of Replaceable Batteries

This system's wireless transmitters have been designed to provide several years of battery life under normal conditions. The expected battery life is a function of the device environment, usage and type. Ambient conditions such as high humidity, high or low temperatures, or large temperature fluctuations may reduce the expected battery life. While each transmitting device has a low battery monitor which identifies when the batteries need to be replaced, this monitor may fail to operate as expected. Regular testing and maintenance will keep the system in good operating condition.

- Compromise of Radio Frequency (Wireless) Devices

Signals may not reach the receiver under all circumstances which could include metal objects placed on or near the radio path or deliberate jamming or other inadvertent radio signal interference.

- System Users

A user may not be able to operate a panic or emergency switch possibly due to permanent or temporary physical disability, inability to reach the device in time, or unfamiliarity with the correct operation. It is important that all system users be trained in the correct operation of the alarm system and that they know how to respond when the system indicates an alarm.

- Smoke Detectors

Smoke detectors that are a part of this system may not properly alert occupants of a fire for a number of reasons, some of which follow. The smoke detectors may

IMPORTANT - READ CAREFULLY: DSC Software purchased with or without Products and Components is copyrighted and is purchased under the following license terms:

- This End-User License Agreement ("EULA") is a legal agreement between You (the company, individual or entity who acquired the Software and any related Hardware) and Digital Security Controls, a division of Tyco Safety Products Canada Ltd. ("DSC"), the manufacturer of the integrated security systems and the developer of the software and any related products or components ("SOFTWARE") which You acquired.
- If the DSC software product ("SOFTWARE PRODUCT" or "SOFTWARE") is intended to be accompanied by HARDWARE, and is NOT accompanied by new HARDWARE, You may not use, copy or install the SOFTWARE PRODUCT. The SOFTWARE PRODUCT includes computer software, and may include associated media, printed materials, and "online" or electronic documentation.
- Any software provided along with the SOFTWARE PRODUCT that is associated with a separate end-user license agreement is licensed to You under the terms of that license agreement.
- By installing, copying, downloading, storing, accessing or otherwise using the SOFTWARE PRODUCT, You agree unconditionally to be bound by the terms of this EULA, even if this EULA is deemed to be a modification of any previous arrangement or contract. If You do not agree to the terms of this EULA, DSC is unwilling to license the SOFTWARE PRODUCT to You, and You have no right to use it.

SOFTWARE PRODUCT LICENSE

The SOFTWARE PRODUCT is protected by copyright laws and international copyright treaties, as well as other intellectual property laws and treaties. The SOFTWARE PRODUCT is licensed, not sold.

1. GRANT OF LICENSE This EULA grants You the following rights:

- Software Installation and Use - For each license You acquire, You may have only one copy of the SOFTWARE PRODUCT installed.
- Storage/Network Use - The SOFTWARE PRODUCT may not be installed, accessed, displayed, run, shared or used concurrently on or from different computers, including a workstation, terminal or other digital electronic device ("Device"). In other words, if You have several workstations, You will have to acquire a license for each workstation where the SOFTWARE will be used.
- Backup Copy - You may make back-up copies of the SOFTWARE PRODUCT, but You may only have one copy per license installed at any given time. You may use the back-up copy solely for archival purposes. Except as expressly provided in this EULA, You may not otherwise make copies of the SOFTWARE PRODUCT, including the printed materials accompanying the SOFTWARE.

2. DESCRIPTION OF OTHER RIGHTS AND LIMITATIONS

- Limitations on Reverse Engineering, Decompilation and Disassembly - You may not reverse engineer, decompile, or disassemble the SOFTWARE PRODUCT, except only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation. You may not make any changes or modifications to the Software, without the written permission of an officer of DSC. You may not remove any proprietary notices, marks or labels from the Software Product. You shall institute reasonable measures to ensure compliance with the terms and conditions of this EULA.
- Separation of Components - The SOFTWARE PRODUCT is licensed as a single product. Its component parts may not be separated for use on more than one HARDWARE unit.
- Single INTEGRATED PRODUCT - If You acquired this SOFTWARE with HARDWARE, then the SOFTWARE PRODUCT is licensed with the HARDWARE as a single integrated product. In this case, the SOFTWARE PRODUCT may only be used with the HARDWARE as set forth in this EULA.
- Rental - You may not rent, lease or lend the SOFTWARE PRODUCT. You may not make it available to others or post it on a server or web site.
- Software Product Transfer - You may transfer all of Your rights under this EULA only as part of a permanent sale or transfer of the HARDWARE, provided You retain no copies, You transfer all of the SOFTWARE PRODUCT (including all component parts, the media and printed materials, any upgrades and this EULA), and provided the recipient agrees to the terms of this EULA. If the SOFTWARE PRODUCT is an upgrade, any transfer must also include all prior versions of the SOFTWARE PRODUCT.
- Termination - Without prejudice to any other rights, DSC may terminate this EULA if You fail to comply with the terms and conditions of this EULA. In such event, You must destroy all copies of the SOFTWARE PRODUCT and all of its component parts.
- Trademarks - This EULA does not grant You any rights in connection with any trademarks or service marks of DSC or its suppliers.

3. COPYRIGHT - All title and intellectual property rights in and to the SOFTWARE PRODUCT (including but not limited to any images,

Items Not Covered by Warranty

In addition to the items which void the Warranty, the following items shall not be covered by Warranty: (i) freight cost to the repair centre; (ii) products which are not identified with DSC's product label and lot number or serial number; (iii) products disassembled or repaired in such a manner as to adversely affect performance or prevent adequate inspection or testing to verify any warranty claim. Access cards or tags returned for replacement under warranty will be credited or replaced at DSC's option. Products not covered by this warranty, or otherwise out of warranty due to age, misuse, or damage shall be evaluated, and a repair estimate shall be provided. No repair work will be performed until a valid purchase order is received from the Customer and a Return Merchandise Authorization number (RMA) is issued by DSC's Customer Service.

Digital Security Controls Ltd.'s liability for failure to repair the product under this warranty after a reasonable number of attempts will be limited to a replacement of the product, as the exclusive remedy for breach of warranty. Under no circumstances shall Digital Security Controls be liable for any special, incidental, or consequential damages based on breach of warranty, breach of contract, negligence, strict liability, or any other legal theory. Such damages include, but are not limited to, loss of profits, loss of the product or any associated equipment, cost of capital, cost of substitute or replacement equipment, facilities or services, down time, purchaser's time, the claims of third parties, including customers, and injury to property. The laws of some jurisdictions limit or do not allow the disclaimer of consequential damages. If the laws of such a jurisdiction apply to any claim by or against DSC, the limitations and disclaimers contained here shall be to the greatest extent permitted by law. Some states do not allow the exclusion or limitation of incidental or consequential damages, so that the above may not apply to you.

Disclaimer of Warranties

This warranty contains the entire warranty and shall be in lieu of any and all other warranties, whether expressed or implied (including all implied warranties of merchantability or fitness for a particular purpose) and of all other obligations or liabilities on the part of Digital Security Controls. Digital Security Controls neither assumes responsibility for, nor authorizes any other person purporting to act on its behalf to modify or to change this warranty, nor to assume for it any other warranty or liability concerning this product. This disclaimer of warranties and limited warranty are governed by the laws of the province of Ontario, Canada.

WARNING: Digital Security Controls recommends that the entire system be completely tested on a regular basis. However, despite frequent testing, and due to, but not limited to, criminal tampering or electrical disruption, it is possible for this product to fail to perform as expected.

Out of Warranty Repairs

Digital Security Controls will at its option repair or replace out-of-warranty products which are returned to its factory according to the following conditions. Anyone returning goods to Digital Security Controls must first obtain an authorization number. Digital Security Controls will not accept any shipment whatsoever for which prior authorization has not been obtained.

Products which Digital Security Controls determines to be repairable will be repaired and returned. A set fee which Digital Security Controls has predetermined and which may be revised from time to time, will be charged for each unit repaired.

Products which Digital Security Controls determines not to be repairable will be replaced by the nearest equivalent product available at that time. The current market price of the replacement product will be charged for each replacement unit.

WARNING - READ CAREFULLY

have been improperly installed or positioned. Smoke may not be able to reach the smoke detectors, such as when the fire is in a chimney, walls or roofs, or on the other side of closed doors. Smoke detectors may not detect smoke from fires on another level of the residence or building.

Every fire is different in the amount of smoke produced and the rate of burning. Smoke detectors cannot sense all types of fires equally well. Smoke detectors may not provide timely warning of fires caused by carelessness or safety hazards such as smoking in bed, violent explosions, escaping gas, improper storage of flammable materials, overloaded electrical circuits, children playing with matches or arson.

Even if the smoke detector operates as intended, there may be circumstances when there is insufficient warning to allow all occupants to escape in time to avoid injury or death.

- Motion Detectors

Motion detectors can only detect motion within the designated areas as shown in their respective installation instructions. They cannot discriminate between intruders and intended occupants. Motion detectors do not provide volumetric area protection. They have multiple beams of detection and motion can only be detected in unobstructed areas covered by these beams. They cannot detect motion which occurs behind walls, ceilings, floor, closed doors, glass partitions, glass doors or windows. Any type of tampering whether intentional or unintentional such as masking, painting, or spraying of any material on the lenses, mirrors, windows or any other part of the detection system will impair its proper operation.

Passive infrared motion detectors operate by sensing changes in temperature. However their effectiveness can be reduced when the ambient temperature rises near or above body temperature or if there are intentional or unintentional sources of heat in or near the detection area. Some of these heat sources could be heaters, radiators, stoves, barbecues, fireplaces, sunlight, steam vents, lighting and so on.

- Warning Devices

Warning devices such as sirens, bells, horns, or strobes may not warn people or waken someone sleeping if there is an intervening wall or door. If warning devices are located on a different level of the residence or premise, then it is less likely that the occupants will be alerted or awakened. Audible warning devices may be interfered with by other noise sources such as stereos, radios, televisions, air conditioners or other appliances, or passing traffic. Audible warning devices, however loud, may not be heard by a hearing-impaired person.

- Telephone Lines

If telephone lines are used to transmit alarms, they may be out of service or busy for certain periods of time. Also an intruder may cut the telephone line or defeat its operation by more sophisticated means which may be difficult to detect.

- Insufficient Time

There may be circumstances when the system will operate as intended, yet the occupants will not be protected from the emergency due to their inability to respond to the warnings in a timely manner. If the system is monitored, the response may not occur in time to protect the occupants or their belongings.

- Component Failure

Although every effort has been made to make this system as reliable as possible, the system may fail to function as intended due to the failure of a component.

- Inadequate Testing

Most problems that would prevent an alarm system from operating as intended can be found by regular testing and maintenance. The complete system should be tested weekly and immediately after a break-in, an attempted break-in, a fire, a storm, an earthquake, an accident, or any kind of construction activity inside or outside the premises. The testing should include all sensing devices, keypads, consoles, alarm indicating devices and any other operational devices that are part of the system.

- Security and Insurance

Regardless of its capabilities, an alarm system is not a substitute for property or life insurance. An alarm system also is not a substitute for property owners, renters, or other occupants to act prudently to prevent or minimize the harmful effects of an emergency situation.

photographs, and text incorporated into the SOFTWARE PRODUCT), the accompanying printed materials, and any copies of the SOFTWARE PRODUCT, are owned by DSC or its suppliers. You may not copy the printed materials accompanying the SOFTWARE PRODUCT. All title and intellectual property rights in and to the content which may be accessed through use of the SOFTWARE PRODUCT are the property of the respective content owner and may be protected by applicable copyright or other intellectual property laws and treaties. This EULA grants You no rights to use such content. All rights not expressly granted under this EULA are reserved by DSC and its suppliers.

4. EXPORT RESTRICTIONS - You agree that You will not export or re-export the SOFTWARE PRODUCT to any country, person, or entity subject to Canadian export restrictions.

5. CHOICE OF LAW - This Software License Agreement is governed by the laws of the Province of Ontario, Canada.

6. ARBITRATION - All disputes arising in connection with this Agreement shall be determined by final and binding arbitration in accordance with the Arbitration Act, and the parties agree to be bound by the arbitrator's decision. The place of arbitration shall be Toronto, Canada, and the installation manual of the arbitration shall be English.

7. LIMITED WARRANTY

(a) NO WARRANTY - DSC PROVIDES THE SOFTWARE "AS IS" WITHOUT WARRANTY. DSC DOES NOT WARRANT THAT THE SOFTWARE WILL MEET YOUR REQUIREMENTS OR THAT OPERATION OF THE SOFTWARE WILL BE UNINTERRUPTED OR ERROR-FREE.

(b) CHANGES IN OPERATING ENVIRONMENT - DSC shall not be responsible for problems caused by changes in the operating characteristics of the HARDWARE, or for problems in the interaction of the SOFTWARE PRODUCT with non-DSC-SOFTWARE or HARDWARE PRODUCTS.

(c) LIMITATION OF LIABILITY; WARRANTY REFLECTS ALLOCATION OF RISK - IN ANY EVENT, IF ANY STATUTE IMPLIES WARRANTIES OR CONDITIONS NOT STATED IN THIS LICENSE AGREEMENT, DSC'S ENTIRE LIABILITY UNDER ANY PROVISION OF THIS LICENSE AGREEMENT SHALL BE LIMITED TO THE GREATER OF THE AMOUNT ACTUALLY PAID BY YOU TO LICENSE THE SOFTWARE PRODUCT AND FIVE CANADIAN DOLLARS (CAD\$5.00), BECAUSE SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

(d) DISCLAIMER OF WARRANTIES - THIS WARRANTY CONTAINS THE ENTIRE WARRANTY AND SHALL BE IN LIEU OF ANY AND ALL OTHER WARRANTIES, WHETHER EXPRESSED OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) AND OF ALL OTHER OBLIGATIONS OR LIABILITIES ON THE PART OF DSC. DSC MAKES NO OTHER WARRANTIES. DSC NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON PURPORTING TO ACT ON ITS BEHALF TO MODIFY OR TO CHANGE THIS WARRANTY, NOR TO ASSUME FOR IT ANY OTHER WARRANTY OR LIABILITY CONCERNING THIS SOFTWARE PRODUCT.

(e) EXCLUSIVE REMEDY AND LIMITATION OF WARRANTY - UNDER NO CIRCUMSTANCES SHALL DSC BE LIABLE FOR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL OR INDIRECT DAMAGES BASED UPON BREACH OF WARRANTY, BREACH OF CONTRACT, NEGLIGENCE, STRICT LIABILITY, OR ANY OTHER LEGAL THEORY. SUCH DAMAGES INCLUDE, BUT ARE NOT LIMITED TO, LOSS OF PROFITS, LOSS OF THE SOFTWARE PRODUCT OR ANY ASSOCIATED EQUIPMENT, COST OF CAPITAL, COST OF SUBSTITUTE OR REPLACEMENT EQUIPMENT, FACILITIES OR SERVICES, DOWN TIME, PURCHASERS TIME, THE CLAIMS OF THIRD PARTIES, INCLUDING CUSTOMERS, AND INJURY TO PROPERTY.

WARNING: DSC recommends that the entire system be completely tested on a regular basis. However, despite frequent testing, and due to, but not limited to, criminal tampering or electrical disruption, it is possible for this SOFTWARE PRODUCT to fail to perform as expected.

Index

Symbols

16, 40, 41
Access Code Required for 41
Sensor Reset 31

Numerics

41
1 – Test Transmission Exception Option 39
31, 41
200 Baud Open/Close Identifier Toggle 40
24 Hour Low Temperature 29, 60
24-Hour Bell/Buzzer 28, 60
24-Hour Burglary 28, 60
24-Hour CO 28, 60, 67, 68
24-Hour Emergency 28, 60
24-Hour Flood 28
24-Hour Gas 28, 60
24-Hour Heat 28, 60
24-Hour High Temperature 60
24-Hour Holdup 28, 60
24-Hour Latch Tamper 28, 60
24-Hour Medical 28, 60
24-Hour Non Latch 60
24-Hour Non-Alarm 28, 60
24-Hour Non-Latching Tamper 29
24-Hour Panic 28, 60
24-Hour Sprinkler 28, 60
24-Hour Supervisory 28, 60
24-Hour Supervisory Buzzer 28, 60
24-Hour Water 60
2-way Audio attribute 60
2-Wire Smoke 31
41
4-Digit Access Codes 42
50Hz AC/60Hz AC 41
41
6-Digit Access Codes 42
31, 40

A

About the System 1
AC Fail Trouble Beeps Option 40
AC Failure Communication Delay 48, 50
AC Trouble Display Option 38
AC Trouble Option 38
AC, Wiring 9
AC/DC Inhibits Arming 41
Access 20
Access Code Length 42
Access Codes 22
Access codes, adding 19
Access While Armed 40
Accessibility Option 41
Account Code 50
Account Code Error Checking 50
Account Codes 47, 82
Acknowledging Troubles 18
Activity Delinquency 49
Add/Remove Modules 53
Alarm Canceled 44
Alarm Memory Display 18
Alarm When Armed Event Message 27

Alt. Comm Battery Trouble/Restore 46
Alt. Comm Communications Fault/Restore 46
Alt. Comm Ethernet Trouble /Restore 46
Alt. Comm Lockout Trouble/Restore 46
Alt. Comm Network Fault/Restore 46
Alt. Comm Power Supply Trouble/Restore 46
Alt. Comm Radio/SIM Failure/Restore 46
Alternate Communicator 32
Alternate Communicator Auto Routing (dual-path) 43
Alternate Communicator DLS/SA Option 51
Alternate Communicator Enable/Disable 50
Alternate Communicator Label 27
Alternate Communicator, Installing 5
Alternate Dial 49
Annunciation 15
Approvals 110
ASCII Characters 26
ASCII Entry 26
Audible 24-Hour Input 32
Audible Bus Fault Option 40
Audible Exit Delay 38
Audible Exit Delay for Stay Arming 40
Audible Exit Fault 37
Audio Verification 23
Audio Verification Module, Installing 5
Auto Arm Cancellation/Postpone 44
Auto Detection 13
Auto DLS Options 51
Auto Enroll Modules 53
Auto Verify Fire 28, 60
Auto-Arm Schedule Programming 37
Auto-Arm Time 21
Auto-Arm/Disarm 21
Auto-Arming Bypass 40
Automatic Clock Adjust 30
Automatic Closing/Opening 44
Automatic DLS/SA Options 51
Automatic Zone Bypass/Unbypass 44
Aux Power Wiring 8
Auxiliary Input Alarm and Restore 44
Auxiliary Power Supply Trouble/Restore 45
Available Models 1
Available User Codes 19
Away Armed Status 32
Away Armed with No Zone Bypasses Status 32
Away to Stay Toggle 40

B

Batteries, wiring 9
Battery Settings 54
Bell Audible 29
Bell Circuit Trouble/Restore 45
Bell Cutoff 30
Bell Cutoff Time 30
Bell Duration Auto-Arm 38
Bell Pulsed 29, 60
Bell Squawk Attribute 20
Bell Squawk on Away Arming/Disarming 39
Bell Squawk on Away Arming/Disarming Option 39
Bell Squawk On Entry Option 38
Bell Squawk On Exit Option 38

Bell Squawk On Trouble Option 38
Bell Squawk Option 38
Bell Status and Programming Access Output 33
Bell Timeout 11
Bell Wiring 6
Bell/PGM Support 12
Bell/Siren Configuration 12
Bell/Siren Operation 11
binary data input 25
Brightness Control 21
Burglary Verified Counter 42
Burglary and Fire Bell Follower 31
Burglary Not Verified 44
Burglary Verification 29
Burglary Verification Selection 42
Burglary Verification Timer 30
Burglary Verified 44
Buzzer Control 22
Bypass Enabled 29, 60
Bypass Open Zones 17
Bypass Recall 17
Bypass Status Display Option 39
Bypass Stay/Away/Night Zones 17

C

Call Waiting Cancel 49
Call Waiting Cancel String 43, 79
Capacitance 5
Change Case 26
Chime Function 29, 60
Chime on Closing 39
Chime on Opening 39
Clear Bypasses 17
Clear Display 26
Clear to End 26
Closing Confirmation 49
CO Alarm Message 27
CO Detector, Wiring 8
Cold Start 45
Combustion
capacitance 5
line loss 5
Command Outputs 1, 3, 4 22
Command Outputs 1-4 22, 32
Commands 16
Communication Attempt Limit 13
Communication Delay 48
Communication Paths 13, 43
Communication Variables 47, 84
Communications 12
Communications Enabled/Disabled 48
Communications Options 13
Communications Paths 79
Communications Priority 49
Communicator Backup Options 50
Communicator Formats 47, 84
Communicator Option One 48
Compatible Devices 2
Configuration steps 10
Confirm Module 54
Connecting Power 6
Contact ID 98
Contrast Control 22

- Control Panel Information 53
- Control Panel Installation 3
- Controls and Indicators 10
- Corbus Wiring 4
- Courtesy Pulse 31
- Crystal Timebase 41
- Current Calculation
 - main panel 4
- Current Rating
 - module 4

D

- Data, Entering 10
- Day Zone 28, 60
- Daylight Savings Begin/End 30
- Daylight Savings Time 39
- Daylight Savings Time Option 39
- DC Trouble 33
- Default All Keypad Programming 54
- Default All labels 12
- Default Alternate Communicator 54
- Default Keypads 1-8 54
- Default Labels 27
- Default Master Code 54
- Default System 54
- Default, Hardware 12
- Defaults 54
- Delay 1 27, 60
- Delay 2 27, 60
- Delay Call Window 52
- Delay Stay/Away 28, 60
- Delayed 24-Hour Fire 28, 60
- Delayed Fire and Burglary 31
- Delete Module 53
- Delinquency 45, 49
- DEOL 30, 60
- Device Supervision 11
- DLS Access Code 51
- DLS Call-Back Enabled/Disabled 50
- DLS Disconnect 41
- DLS Lead In and Lead Out 45
- DLS Phone Number Programming 51
- DLS Programming 24, 50
- DLS Window 41
- DLS/SA Panel ID 51
- Door Bell 29, 60
- Door Chime 15
- Door Chime Enable/Disable 19
- Double Call 50
- Double End of Line Resistors 7
- DTMF/Pulse Dialing Option 49
- Duress Alarm 44
- Duress Code Attribute 20
- Duress Codes 19, 40

E

- Enable DLS/Allow System Service 21
- End-of-Line Options SEOL/SEOL 37
- Enrolling 1st Keypad 11
- Enrolling Devices 10
- Enrolling Keypads 10
- Entry Delay 1 30
- Entry Delay 1-2 30
- Entry Delay 2 30
- Entry Delay Only Attribute 20
- European Dial 41

- Event Buffer 21
- Event Buffer 75% Full 45
- Event Buffer Swinger 37
- Event Buffers, Viewing 13
- Event Labels 15
- Event Reporting 43
- Exit Delay 30
- Exit Delay Restart 40
- Exit Delay Termination Option 38
- Exit Fault 44

F

- Fail To Arm Event Message 27
- Fast Loop/Normal Loop Response 30
- Faults and Errors 104
- Fire Alarm Message 27
- Fire and CO Zone Types 12
- Fire Bell Timeout Option 38
- Fire Key Option 38
- Fire Key Options 40
- Fire Pre-Alerts 11
- Fire Supervisory 28, 60
- Fire Trouble & Restore 45
- Firmware Update Begin/was Successful 45
- Firmware Update Fail 45
- Force Arm 29, 60
- Force Dial Option 41
- Freeze Trouble/Restore 45
- FTC Bell Option 41
- FTC Events Communicate 50
- Full Enrollment 11
- Function Key Definitions 15
- Function Keys 15

G

- Gas Trouble/Restore 45
- Global Keypad, vs Partition 14
- Global Zones 12
- Global/Multi Partition 12
- Global/Multiple Partition Operation 14
- Ground Start 32
- Ground Wiring 9

H

- Hardware Default 12
- Hardware Reset 12
- Heat Trouble/Restore 45
- Hex and Decimal Data, Programming 25
- HEX Programming 25
- High Current Output Battery 54
- High-Current Output Supply Label 27
- Holdup Output 32
- Holdup Time 30
- Hold-Up Verification Counter 42
- Holiday Schedules 52
- HSM2HOST Label 27

I

- I.D. Tone Option 41
- I/O Module, Installing 5
- ICON keypad 25
- Installation 3
- Installer Code 19, 30
- Installer Defined Codes 63

- Installer Lead In and Lead Out 45
- Installer Lockout 54
- Installer Programming 22, 25
- Installer Walk Test 13
- Installer Walk Test Enable/Disable 53
- Instant 27, 60
- Instant Stay/Away 28, 60
- Interior 27, 60
- Interior Delay 28, 60
- Interior Stay/Away 28, 60
- Interval Toggles-Holidays 52
- IP/Cellular Fault Check Timer 48
- IP/GS Wait for Ack 84

K

- Key Annunciation 38
- Keypad Backlighting Option 39
- Keypad Blanking Option 39
- Keypad Blanking Requires Code 39
- Keypad Blanking While Armed 40
- Keypad Buzzer Alarm Option 40
- Keypad Buzzer Follow 31
- Keypad Fire Alarm 44
- Keypad Function Keys 15
- Keypad Labels 27
- Keypad Lockout 37, 44
- Keypad Lockout, Number of Invalid Local Attempts 37
- Keypad Medical Alarm 44
- Keypad Panic Alarm 44
- Keypad Partition Operation 12
- Keypad Tamper Option 39
- Keypad Types 25
- Keypad Zone Assignment 6
- Keypads, Default to Factory Settings 54
- Keyswitch Arms in Away Mode 40
- Kissoff 32

L

- Label 26
- Label Programming 26
- labels, defaulting 12
- Labels, Event 15
- Labels, Module 14
- Labels, Partition 14
- Labels, Partition Command Output 15
- Labels, Zone 14
- Land Line Test Transmission Option 41
- Language Selection 16, 26
- Latch Tamper 28, 60
- Latched System Event (Stroke) 33
- Latching Troubles Option 40
- Late to Close Option 39
- Late to Close/Open 44
- Late to Open 21
- Late to Open Time 21
- LCD Keypad 25
- LED Indicators 10
- LED keypad 25
- letter case 26
- Line Loss 5
- Loaned Partition 12
- Local Firmware Upgrade 13
- Lockout 37
- Low Signal Trouble and Restore 46
- Low Temperature Warning 15

M

- Maid's Code Attribute 20
- Main Bell Mask 33
- Main Bell Operational Mask 31
- Maintain Arm 29, 60
- Maintain Disarm 29, 60
- Maintenance Code 19, 30
- Manual Enroll 53
- Manual Enrollment 11
- Master Code 19, 30
- Master Code Option 38
- Model Differences 1
- Module AC Trouble/Restore 45
- Module Aux Trouble/Restore 46
- Module Battery Absent/Restore 46
- Module Battery Trouble/Restore 46
- Module Information 53
- Module Labels 14
- Module Low Voltage Trouble/Restore 46
- Module Supervisory Trouble/Restore 46
- Module Tamper/Restore 44
- Modules, Installing 5
- Modules, Removing 11
- Momentary Arm 29, 60
- Momentary Disarm 29, 60
- Mounting 3
- Multi Hit Option 39
- Multiple Siren Output Operation 11

N

- NC Loop/EOL 37
- Network Fault and Restore 46
- Night Zone 28, 60
- No Entry Arming 22
- Normally Closed 29
- Normally Closed (NC) Loops 60
- Null PGM 31
- Null Zone 27, 60
- Number of Rings to Answer On 51

O

- One Time User Code 19
- One Time User Code Attribute 20
- Open After Alarm 33
- Open/Close Events 44
- Opening after Alarm 44
- Opening After Alarm Bell Ringback 49
- Opening After Alarm Keypad Ringback 49
- Output 1 Fault/Restore 46
- Output Expander Label 27
- Output Expander, Installing 5
- Overview of Installation Process 3

P

- 38
- Panel AC Fail Trouble/Restore 45
- Panel Battery Absent Trouble/Restore 45
- Panel Battery Settings 54
- Panel Call-Up Baud Rate Option 51
- Panel Low Battery Trouble/Restore 45
- Panel/Receiver Communication Paths 43
- Parallel Communications 49
- Partial Closing 44
- Partition 1 to 8 Enable Mask 42
- Partition 1-8 Labels 27

- Partition 1-8 Timer 30
- Partition Account Codes 47
- Partition Auto-Arm Postpone Timer 42
- Partition Auto-Arm/Disarm 74, 75, 76
- Partition Auto-Arm/Disarm 42
- Partition Auto-Arming Pre-Alert Timer 42
- Partition Auto-Arming Times 42
- Partition Auto-Disarming Holiday Schedules 42
- Partition Auto-Disarming Times 42
- Partition Call Directions 47, 82, 83
- Partition Command Output Labels 15, 27, 58
- Partition Labels 14
- Partition Mask 42, 77
- Partition No Activity Arm Timer 42
- Partition No Activity Arming Pre-Alert Duration 42
- Partition Status Alarm Memory 32
- Partition vs. Global Keypad 14
- Partition Zone Assignment 43
- Partition, Setting Up 11
- Partitions, Assigning to Users 20
- Partitions, Working With 11
- PC-Link, Local Programming with 24
- PC-Link, Programming 24
- Periodic DLS 51
- Periodic DLS Days 51
- Periodic DLS Time 52
- Periodic Test Transmission 46
- Periodic Test Transmission with Trouble 46
- PGM 1-28 Attributes 34
- PGM 2 2-Wire Alarm/Restore 44
- PGM 2 Two-Wire Trouble/Restore 45
- PGM Attributes 33, 67
- PGM Configuration Options 37, 70
- PGM Output Types 66
- PGM Partition Assignment 31, 63, 64
- PGM Timer Programming 31
- PGM Timers 65, 70
- PGM Wiring 6
- Phone Number Account Code 50
- Phone Number Programming, Central Station 43
- Placement Test Wireless keys 54
- Placement Test Zones 1-128 54
- Power Save Mode Option 39
- Power Supply Label 27
- Power-up Sequence 10
- Pre-Enrollment 11
- Priority Alarms 44
- Probe Disconnected Trouble/Restore 45
- Program Group 1 17
- Program User Codes 19
- Programming Methods 26
- Programming Schedule 1 52
- Programming, DLS 24
- Programming, How to 24
- Programming, Installer 25
- Programming, Template 24
- Proximity Tag Used 33
- Proximity Tags, Assigning 20
- PSTN 1 Communication Path 43
- PSTN Double Call Timer 51
- Pulse Dial after 5th attempt 49

Q

- Quick Arm/Exit 22
- Quick Arming /Function Key Option 38
- Quick Exit Option 38

R

- Ready LED Flashes for Force Arming 40
- Ready to Arm 31
- Real Time Clock 13
- Real Time Clock Option 41
- Real-Time Redundant Communications 13
- Receiver 1 to 4 FTC Trouble and Restore 45
- Receiver 1 to 4 Supervision Failure and Restore 46
- Receiver 1 to 4 Trouble and Restore 46
- Receiver 2 Backup Option 50
- Receiver 3 Backup Option 50
- Receiver 4 Backup Option 50
- Recent Closing 44
- Reduced Dialing Attempts 49
- Regulatory Approvals 105, 110, 114, 115
- Remote Firmware Upgrade 13
- Remote Firmware Upgrade, Modules 13
- Remote Firmware Upgrade, Panel 13
- Remote Lockout 37
- Remote Lockout Duration 37
- Remote Operation 33
- Remote Programming 24
- Remote Reset 40
- Repeater Labels 27
- Reporting 43
- Reporting Codes 98
- Restore Transmission on Bell Timeout 48
- RF Jam Trouble/Restore 45

S

- SA Access Code 51
- SA Lead In and Lead Out 45
- Save Label 26
- Schedule Labels 27
- Schedule Programming 52
- Select Option menu 26
- SEOL 30
- Sequential Detection 60
- Set End Day 52
- Set End Time 52
- Set Start Day 52
- Set Start Time 52
- Settle Delay 30
- Shared Zones 12
- SIA Format 98
- Silent 24-Hour Input 32
- Single End of Line (SEOL) Resistors 60
- Single Partition 12
- Single Partition Operation 14
- Single Siren Output Operation 11
- Siren Labels 27
- Smoke Detector, Wiring 5
- SMS Command and Control 22
- SMS Messages 23
- SMS Programming 21
- Special Closing/Opening 44
- Specifications 1
- Standard 24-Hour Fire 60
- Status LED 10
- Stay Armed Status 32
- Supervision 11
- Supervision Restore 13
- Supervisor Attribute 20
- Supervisor Codes 19
- Swinger Shut Down 29
- Swinger Shutdown 29, 47, 60

- System Account Code 47, 50
- System Area 30
- System Armed Status 32
- System Call Direction 47, 82
- System Information 53
- System Label 27
- System Labels 14
- System Lockout 37
- System Option 1 37, 73
- System Option 10 40
- System Option 11 40, 73
- System Option 12 41
- System Option 13 41, 73
- System Option 2 38
- System Option 3 38, 73
- System Option 4 38
- System Option 5 39, 73
- System Option 6 39
- System Option 7 40, 73
- System Option 8 40
- System Option 9 40, 73
- System Tamper 33
- System Test 21, 46
- System Trouble 32

T

- Tampers Inhibit Arming 41
- Telephone Line Monitor Audible When Armed 38
- Telephone Line Monitor Option 38
- Telephone Line Trouble and Restore 45
- Telephone Line Wiring 6
- Temperature Display 15
- Temperature in Celsius 40
- Template Programming 24
- Temporal Three Fire Signaling 37
- Test Transmission Cycle 48
- Test Transmission Receiver 49
- Testing 54
- Testing the System 13
- Time and Date 21
- TLM and Alarm 32
- TLM Trouble Delay 48
- Tone Generated-1200Hz 41
- Transmission Counter in Hours 40
- Transmission Delay 29, 60
- Trouble Beeps Control 40
- Trouble Display 17
- Trouble Indicators 12
- Troubleshooting 93

U

- User Authentication 42
- User Authentication Options 20, 22
- User Call-up 21
- User Call-Up Enabled/Disabled 51
- User Closing/Opening 44
- User code and proximity tag 20, 42
- User Code Attributes 20
- User code or proximity tag 20, 42
- User Codes 19
- User Codes, Assigning 19
- User Enables/Disables DLS 50
- User Functions 21
- User Labels, Adding 20
- User Walk Test 21
- Using the Keypad 10

V

- Verified Events 42
- Video Verification 23
- Viewing Event Buffers 13
- Viewing Programming 25
- Voice Chime 15

W

- Walk Test 13
- Walk Test Communications 49
- Walk Test Start & End 46
- Wireless Device AC Failure/Restore 46
- Wireless Device Fault/Restore 46
- Wireless Device Low Battery Transmission Delay 48
- Wireless Device Low Battery Trouble/Restore 46
- Wireless Devices, Enrolling 11
- Wireless Placement Test 54
- Wireless Receiver, Default 54
- Wireless Transceiver Module, Wiring 5
- Wiring 3
- Word Library 26
- Words 26

Z

- Zone Assignment, Partition 43
- Zone Attributes 29, 60
- Zone Bypassing Attribute 20
- Zone Expander Labels 27
- Zone Expander Supervisory Alarm and Restore 44
- Zone Expander, Installing 5
- Zone Fault Label 27
- Zone Follow PGM By Zone 33
- Zone Follower 33
- Zone Label Options 26
- Zone Labels 14, 26, 57
- Zone Loop Options 37
- Zone Loop Response Time 30
- Zone Reporting 43
- Zone Tamper Label 27
- Zone Types 27, 60
- Zone Types, Fire and CO 12
- Zone Wiring 6

© 2014 Tyco International Ltd. and its Respective Companies. All Rights Reserved.

The trademarks, logos, and service marks displayed on this document are registered in the United States [or other countries]. Any misuse of the trademarks is strictly prohibited and Tyco International Ltd. will aggressively enforce its intellectual property rights to the fullest extent of the law, including pursuit of criminal prosecution where necessary. All trademarks not owned by Tyco International Ltd. are the property of their respective owners, and are used with permission or allowed under applicable laws.

Product offerings and specifications are subject to change without notice. Actual products may vary from photos. Not all products include all features. Availability varies by region; contact your sales representative.



Technical Support: 1-800-387-3630 (Can/US)
www.dsc.com

