


COMMAX Co.,Ltd. • Thank you for purchasing our COMMAX product. • Please carefully read this User's Guide (in particular, precautions for safety) before using the product and follow the instructions to use your product exactly. The company is not responsible for any safety accidents caused in abnormal operation of the product.

# Table of Contents

 $\bigcirc$ 

1. Features an	d Function 1
2. Sys	tem Layout 1
3. Wiriı	ng Diagram 2
4. Sj	pecification 2
5. Wiring method and	How to use

COMMAX Co.,Ltd.




#### Warnings and caution

٠

 $\bigcirc$ 


◎ Make sure to follow the instructions to prevent any danger or property losses.




**COMMAX Co., Ltd.** 

Warnings and caution

42



COMMAX Co.,Ltd.



## **11.** Features and Functions


#### 1. Features

Flush mouth type Digital Control Station Free Voltage power supply To be interfaces up-to 4<sup>th</sup> cameras To be interfaces up-to 20<sup>th</sup> monitors

#### 2. Function

Working with CAV-70B Working with DPV-nAS Working with Alarm Sensor

### 2. System Layout




Maximum connect with up-to 4<sup>th</sup> cameras \*Available to connect with CCTV camera Maximum connect with up-to 20<sup>th</sup> monitors

**COMMAX Co., Ltd.** 

1

### **13**. Wiring Diagram



Notes for connecting


Maximum number per line from the slave connection terminal of main unit is 5.
Please connect wiring terminal carefully on polarity.
Please use UTP (CAT. 5) for cable and 14~24AWG for others.

### 4. Specification

40


Model ITEM	CONTENTS(CDS-70M)
Transmisson	2 wires, 4wires at Entrance, 6wires at MASTER Unit
Rated voltage	DC15V
Power consumption	On standby: 100mA, On operating: 250mA
Telephone Conversation Distance	Entrance: 28M(CAT#5 cable) MASTER Unit: 20M(0.65 cable, Video-out 3C2V Coaxial cable)

COMMAX Co.,Ltd.



### **5**. Wiring Method and How to use





#### 1. Wiring Method

As the maximum, five Master-V/Ps can be connected with 1 line which is a master connection terminal of main unit.

► The maximum 20 sets of Master-V/P can be connected with 1 main unit. In case of wiring between two Master-V/Ps, an video cable must be connected as a VD/IN and VD/OUT pair.

Be careful of connection, as it is polarized cables.

In case of wrong connection, a video phone in a household shall not operate. Master ID (household video phone) must be input, unless master ID input, it shall not operate properly.

#### 2. How to use

**COMMAX Co., Ltd.** 


In case of normal connection, it shall be connected with power cord, and then, turn on the power switch.

LED shall operate, if power is on.

Refer CAV-70B and DPV-NAS user guide for another operation method. DIP S/W shall be in accordance with the number of a camera connection. If three cameras connected, DIP S/W shall turn on 1, 2 and 3 switches.

COMMAX Co.,Ltd.

4





 $\bigcirc$ 

**COMIMAX Co.,Ltd.** a513-11, Sangdaewon-dong, Jungwon-gu, Seongnam-si, Gyeonggi-do, Korea Int'l Business Dept. : Tel.; +82-31-7393-540~550 Fax.; +82-31-745-2133 Web site : www.commax.com

Printed In Korea