

Wiegand Reader

CT & PR 1200

Colors for 8 and 12 cores cable.

Color	Function in the Wiegand reader	Notes
Black	0 V - GND	Power
Red	+ 12 V DC	Power
Blue	Extern green LED	Active on GND
Orange	Extern red LED	Active on GND
Green	D0	Wiegand 0
White	D1	Wiegand 1
Brown	Extern buzzer	Active on GND
Yellow	Hold 1, 2	
Grey	Tamper switch	
Purple	Tamper switch	
Pink		Not in use
Light green		Not in use