

REPLACING A WAY MONITOR

- Install extra monitor **Ref.1412** (monitor 1) or **Ref.1413** (monitor 2)
- Go to **MENU** Screen & press **ABOUT** button
- Hold press **KEY** button for **2 seconds**



- In the **INSTALLER SETUP**
*NOTE: Extra monitors are always programmed as **SLAVE** from factory and they show always video when receiving an incoming call.*
*There must be always one **MASTER** in the same house (1 master maximum).*
*For **MASTER** - Dial **8000** and press OK*
*For **SLAVE** - Dial **8001** and press OK*
 - Dial **8006** in case you want to have video+call signal in **SLAVE** monitor
 - Dial **8007** to not have video+call signal in **SLAVE** monitor

Important note: Batteries. This equipment contains a lithium button cell CR1120 3V 40mAH welded to the circuit. This button cell must be removed by a qualified professional and taken to the proper disposal site.

