


# ALES HTR

## Heaters with thermostat



Place jumper in position 1-2 and 3-4 to power from 10 to 15Vdc

Place jumper in position 2-3 and 4-5 to power from 20 to 30Vdc

Power supply from 10 VDC to 30 VDC

10/15Vdc = 6W, 0.4 A

20/30Vdc = 6W, 0.2 A



Mounting in Ales



**POLITEC s.r.l.**

Via Adda, 66/68 - 20882 Bellusco (MB) - Italy  
tel. +39 039 6883019 r.a. - fax +39 039 6200471  
[www.politecsrl.it](http://www.politecsrl.it)