

SETUP VESTA cameras



VESTA®



CAMERA STARTUP



STEP 1: INSERT POWER CABLE




STEP 2: WAIT FOR THE LED TO REMAIN FIXED IN GREEN (ETHERNET CONNECTION) OR FLASHING IN CASE OF WIFI SETUP.


SETUP FROM SMARTHOMESEC



Use SmartHomeSec to **initialise** the camera and **add** it to the system



STEP 1: Login to SmartHomeSec




STEP 2: Chose → Cameras → Add [+]




STEP 3: Chose → VESTA



STEP 4: Scan camera QR code




STEP 5: Select next



STEP 6: Chose communication of camera

SETUP FROM SMARTHOMESEC




STEP 7: Allow the APP to connect to a network on request




STEP 8: Select your WIFI network to which the camera will connect.




STEP 9: Enter WIFI password



STEP 10: Select IP of camera detected




STEP 11:
User name: *admin*
Password:
(Verification code of camera, label below)



SETUP COMPLETED

SETUP COMPLETED



I cannot find the IP of the camera on setup steps:

1. Ensure that the VESTA central controller is connected to the same network as the camera.
2. Restart the switch or router where the VESTA panel & Camera is connected.

I cannot complete the setup via WIFI

1. Check that you have the latest firmware in the VESTA control unit.
2. Make sure to enable the location for the SmartHomeSec APP.
3. Make sure you give the APP permissions to connect to a WIFI network, and if it asks for connection permissions allow them.




The camera is not ready:

1. Reset camera to factory settings

TRUBLE SHEET 1



Very important: Make sure to enable the connectivity permissions of the APP:



To reset the VESTA camera:

Press the button **RESET** located on the back and hold for 10 seconds (The camera will make a BEEP and the led will turn red)

NOTES: In the VESTA-292 model, the button is located under the optics



RESET